



**Océ**  
ColorWave® 300

Jump to One



**Canon**  
CANON GROUP

**User manual**  
Operating  
information

# Océ-Technologies B.V.

© 2011 Océ.

All rights reserved. No part of this work may be reproduced, copied, adapted, or transmitted in any form or by any means without written permission from Océ.

Océ makes no representation or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Further, Océ reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation to notify any person of such revision or changes.

## Trademarks

Océ, Océ ColorWave® 300 and the Océ Express WebTools are registered trademarks of Océ-Technologies B.V.

Adobe® and PostScript® 3™ are registered trademarks of Adobe® Systems Incorporated.

Macintosh® is a registered trademark of Apple® Computer, Inc.

Microsoft®, Windows®, Windows XP®, Windows Server 2003®, Windows Vista®, Windows 7® are either registered trademarks or trademarks of Microsoft® Corporation in the United States and/or other countries.

AutoCAD® is a registered trademark of Autodesk, Inc.

Mozilla Firefox™ is a registered trademark of The Mozilla Foundation.

Pentium® is a registered trademark of Intel Corporation.

ENERGY STAR® is a registered trademark of the U.S. Environmental Protection Agency (EPA).

Products in this publication are referred to by their general trade names. In most, if not all cases, these designations are claimed as trademarks or registered trademarks of their respective companies.

# Contents

## Chapter 1

<b>Introduction</b> .....	<b>11</b>
Notes for the reader.....	12
Online support for your product.....	14
Available documentation.....	16
How to use this manual.....	18
The Océ ColorWave 300 key concepts.....	21
User interaction.....	23

## Chapter 2

<b>Get to know the Océ ColorWave 300 multifunction printer</b> .....	<b>25</b>
The main components.....	26
The Océ ColorWave 300 system.....	27
Working area [Footprint].....	28
The Océ ColorWave 300 hardware and consumables.....	30
The components of the printer (front).....	30
The components of the printer (right hand side).....	32
The components of the printer (back).....	33
The components of the scanner .....	34
The components of the top delivery tray (optional).....	36
The user panel.....	37
The top delivery tray.....	40
The printing system consumables.....	44

## Chapter 3

<b>Quick start</b> .....	<b>45</b>
Connect the mains supply cable.....	46
Switch on the printing system.....	47
Replace / Install the media.....	48
The Océ Express WebTools.....	53
The Smart Inbox.....	54
Easy printing, copying and scanning.....	56
Print a file from a USB mass storage device or flash drive.....	56
Use Océ Publisher Express to send a print job.....	57
Print a job from the Smart Inbox.....	60
Use the Océ Windows® Printer Driver to send a print job.....	61
Use the Océ PostScript® 3 Driver to send a print job.....	63
Make a fast copy of a CAD drawing.....	65
Make a normal color copy.....	67
Make a fast b/w copy of a CAD drawing.....	69

---

Scan a color CAD drawing to PDF format.....	71
Scan a CAD drawing to b/w TIFF format.....	73
Scan to a USB mass storage device.....	75
Switch off the printing system.....	77

## Chapter 4

<b>Define your workflow with the Océ Express WebTools.....</b>	<b>79</b>
Introduction.....	80
The Océ Express WebTools.....	80
The system requirements.....	81
The 'Jobs' tab.....	83
The 'Preferences' tab.....	85
The 'Configuration' tab.....	86
The 'Support' tab.....	87
The 'System' tab.....	89
Set another language for the Océ Express WebTools.....	90
How to edit a setting.....	92
View and check the settings.....	95
Save the settings in a file.....	96
Load the settings from a file.....	97
Restore the factory defaults.....	98
The system monitor.....	99
Shut down or restart the system.....	101
Security.....	102
Access and passwords.....	102
User roles and authorizations.....	102
Log in as an authorized user.....	103
Log out after your session.....	104
Change the password for authorized users.....	105
Secure protocols.....	106
Enable IPSec.....	106
Enable IPv6.....	107
IPv6 settings.....	108
E-shredding.....	109
Enable or disable the E-shredding function.....	109
Select the E-shredding algorithm.....	110
Specify the number of overwrite passes.....	111
Configure your printing system.....	112
Change the regional settings.....	112
Configure the sleep mode timer.....	113
Configure the network settings in the Océ Express WebTools....	114
Configure and manage scan destinations.....	115
Configure scan destinations.....	115
Configure a local scan destination.....	117
Configure a remote scan destination.....	118

- Configure the pen settings..... 122
- Define your printing system preferences..... 123
  - What you need to know about default settings..... 123
  - Define the system preferences..... 124
  - Define the print job preferences..... 126
  - Optimize the default output quality for print jobs..... 128
  - Define the copy job preferences and copy templates..... 133
  - Optimize the default output quality for copy jobs..... 136
  - Define the scan job preferences and scan templates..... 139
  - Optimize the default output quality for scan jobs..... 142
- Manage jobs on your printing system..... 145
  - The Smart Inbox and Jobs Queue concept..... 145
  - Use Smart Inboxes in a multiple-user environment..... 148
  - Use Smart Inboxes in a repro environment..... 149
  - Open or create a Smart Inbox..... 150
  - Delete a Smart Inbox..... 151

**Chapter 5**

- Use the Océ ColorWave 300 multifunction printer..... 153**
  - Pause, resume or delete an active job ..... 154
  - The job states..... 157
  - Clear the system..... 159
  - Basic scan jobs..... 160
    - Introduction to scan jobs..... 160
    - Feed the original..... 161
    - Auto-feed the original..... 162
    - Do a basic scan job..... 164
  - Extended scan jobs..... 165
    - Introduction to scan jobs..... 165
    - Do an extended scan job..... 166
    - Available settings for scan jobs..... 168
    - 'File type' ..... 174
    - Make a scan and erase a margin..... 176
  - Basic copy jobs..... 178
    - Introduction to copy jobs..... 178
    - Feed the original..... 179
    - Auto-feed the original..... 180
    - Do a basic copy job..... 182
  - Extended copy jobs..... 184
    - Introduction to copy jobs..... 184
    - Do an extended copy job..... 185
    - Available settings for copy jobs..... 187
    - Make multiple sets of copies..... 197
    - Make a copy with a stamp..... 199
    - Scale to another media size..... 200

Make a copy and add a strip.....	202
Make a copy and erase a margin.....	204
Make a copy of a specific area of an original.....	206
Make a copy and erase a specific area of an original.....	208
Send print jobs.....	210
What you need to know before you send your print jobs.....	210
Use Océ Publisher Express to send a print job.....	211
Use the Océ Windows® Printer Driver to send a print job.....	214
Use the Océ PostScript® 3 Driver to send a print job.....	216
Use FTP to send a print job to the Océ ColorWave 300.....	218
Use LPR to send a print job to the Océ ColorWave 300.....	219
Print a job from the Smart Inbox.....	220
Print a file from a USB mass storage device or flash drive.....	221

## Chapter 6

<b>Ensure the best output quality.....</b>	<b>223</b>
Introduction to how to ensure the best output quality.....	224
Optimize the output quality of the scanner.....	226
Calibrate the scanner.....	226
Define the output quality of the printer.....	228
The quality modes.....	228
Output type, output quality and print speed.....	229
Recommended media types and quality modes.....	230
Color Management.....	238
'Color Management'.....	238
'Color feel'.....	243
Océ 'Enhanced colors: RGB input data'.....	244
Océ 'Enhanced colors: CMYK input data'.....	245
Océ 'Enhanced colors: Rendering intent'.....	246
Media.....	248
What is a media profile?.....	248
Manage media.....	249
Download and install a media profile.....	251
Input profiles.....	253
What is an input profile? .....	253
Manage input profiles.....	254
Check the output quality of the printer .....	256
'Demo print'.....	256
'Quality check' print.....	258
'Tone scale area check' print.....	259
'Color reference chart' print.....	261
Output quality problems.....	263
Optimize the output quality of the printer.....	268
Optimize the output quality on the printer .....	268

Use the 'Print quality' wizard.....272

**Chapter 7**

**Maintain the Océ ColorWave 300 multifunction printer.....275**

- Replace the media.....276
  - Replace / Install the media.....276
- Ink.....281
  - Replace the ink tanks.....281
  - Replace a defective printhead.....284
  - Replace the maintenance cassette.....290
  - Refill the ink tube.....293
  - Remote consumables reading .....297
- Maintain the scanner.....298
  - Clean the scanner.....298
  - Calibrate the scanner.....302
- Update.....304
  - Update the system software.....304

**Chapter 8**

**System messages and solutions.....307**

- The printer.....308
  - Overview.....308
  - Cover or door opened.....310
  - Remove jammed media.....313
  - Temperature or humidity out of range.....315
  - Carriage away from home position too long.....316
- The scanner.....317
  - Clear an original jam on the scanner.....317

**Chapter 9**

**License management.....319**

- Introduction to managing licenses.....320
- The 'Licenses' tab in the Océ Express WebTools.....321
- The basic workflow of 'Support' - 'Licenses' activation.....322
- Océ License Logic.....323
- The structure of license files and licenses.....324
- Check your licenses.....326
- Save the currently active licenses.....328
- Install a new license.....329

**Chapter 10**

**Software options.....335**

- Océ Repro Desk Studio.....336
  - Océ Repro Desk Studio.....336
- Account management.....337
  - An overview of Océ Account Center.....337



---

**Chapter 11**

<b>Network and Security settings</b> .....	<b>339</b>
Check or adapt the network settings.....	340
Check or adapt the security settings.....	342

**Appendix A**

<b>Specifications of the Océ ColorWave 300</b> .....	<b>345</b>
Specifications Océ ColorWave 300 printer .....	346
Specifications Océ Scanner Express.....	349
Specifications Océ PowerM controller.....	351
Specifications drivers and job submission software.....	353
Preferred Océ media names.....	355
Typical drying times.....	362
Standard scale factor.....	369

**Appendix B**

<b>Reader's comment sheet</b> .....	<b>371</b>
Reader's comment sheet.....	372



# **Chapter 1**

## **Introduction**

## Notes for the reader

### Introduction

This manual helps you to use the Océ ColorWave 300. The manual contains a description of the product and guidelines to use and operate the Océ ColorWave 300.

### Definition

#### Attention Getters







Parts of this manual require your special attention. These parts can provide the following:

- Additional general information, for example information that is useful when you perform a task.
- Information to prevent personal injuries or property damage.




### Note, Attention and Caution

The words **Note**, **Attention** and **Caution** draw your attention to important information.

Overview of the attention getters

Word	Icon	Indicates
<b>Note</b>		Tips or additional information about the correct use of the product.
<b>Attention</b>		Information to prevent property damage, for example damage to the product, documents or files.
<b>Caution</b>		Information to prevent personal injuries. The <b>Caution</b> indication has several icons that warn against various hazards. The icons are shown below.
<b>Caution</b>		General hazard
<b>Caution</b>		Hot surface
<b>Caution</b>		Electric shock

---

Word	Icon	Indicates
Caution		Moving parts
Caution		Laser beam
		The use of heat-resistant gloves is mandatory when you carry out the actions concerned.

### Safety information

The safety information for this product is included in a separate manual with the title **Safety information**. This manual is part of the documentation set that you received with your product.

## Online support for your product

### Introduction

Océ offers comprehensive support for your product on the website:

**<http://global.oce.com/>**

Here you can find the latest information that can help you to take full benefit of your product. You can also find answers to your questions.

Please visit the website regularly for updates on the following topics:

- Downloads:
- Support
- Supplies

### Downloads:

User manuals, printer drivers and other resources can change without prior notice. To stay up-to-date, you are advised to download the latest resources from:

**<http://global.oce.com/support>**

Before using your product, you must always download the latest safety information for your product. Before using your product, make sure that you read and understand all safety information in the manual entitled "**Safety Instructions**".

### Support

A Knowledge Base (OKB) with answers to your questions or problems is continuously being updated. To find an answer to your question or problem, please visit:

**<http://global.oce.com/support>** and select your product.

In the Support section, use the search field to enter your question. You will get a list of possible answers.

### Supplies

A media guide with the latest information is available on the website:

**<http://global.oce.com/supplies/>**

Here you can find the media that your product supports, for example. You can also find more information about supplies for your product, such as print heads. You can also order new supplies directly through the website.

## Addresses of local Océ organizations

For the addresses of local Océ organizations, visit:

**<http://global.oce.com/contact/countries>**

## Comments

Send your comments by e-mail to:

**[itc-userdoc@oce.com](mailto:itc-userdoc@oce.com)**

## Available documentation

### Introduction

This manual is part of a complete documentation set. The following table shows a complete overview of the available documentation.

### Available documentation Océ ColorWave 300

Documentation	Availability
User manual - Operating information	■ On <a href="http://www.oce.com">www.oce.com</a> Available as a PDF file in multiple languages.
User manual - Safety information	■ On <a href="http://www.oce.com">www.oce.com</a> Available as a PDF file.
Wide-Format Printing Systems - Connectivity Manual	■ On <a href="http://www.oce.com">www.oce.com</a> Available as a PDF file in English only.



**Note:**

Visit Océ on the internet at [www.oce.com](http://www.oce.com) for the latest information.

### Available documentation Océ Express WebTools

Documentation	Availability
User manual - Operating information	■ On <a href="http://www.oce.com">www.oce.com</a> Available as a PDF file in multiple languages.
On-line Help	■ Embedded in the application Available in multiple languages.



**Note:**

Visit Océ on the internet at [www.oce.com](http://www.oce.com) for the latest information.



## Available documentation Océ Windows® Printer Driver

Documentation	Availability
User manual	<ul style="list-style-type: none"> <li>On <a href="http://www.oce.com">www.oce.com</a> Available as a PDF file in multiple languages.</li> </ul>
On-line Help	<ul style="list-style-type: none"> <li>Embedded in the application Available in multiple languages.</li> </ul>



**Note:**

Visit Océ on the internet at [www.oce.com](http://www.oce.com) for the latest information.

## Available documentation Océ PostScript® 3 Driver

Documentation	Availability
Installation manual	<ul style="list-style-type: none"> <li>On <a href="http://www.oce.com">www.oce.com</a> Available as a PDF file in multiple languages.</li> </ul>
On-line Help	<ul style="list-style-type: none"> <li>Embedded in the application Available in multiple languages.</li> </ul>



**Note:**

Visit Océ on the internet at [www.oce.com](http://www.oce.com) for the latest information.

# How to use this manual

## Introduction

You can access a topic quickly with the following methods.

- Refer to the alphabetical index at the end of the manual.
- Refer to the table of contents at the beginning of this manual.

Before you turn to the complete table of contents, you can also use the following table to find a topic quickly.

## The sections of this manual

The following table gives an overview of how the chapters are arranged logically.

Chapter	Section	Topics
1	Introduction	<ul style="list-style-type: none"><li>■ Overview of available documentation.</li><li>■ Explanation regarding the manual and how to use it.</li><li>■ The Océ ColorWave 300 key concepts.</li><li>■ User interaction.</li></ul>
2	Get to know the Océ ColorWave 300	<ul style="list-style-type: none"><li>■ The main components.</li><li>■ Footprint.</li><li>■ The Océ ColorWave 300 hardware.</li><li>■ The consumables.</li></ul>
3	Quick start	<ul style="list-style-type: none"><li>■ Connect the mains supply cable.</li><li>■ Switch on the printing system.</li><li>■ Load the media.</li><li>■ The Océ Express WebTools.</li><li>■ The Smart Inbox.</li><li>■ Easy copying, scanning and printing</li></ul>
4	Define your workflow with the Océ Express WebTools	<ul style="list-style-type: none"><li>■ Introduction.</li><li>■ Security.</li><li>■ Configure your printing system.</li><li>■ Define your printing system preferences.</li><li>■ Manage jobs on your printing system.</li></ul>

Chapter	Section	Topics
5	Use the Océ ColorWave 300 multifunction printer	<ul style="list-style-type: none"> <li>■ Basic and extended scan jobs.</li> <li>■ Basic and extended copy jobs.</li> <li>■ Send print jobs.</li> </ul>
6	Ensure the best output quality	<ul style="list-style-type: none"> <li>■ Optimize the output quality of the scanner.</li> <li>■ Define the output quality of the printer. <ul style="list-style-type: none"> <li>- Color management.</li> <li>- Media.</li> <li>- Input profiles.</li> </ul> </li> <li>■ Check the output quality of the printer.</li> <li>■ Optimize the output quality of the printer. <ul style="list-style-type: none"> <li>- Print quality wizard.</li> </ul> </li> </ul>
7	Maintain the Océ ColorWave 300 multifunction printer	<ul style="list-style-type: none"> <li>■ Replace the media.</li> <li>■ Ink <ul style="list-style-type: none"> <li>- Replace consumables: print head, ink tank and maintenance cassette.</li> </ul> </li> <li>■ Maintain the scanner.</li> </ul>
8	System messages and solutions	<ul style="list-style-type: none"> <li>■ Remove jammed media.</li> <li>■ Clear a media jam.</li> <li>■ Clear an original jam on the scanner.</li> </ul>
9	License management	<ul style="list-style-type: none"> <li>■ Manage licenses.</li> </ul>
10	Software options	<ul style="list-style-type: none"> <li>■ Océ Repro Desk Studio.</li> <li>■ Account management.</li> </ul>
11 / B	Network and Security settings	<ul style="list-style-type: none"> <li>■ Check and adapt network settings.</li> <li>■ Check and adapt security settings.</li> </ul>
Appendix A	Specifications of the Océ ColorWave 300	<ul style="list-style-type: none"> <li>■ System specifications.</li> <li>■ Specifications drivers and job submission software.</li> <li>■ Preferred Océ media types and sizes.</li> </ul>
Appendix B	General information	Reader's comment sheet.

Chapter	Section	Topics
Appendix C	General information	Addresses of local Océ organizations.

# The Océ ColorWave 300 key concepts

## Océ ColorWave 300 system configuration

The Océ ColorWave 300 system is available in a number of configurations. The Océ ColorWave 300 multifunction printer is a printer combined with an Océ scanner Express, top delivery tray and a lower receiving tray.

The minimum configuration is a 2 roll printer only version with a lower receiving tray.

## Copy functionality

The Océ ColorWave 300 multifunction printer offers a large number of copy activities. A wide variety of original and copy related settings are supported. You can specify particular layout, media, finishing, feeding and quality enhancement options from the user panel.

## Scan functionality

The Océ ColorWave 300 multifunction printer offers a large number of scan activities. A wide variety of original and scan related settings are supported. You can specify particular layout and quality enhancement options and you can select a local or remote scan destination from the user panel.

## USB

Support of USB scanning and printing.

## Green button principle

The Océ ColorWave 300 multifunction printer is a very user-friendly system. Basic copy or scan jobs can be performed by simply pressing the start button on the user panel. Only if you want to perform more complex copy or scan jobs, you have to change the default settings with the help of the other settings on the user panel. The templates offer you extended ease of use because you can use them to store preferred combinations of settings.

## Templates

The user panel offers you a number of customizable templates for the job settings of a copy or scan job. The templates allow you to store your preferred job settings. To start

a job you simply select a template on the user panel and press the start button. Templates can be managed in the Océ Express WebTools.

### **Integrated Océ Express WebTools controller application**

The Océ Express WebTools controller application supports a centralized workflow. Only one application with a transparent and intuitive layout where you can perform many tasks based on user role defined access. The jobs tab gives you a full overview and full control on print and scan job management, but also allows you to manage 4 copy templates and 4 scan templates, stamps, system preferences and network connectivity settings.

### **Print jobs**

A print job is a job sent to the Océ ColorWave 300 printer from a user application (print job). A print job can consist of several sets, which in turn may consist of several pages. Sorting of a job can take place based on sets or on pages.

---

# User interaction

## Introduction

The user can communicate with the Océ ColorWave 300 from local locations and remote locations.

## User panel

The Océ ColorWave 300 offers a user panel that allows you to do the following.

- Maintain the system. Examples: monitor the queue, monitor the system status, print a demo print, cancel a job.
- Define the settings for copy and scan jobs.
- Define the settings for print-from-USB jobs.
- Connect the USB mass storage device for copy and print jobs.

## Integrated Océ Express WebTools controller application

The Océ Express WebTools controller application supports a centralized workflow. Only one application with a transparent and intuitive layout where you can perform many tasks based on user role defined access. Separate work spaces give you a full overview and full control on print and scan job management, but also allows you to manage your templates, system preferences and network connectivity settings. You can also monitor the status of your system in this application. You can access the integrated Océ Express WebTools controller application from any networked workstation.

## Printer drivers

With the Océ ColorWave 300 the Océ Windows® Printer Driver and the Océ PostScript® 3™ Drivers can be used. With these drivers users in remote locations can print their files directly from their applications to the Océ ColorWave 300. More information about installing, configuring and using drivers can be found in the documentation provided with the drivers. All Océ drivers can be freely downloaded from the internet at [www.oce.com](http://www.oce.com) (<http://global.oce.com/products/wfps-drivers/downloads.aspx>).

## Océ Publisher Express job submission software

Océ provides Océ Publisher Express job submission software that allows you to send print jobs to your Océ ColorWave 300.

Océ Publisher Express is a built-in job submitter in the Océ Express WebTools. You can open Océ Publisher Express in the jobs tab of the Océ Express WebTools ('Create new job').





## **Chapter 2**

# **Get to know the Océ ColorWave 300 multifunction printer**

## The main components

### Introduction

The 'Océ ColorWave 300' consists of two main components.

Component	Description / Function
The 'Océ ColorWave 300' hardware	The exact hardware components depend on the commercial version of the 'Océ ColorWave 300'. You can find more information about the hardware components in chapter 2.
The Océ Express WebTools	The Océ Express WebTools is an application that runs on the embedded 'Océ ColorWave 300' web server. The purposes of the Océ Express WebTools are the following. <ul style="list-style-type: none"><li>■ Settings and configuration management</li><li>■ Queue management</li><li>■ License management</li><li>■ System monitoring</li><li>■ Scan retrieval</li><li>■ Print job submission</li></ul>

---

# The Océ ColorWave 300 system

## Introduction

The Océ ColorWave 300 is a multifunction printer.

The Océ ColorWave 300 offers a wide range of print functionalities. The Océ ColorWave 300 uses the CMYK color model. The printer contains printheads for cyan, magenta, yellow, and black (CMYK) and is based on thermal inkjet technology.

The Océ ColorWave 300 color printing system consists of the following components:

- The Océ ColorWave 300 printer, including the Océ PowerM® controller.
- The 'Océ Scanner Express' (Optional).
- The 'Top Delivery Tray' (Optional).

The modular construction of the Océ ColorWave 300 allows you to create a customized configuration.

## The Océ ColorWave 300 main components

The following figure shows the components of the Océ ColorWave 300 multifunction printer.




[10] The Océ ColorWave 300 system

1. The Océ ColorWave 300 printer, including the Océ PowerM® controller.
2. The 'Océ Scanner Express'.
3. The 'Top Delivery Tray'.

## Working area [Footprint]

### 'Océ ColorWave 300 multifunction Express' without top delivery tray


The 'Océ ColorWave 300 multifunction Express' requires a floor space of 2242 mm x 986 mm ( 88.2 inch x 38.8 inch).



[11] Footprint Océ ColorWave 300 multifunction Express without top delivery tray

### 'Océ ColorWave 300 multifunction Express' with top delivery tray

The 'Océ ColorWave 300 multifunction Express' requires a floor space of 2242 mm x 1116 mm ( 88.2 inch x 44 inch).




[12] Footprint Océ ColorWave 300 multifunction Express with top delivery tray

# The Océ ColorWave 300 hardware and consumables

## The components of the printer (front)

### Illustration



[13] Components printer (front)

## The main components of the printer (front)

	Component	Function
1	media roll (2)	Provide the media for your printed output.
2	media roll (1)	Provide the media for your printed output.
3	lower front door	Door to access the media path.
4	upper front cover	Cover.
5	front top cover	Cover.

	Component	Function
6	rear top door	Door to access the print surface / media output section.
7	user panel	View the printer information.
8	printhead door	Door to access the printhead(s).
9	ink tank	Plastic container that contains a bag with ink.
10	on / off button	Switches the system on and off.
11 / B	lower right door	Door to access the controller (Service only).
12	media unload button	Button used to retract the media.
13	roll holder	a flange at both sides of the media roll to transport the media.
14	lower receiving tray	Receive the output.
15	foot cover	Cover of the foot.
16	wheel	Swivel wheel with brakes.

## The components of the printer (right hand side)

### Illustration



[14] Components printer (right hand side)

### The main components of the printer (right hand side)

Number	Component	Function
1	maintenance door	Door to get access to the maintenance cassette.
-	maintenance cassette	Device used for the maintenance of the printhead(s).



## The components of the printer (back)

### Illustration




[15] Components printer (back)

### The main components of the printer (back)

Number	Component	Function
1	connection panel	Panel with access to the connectors for the network / folder.
2	power switch	Switch of the mains supply.
3	wheel	Swivel wheel with brakes.
-	connector for the TDT	Electrical connector for the top delivery tray.

# The components of the scanner

## Illustration



[16] Component of the scanner

## Component - function table

	Component	Description / Function
1	original size ruler	Use this ruler to measure the original.
2	original feed rollers	A set of rollers used to transport the original.
3	scanner top cover	Top cover of the scanner.
4	scanner open levers	Lever to open the top cover of the scanner.
5	original support rollers	A set of rollers to guide the original.
6	scanner top cover rollers	A set of rollers in the top cover to guide the original.
7	original sensors	Sensors to detect the original.
8	transparent contact plates	Cover of the image sensors.
9	original feeding table	Use this table if you feed the original into the scanner.

	<b>Component</b>	<b>Description / Function</b>
-	original guide	Guides the original over the scanner to the front.

## The components of the top delivery tray (optional)

### Illustration




[17] Components Top Delivery Tray

### The main components of the printer (back)

Number	Component	Description
1	top delivery tray	Stack the prints and copies
2	door top delivery tray	Door to access the media feed to the TDT.
3	output section top delivery tray	

## The user panel

### Illustration



[18] The user panel

### Overview

Nr	Component	Description / Function
1	start button	The button on the user panel that allows the operator to start a scan job, a print job or a copy job. When active, it blinks.

Nr	Component	Description / Function
2	stop button	The button on the user panel that allows the operator to do the following: <ul style="list-style-type: none"><li>■ immediately interrupt the job (scan job, print job or a copy job).</li></ul>
3	lower left soft key	Key that allows the operator to select the option displayed in lower left corner of the screen of the user panel.
4	USB stick interface	Option to connect a USB stick device to the system.
5	user panel display	The color screen.
6	upper left soft key	Key that allows the operator to select the option displayed in upper left corner of the screen of the user panel.
7	upper right soft key	Key that allows the operator to select the option displayed in upper right corner of the screen of the user panel.
8	status light	The status light indicates the status of the printer: <ul style="list-style-type: none"><li>■ A green light indicates that the system is ready.</li><li>■ A blinking green light indicates that the system is busy.</li><li>■ A red light indicates that an error occurred.</li><li>■ A blinking red light indicates that the system is busy and an error occurred.</li></ul>
9	confirmation button	Button that allows the operator to do the following: <ul style="list-style-type: none"><li>■ Open a setting.</li><li>■ Close and confirm the selected value of a setting.</li></ul>
10	scroll wheel	Wheel on the right side of the user panel, that allows the operator to do the following: <ul style="list-style-type: none"><li>■ Scroll through settings and values.</li></ul>

---

Nr	Component	Description / Function
11 / B	numeric buttons	Buttons with the numeric values 0-9 in the lower part of the user panel, that allow the operator to enter a numeric value, for example the number of prints or copies.
	clear button(C)	With the clear button the operator can delete the last added numeric value.
12	lower right soft key	Key that allows the operator to select the option displayed in lower right corner of the screen of the user panel.

## The top delivery tray

### Introduction

The 'Top Delivery Tray' [1] is an optional for the Océ ColorWave 300 system. The 'Top Delivery Tray' can collect a maximum of 50 sheets.

### Illustration



### Capacity

The capacity of the 'Top Delivery Tray' depends on various factors like the media type, width, length and climate conditions.

The system optimizes the stack capacity automatically.

In the Océ Express WebTools you can define the default 'Top Delivery Tray capacity' for your printed output.

Under normal use this setting is set to 'Standard', the system will stop delivering sheets to the 'Top Delivery Tray' when the calculated capacity has been reached.

Based on the exact media conditions (Example: flat media versus heavy curled media), you can select either 'basic' or 'High' for less or more stack capacity (+/- 20%).



#### *Note:*

The system will indicate 'Remove media from the Top Delivery Tray' in case the calculated capacity is reached.



## Supported sizes and media to the 'Top Delivery Tray'

The 'Top Delivery Tray' can stack the following media:

- Length: 279 - 1219 millimeters (11 - 48 inches). Longer media can be transported to 'Top Delivery Tray' although this can influence the usability of the scanner.
- Width: 279 - 914 millimeters (11 - 36 inches).
- Supported media:

### Supported Paper

	'Media type' on the user interface	'Media label' on the media box
1	'Paper 70-80g'	IJM005: Océ Draft Paper 75 g/m2
		IJM012: Océ Draft Plus Paper 80 g/m2
2	'Recycled paper 70-80g'	IJM042: Océ Recycled Paper 80 g/m2
3	'Paper 90g'	IJM021: Océ Standard Paper 90 g/m2
		IJM022: Océ Standard PLUS Paper FSC 90 g/m2
4	'Paper Japan 64g'	IPS-B: Océ Plain Paper 64 g/m2
5	'Paper 56g'	IJM001: Océ Standard Paper 56 g/m2
6	'Paper 20 lb'	Ink Jet Bond: 86500 Océ Check Plot Bond 20 lb
7	'Recycled paper 20 lb'	Ink Jet Bond: 86500R Océ Recycled Bond 20 lb
8	'Paper 24 lb'	Ink Jet Bond: 86800 Océ Deluxe Bond 24 lb
9	'Custom paper'	

### Supported Coated Paper

	'Media type' on the user interface	'Media label' on the media box
10	'Coated paper 90-130g'	IJM113: Océ Premium Paper FSC 90 g/m2
		IJM119: Océ Premium Paper FSC 100 g/m2
		IJM123: Océ Premium Paper FSC 130 g/m2
		IJM131: Océ Premium Plus Paper 90 g/m2
		IJM132: Océ Premium Plus Paper 120 g/m2
11 / B	'High qual. coated paper 120-170g'	IJM149: Océ Smart Matt Paper 120 g/m2
		IJM150: Océ Smart Matt Paper 170 g/m2
		IJM151: Océ Smart Matt Paper 150 g/m2

	'Media type' on the user interface	'Media label' on the media box
12	'Coated paper 24 lb'	Ink Jet Bond: 862024 Océ Premium Color Bond 24 lb
		Ink Jet Bond: 861024 Océ Inkjet Color Bond 24 lb
13	'Coated paper Japan'	IPC-U: Océ Coated Paper 80 g/m2
14	'High qual. coated paper Japan'	IPP-J: Océ Premium Coated Paper 81 g/m2
15	'Custom coated paper'	

Supported Photopaper

	'Media type' on the user interface	'Media label' on the media box
16	'Photo gloss'	IJM222: Océ Top Photo Plus Gloss 195 g/m2
		GIPPLS7: Océ Glossy Photo paper 7.6 mil
		IPG-ZA: Océ Top Photo Plus Gloss 195 g/m2
17	'Photo gloss (instant dry)'	IJM251: Océ Photo Gloss Paper 170 g/m2
		IPG: Océ Photo Gloss Paper 170 g/m2
18	'Photo matte'	IJM229: Océ Top Photo Plus Matt Paper 195 g/m2
		PMPLUS7: Océ Matte Photo Paper 7.6 mil
19	'Photo semi-matte (instant dry)'	IJM257: Océ Semi-Matt Photo Paper 170 g/m2
20	'Photo satin'	IJM240: Océ Top Photo Plus Satin 195 g/m2
		SIPPLS7: Océ Satin Photo Paper 7.6 mil
21	'Custom photo paper'	

The system will deliver all other (than above mentioned) media to the 'Lower receiving tray'.

## How to enable and use the 'Top Delivery Tray'

Enable the 'Top Delivery Tray':

After the installation of the 'Top Delivery Tray' you must enable the 'Top Delivery Tray' in the Océ Express WebTools.

Select 'Preferences' / 'System settings' / 'Printer properties' / 'Top Delivery Tray' and set it to 'Present'.

Use the 'Top Delivery Tray' in the Océ Express WebTools:

- For a Print Job: Select 'Preferences' / 'System settings' / 'Print job defaults' / 'Sheet' / 'Sheet delivery' and set it to 'Top Delivery Tray'
- For a Copy Job: Select the required template (Example: 'Preferences' / 'System settings' / 'Copy job defaults' / 'Copy template 1: Name and description' / 'Copy template 1: Sheet' / 'Sheet delivery') and set it to 'Top Delivery Tray'.

Use the 'Top Delivery Tray' in the Océ Windows® Printer Driver:

Select the 'Finishing' option and set the Finishing Options 'Top Delivery Tray'.

Use the 'Top Delivery Tray' in the Océ PostScript® 3 Driver:

Select Advanced Options / Printer Features / Output Bin and select 'Top Delivery Tray'.

## How to define the output delivery

In the Océ Express WebTools you can define the default 'Sheet delivery' for your printed output.

- If you select 'Top Delivery Tray' and you use 'Paper', 'Coated paper' or 'Photopaper', your printed output is by default delivered in the 'Top Delivery Tray'.  
If you use a different media type, the printed output is always delivered to the 'Lower receiving tray'.
- If you select 'Lower receiving tray' your printed output is by default delivered to the 'Lower receiving tray' of the printer.

## The printing system consumables

Consumable	Consumable part	Description
media For detailed information: <i>Preferred Océ media names</i> on page 355	roll	Roll that carries the media. A roll has a 2" core.
	adapter for 3" core	Optional adapter to load a media roll with a 3" core.
	media cutter	Knife to cut the media.
Océ ColorWave 300 supplies	printhead	
	ink tank	Container that contains a bag with ink.
	maintenance cassette	Container used for the maintenance of a print head.
ink colors	cyan (C)	
	magenta (M)	
	yellow (Y)	
	black (K)	

# **Chapter 3**

## **Quick start**

## Connect the mains supply cable

---



**Caution:**

Make sure the power switch is in 'off' position.

---


1. Plug in the mains supply cable at the power connection at the back of the printer.




2. Plug the other side of the mains supply cable into the wall socket.

## Switch on the printing system

1. Switch on the power switch at the rear side of the printing system.



2. Use the on / off button at the front side of the printer to switch on the printing system.



## Replace / Install the media

### Introduction

The Océ ColorWave 300 contains two rolls of media. Appendix A (of the User Manual) contains a list of the supported media types and media sizes.

This section describes how to remove and load a roll of media.


### When to do

Change a roll when a job needs a media type or size that is not on one of the rolls.

Change the media type that is defined on the system when one roll is empty and the other available media type does not correspond.

### How to remove a roll of media

1. Press the media unload button on the right-hand side of the roll.




[23] Press the media unload button

The media automatically retracts from the printer.




2. Use both hands to remove the roll.




[24] Remove the roll

3. Both far ends of the roll contain roll holders with handles. Lift the handles to release the roll holders.



[25] Release the roll holders

4. Remove the roll holders.



[26] Remove the roll holders

### How to load a new media roll


1. Insert the roll holder in both ends of the new media roll.
2. Press the handles down to fasten the roll holders.

3. Put the green saddles into position at the ends of the track.



[27] Green saddles

4. Use both hands to place both roll holders in the green saddles on the printer.
5. Use both hands to slide the media under the paper guide. Place the media on the printer as shown in the figure below.



The media loads into the printer from the top of the media roll. Make sure the media makes contact with the transport rollers.

6. The printer automatically draws the media into the correct position.
7. Follow the steps in the wizard on the user panel:
  - Select the correct media type for the new media roll.
  - Select the clean-cut length.
    - Options:
      - No strip
      - Long strip (preferred if the new media on the core is dirty).
      - Short strip.



*Note:*

The printer automatically detects the width of the media.

---

# The Océ Express WebTools

## Introduction

The Océ Express WebTools is an application that runs embedded on the Océ ColorWave 300. You can use an Internet browser (Microsoft® Internet Explorer 7 (or higher) or Mozilla Firefox™ 2.0 (or higher) to open the home page of the Océ Express WebTools.

## Definition

You can use the Océ Express WebTools to do the following.

- Send print jobs to your Océ ColorWave 300 with Océ Publisher Express.
- Access the settings to manage the configuration and preferences of the printing system. To change settings in the Océ Express WebTools you must log in using one of three predefined user roles because the settings are all password protected. (see '[User roles and authorizations](#)' on page 102)
- Monitor the status of the printing system.
- Retrieve scan jobs
- Retrieve information on the status of consumables

## How to access the Océ Express WebTools

To access the Océ Express WebTools do the following.

- Enter the Océ ColorWave 300 Hostname (for example `http://OceColorWave300`) in the workstation web browser. The hostname is displayed on the printer user panel.  
or
- Enter the Océ ColorWave 300 IP address (for example `http://192.168.1.123`) in the web browser of the workstation.



### Note:


If the Océ Express WebTools do not appear, contact the network administrator to check the network parameters. Check if the Océ ColorWave 300 network settings have been registered in the network infrastructure.

# The Smart Inbox

## Definition

Smart Inboxes are used for customized job management. You can get an overview of the Smart Inboxes when you open the 'Jobs' tab in the Océ Express WebTools.

## Illustration



## Jobs in a Smart Inbox

You can use the Smart Inbox to manage your jobs. Define one or more Smart Inbox names that allow you to easily organize and access your jobs.

The following jobs are placed in a Smart Inbox.

- **Print jobs**, sent via printer drivers, applications or Océ Publisher Express.  
In the printer driver, application or job submitter you can select the Smart Inbox you want to print to. When you use the Océ Windows® Printer Driver you can also enable or disable 'Direct print'. When 'Direct print' is enabled your print job will be sent to the print queue immediately. When 'Direct print' is disabled your print job is kept in the Smart Inbox and you must send the print job to the print queue manually.
- **Scan jobs**, if the selected scan destination is set to 'Local to the Smart Inbox'.  
If you select a remote scan destination ('Configuration' - 'Scan destinations') it is possible that the scanned file cannot be delivered to this destination. In that case the scanned file will also be placed in the 'Scans' Smart Inbox.

- **Copy jobs**

If you want your copy jobs to appear in a Smart Inbox, you must enable the 'Preferences' - 'System settings' - 'Smart Inbox management' - 'Display a Smart Inbox with all jobs' setting. Your copy job is then displayed in the 'View all' Smart Inbox. The 'Preferences' - 'System settings' - 'Smart Inbox management' - 'Save printed jobs in a Smart Inbox' - setting determines if copy jobs that have been printed will be kept in the Smart Inbox for reprint or not.

# Easy printing, copying and scanning


## Print a file from a USB mass storage device or flash drive

1. Insert USB mass storage device in the USB stick interface on the user panel.
2. The system automatically selects the print tab.



**Note:**

When the first template in the Scan tab is a Scan to USB template, the system selects the Scan tab.



3. Open the print tab with the confirmation button above the scroll wheel. The content of your USB mass storage device is displayed.
4. Use the scroll wheel to browse to the file you want to print. You can select or deselect the desired file with the confirmation button.  
You can also select multiple files:
  - Press 'Select more...'. Use the scroll wheel to browse to the desired files with scroll wheel. You can select or deselect the files with the confirmation button.
  - Press 'Select all' when you want to print all the files from a folder.



**Note:**

You can only select multiple files from one folder.

5. If necessary, you can edit the settings of your job with the lower right softkey.



**Note:**

In case multiple files are selected the setting is the same for all files.

6. Use the start button to start printing.




## Use Océ Publisher Express to send a print job

### Introduction



Océ Publisher Express is a job submitter that is integrated in the Océ Express WebTools.

### Illustration



### How to use Océ Publisher Express to send a print job

Step	Action	Remarks
1	Open your web browser.	Use one of the following web browsers <ul style="list-style-type: none"> <li>■ Microsoft® Internet Explorer 7 (or higher)</li> <li>■ Mozilla Firefox™ 2.0 (or higher)</li> </ul>
2	Enter the URL <b>http://'printer name'</b> or IP address in your workstation browser to connect to the Océ Express WebTools.	'Printer name' is the name of your Océ ColorWave 300 printer.

Step	Action	Remarks
3	Open the 'Jobs' tab,	This tab displays the following. <ul style="list-style-type: none"> <li>■ The Océ Publisher Express section.</li> <li>■ An overview of all jobs that are currently available in the 'Jobs - Queue'.</li> <li>■ An overview of all the Smart Inboxes that currently contain on or more jobs.</li> </ul>
4	Click on 'Create new job' in the Océ Publisher Express section.	A separate window opens.
5	Click on 'Add file' and use the <b>Browse...</b> button to select the file you want to print. <p> <b>Note:</b> If the Top Delivery Tray is used and you add multiple files in one job: Add the files in reverse order (e.g. file3, file2, file1 instead of file1, file 2 and file 3). This to prevent you from having to re-order the printed files.</p> <p> <b>Note:</b> In case the file is generated with the Océ Windows® Printer Driver these settings prefer over the Océ Publisher Express job settings.</p>	You can print documents with the following data formats <ul style="list-style-type: none"> <li>■ - HP-GL - .hp, .hpg, .hpgl</li> <li>■ - HP-GL/2 - .hp2</li> <li>■ - HP RTL - .rtl</li> <li>■ - CALS - .cls, .cal</li> <li>■ - NIRS - .nir, .nif</li> <li>■ - CalComp - .cc, .906, .907, .951, .crf, .pci</li> <li>■ - Edmics (C4) - .c4</li> <li>■ - TIFF - .tif</li> <li>■ - PostScript 3 - .ps (optional)</li> <li>■ - PDF - .pdf (optional)</li> <li>■ - JPEG - .jpg, .jpeg</li> <li>■ - DWF, DWF/X</li> </ul>
6	Change the 'Settings' and the 'Preset' if necessary.	Job settings that you change in Océ Publisher Express always overrule the default settings defined in the Océ Express WebTools.

Step	Action	Remarks
7	In the 'Workflow' section enter the name of the Smart Inbox you want to print to and click 'Ok' to send the print job to the Smart Inbox.	You can easily create a new Smart Inbox if you enter a new Smart Inbox name.

## Print a job from the Smart Inbox

### How to print a job from the Smart Inbox using the Océ Express WebTools

1. Select the 'Jobs' tab in the Océ Express WebTools.
2. Select the correct Smart inbox.
3. Select the job and click 'Print'. The job is copied to the Jobs Queue.

## Use the Océ Windows® Printer Driver to send a print job

### Introduction

Océ provides the Océ Windows® Printer Driver that allows you to send print jobs to your Océ ColorWave 300. This driver is a mixed raster-vector HP-GL/2 printer driver that allows you to print from any application under Windows XP®, Windows Vista® or Windows Server® 2003 to your Océ printer.



**Note:**

More information about how to install, configure and use the driver is available in the documentation provided with the Océ Windows® Printer Driver.


- the Océ Windows® Printer Driver Online Help
- the Océ Windows® Printer Driver User manual



**Note:**

The Océ ColorWave 300 is delivered with a driver pack CD-ROM. You can also download the latest Océ drivers, free of charge, from our Web site [www.oce.com](http://www.oce.com).

### Illustration



### How to use the Océ Windows® Printer Driver to send a print job

Step	Action	Remarks
1	Open the file that you want to print in the source application.	AutoCAD® 2000 or any other Windows application
2	From the 'File' menu of the application, click 'Print'.	
3	Select the Océ ColorWave 300 in the 'Printer' area of the 'Print' dialog box.	
4	Click 'Properties'.	
5	Check all tabs in the driver and change the settings for this job if necessary.	
6	Click 'OK' to send the print job to the print queue.	

# Use the Océ PostScript® 3 Driver to send a print job

## Introduction

Océ provides the Océ PostScript® 3 Driver that allows you to send print jobs to your Océ ColorWave 300.



**Note:**

You need a license to be able to print PostScript® files on the Océ ColorWave 300.




**Note:**

More information about how to install, configure and use the driver is available in the documentation provided with the Océ PostScript® 3 Driver.

- the Océ PostScript® 3 Driver Online Help
- the Océ PostScript® 3 Driver Installation manual

## Illustration



## How to use the Océ PostScript® 3 Driver to send a print job

Step	Action	Remarks
1	Open the file that you want to print in the source application.	

Step	Action	Remarks
2	From the 'File' menu of the application, click 'Print'.	
3	Select the Océ ColorWave 300 in the 'Printer' area of the 'Print' dialog box.	
4	Click 'Properties'.	You can define the default print job settings in the Océ Express WebTools.
5	Activate the Océ Job Ticket to overrule the default values for the job settings.	
6	Check and change the Printer Features settings if necessary.	
7	Click 'OK' to send the print job to the print queue.	



## Make a fast copy of a CAD drawing

1. Feed the original face up and centered on the original feeding table.



**Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.



The 'Copy' tab is automatically activated on the user panel.



2. Open the 'Copy' tab with the confirmation button above the scroll wheel.
3. Use the scroll wheel to select copy template 2 ('Fast CAD color copy').



*Note:*

The description of the second default copy template is displayed ('Fast CAD color copy'). With a copy template you can pre-define the settings you need for a copy job. You only need to set the job settings once and you can store the settings in a job template that is presented on the user panel. You can re-use the job template for each next job without the need to redefine all the settings every time. (see *'Define the copy job preferences and copy templates'* on page 133).

4. Press the start button.  
After the scan procedure, the scanner always releases the original.

## Make a normal color copy

1. Feed the original face up and centered on the original feeding table.




**Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.



The 'Copy' tab is automatically activated on the user panel.



2. Open the 'Copy' tab with the confirmation button above the scroll wheel.
3. Use the scroll wheel to select copy template 1 ('Normal color copy').



*Note:*

With a copy template you can pre-define the settings you need for a copy job. You only need to set the job settings once and you can store the settings in a job template that is presented on the user panel. You can re-use the job template for each next job without the need to redefine all the settings every time. (see *Define the copy job preferences and copy templates* on page 133).

4. Press the start button.  
After the scan procedure the scanner releases the original.

## Make a fast b/w copy of a CAD drawing

1. Feed the original face up and centered on the original feeding table.




**Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.



The 'Copy' tab is automatically activated on the user panel.



2. Open the 'Copy' tab with the confirmation button above the scroll wheel.
3. Use the scroll wheel to select copy template 3 ('Fast CAD b/w copy').



*Note:*

With a copy template you can pre-define the settings you need for a copy job. You only need to set the job settings once and you can store the settings in a job template that is presented on the user panel. You can re-use the job template for each next job without the need to redefine all the settings every time. (see *Define the copy job preferences and copy templates* on page 133).

4. Press the start button.  
After the scan procedure the scanner releases the original.

## Scan a color CAD drawing to PDF format

1. Feed the original face up and centered on the original feeding table.




**Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.



2. Select 'Scan' on the user panel.



3. Open the 'Scan' tab with the confirmation button above the scroll wheel.
4. Use the scroll wheel to select scan template 1 ("CAD to color PDF").



*Note:*

The description of the first default scan template is displayed ('CAD to color PDF'). With a scan template you can predefine the settings you need for a scan job. You only need to set the job settings once and you can store the settings in a job template that is presented on the user panel. You can re-use the job template for each next job without the need to redefine all the settings every time. (see *'Define the scan job preferences and scan templates'* on page 139).

5. Press the start button.

## Result

The scanned PDF file is placed in the Smart Inbox 'Scans'. You can access this Smart Inbox via the 'Jobs' tab in the Océ Express WebTools.



## Scan a CAD drawing to b/w TIFF format

1. Feed the original face up and centered on the original feeding table.




**Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.



2. Select 'Scan' on the user panel.



3. Open the 'Scan' tab with the confirmation button above the scroll wheel.
4. Use the scroll wheel to select scan template 2 ('CAD to b/w TIFF').



**Note:**

With a scan template you can pre-define the settings you need for a scan job. You only need to set the job settings once and you can store the settings in a job template that is presented on the user panel. You can re-use the job template for each next job without the need to redefine all the settings every time. (see *Define the scan job preferences and scan templates* on page 139).

5. Press the start button.  
After the scan procedure the scanner releases the original.

## Result

The scanned TIFF file is placed in the Smart Inbox 'Scans'. You can access this Smart Inbox via the 'Jobs' tab in the Océ Express WebTools.

## Scan to a USB mass storage device

1. Feed the original face up and centered on the original feeding table.




**Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.



2. Select 'Scan' on the user panel.



3. Open the 'Scan' tab with the confirmation button above the scroll wheel.
4. Use the scroll wheel to select scan template 3 ('Scan to USB').



*Note:*

With a scan template you can pre-define the settings you need for a scan job. You only need to set the job settings once and you can store the settings in a job template that is presented on the user panel. You can re-use the job template for each next job without the need to redefine all the settings every time. (see *'Define the scan job preferences and scan templates'* on page 139).

5. 'Insert USB device'.
6. Press the start button.

## Result

The system creates a sub-directory "scans\_x" on the USB mass storage device and stores the scanned file in this sub-directory in JPEG format.

---

## Switch off the printing system


1. Use the on / off button at the front side of the printer to switch off the printing system.



**Note:**  
Wait until the user panel is black.



**Note:**  
You can also use the 'Shut down' button in the Océ Express WebTools.





# **Chapter 4**

## **Define your workflow with the Océ Express WebTools**

# Introduction

## The Océ Express WebTools

### Introduction

The Océ Express WebTools is an application that runs embedded on the Océ ColorWave 300. You can use an Internet browser (Microsoft® Internet Explorer 7 (or higher) or Mozilla Firefox™ 2.0 (or higher) to open the home page of the Océ Express WebTools.

### Definition

You can use the Océ Express WebTools to do the following.

- Send print jobs to your Océ ColorWave 300 with Océ Publisher Express.
- Access the settings to manage the configuration and preferences of the printing system. To change settings in the Océ Express WebTools you must log in using one of three predefined user roles because the settings are all password protected. (see *'User roles and authorizations'* on page 102)
- Monitor the status of the printing system.
- Retrieve scan jobs
- Retrieved information on the status of consumables

### How to access the Océ Express WebTools

To access the Océ Express WebTools do the following.

- Enter the Océ ColorWave 300 Hostname (for example http://OceColorWave300) in the workstation web browser. The hostname is displayed on the printer user panel.  
or
- Enter the Océ ColorWave 300 IP address (for example http://192.168.1.123) in the web browser of the workstation.



**Note:**

If the Océ Express WebTools do not appear, contact the network administrator to check the network parameters. Check if the Océ ColorWave 300 network settings have been registered in the network infrastructure.



## The system requirements

### Introduction

You can use an Internet browser to open the home page of the Océ Express WebTools. Depending on the Internet browser you use, you must set the required minimum browser security settings as indicated below.



**Note:**

The minimum system requirements are a 3 GHz Pentium 4 with 1 Gbyte RAM and Windows XP.

### Set the minimum browser security settings for Internet Explorer 7 / 8 / 9



**Caution:**

You must enable cookies.

Step	Action	Value
1	Select Tools / Internet Options / Security / Local intranet / Custom Level	
2	<b>ActiveX controls and plug-ins</b>	
	Binary and script behaviors	Enable
3	<b>Downloads:</b>	
	File download	Enable
4	<b>Miscellaneous</b>	
	Allow META REFRESH	Enable
	Launching applications and unsafe files	Enable
	Use Pop-up blocker	Disable
5	<b>Scripting</b>	
	Active scripting	Enable

### Set the minimum browser security settings for Firefox 2 / 3


Step	Action	Value
1	Select Tools / Options	
2	<b>Main</b>	
	Show the downloads window when downloading a file	Recommended
3	<b>Content:</b>	
	Load images automatically	Enable
	Enable Javascript	Enable
4	<b>Privacy</b>	
	Accept cookies from sites	Enable

### Set the minimum browser security settings for Firefox 4

Step	Action	Value
1	Select Options / Options	
2	<b>General</b>	
	Show the downloads window when downloading a file	Recommended
3	<b>Content:</b>	
	Load images automatically	Enable
	Enable Javascript	Enable

## The 'Jobs' tab

### Illustration



### The 'Jobs' tab



#### Note:

Editable for any user. For some specific actions you must log on as a Key operator. (see [‘User roles and authorizations’ on page 102](#))

#### Your remote control of the system's workflow.

##### Tasks:

Create a new job from a printable file in the Océ Publisher Express section.

- To submit a new job click 'Create new job'. A new window opens, where you can define some basic job settings and where you can browse to the file you want to print. (see [‘Use Océ Publisher Express to send a print job’ on page 211](#))

Monitor jobs in the 'Jobs - Queue' section.


- This section gives an overview of the jobs in the queue, waiting to be printed. The buttons on top of the 'Jobs - Queue' section allow you to move a selected job to the top of the queue or to delete the job. If you click 'Delete all' all jobs are deleted from the queue. (see [‘The Smart Inbox and Jobs Queue concept’ on page 145](#))

Control your jobs in the 'Smart Inbox' section (group jobs, make settings, start jobs/sets). This section enables you to do the following.

- When you click 'Open Smart Inbox' and enter a name, the new Smart Inbox immediately appears in the Smart Inbox overview (see *'Open or create a Smart Inbox' on page 150*).
- Get an overview of all the Smart Inboxes that you created on your system. When you select a print job in the Smart Inbox you can use the buttons on top of the Smart Inbox section to print, edit or delete the job. You can also *'Delete a Smart Inbox' on page 151*.
- Get an overview of all scan jobs. All scan jobs are placed in the Smart Inbox 'Scans'. When you select a scan job you can use the buttons on top of the Smart Inbox 'Scans' section to print, save or delete the scan job.
- Get an overview of all jobs on the system. Only when you enable the 'Preferences' - 'System settings' - 'Smart Inbox management' - 'Display a Smart Inbox with all jobs' setting, the Smart Inbox 'View all' displays all the jobs. When you select a job you can use the buttons on top of the Smart Inbox 'View all' section to print, edit or delete the job. If you click 'Delete all', all jobs are deleted from the system.

## The 'Preferences' tab

### Illustration



## The 'Preferences' tab



### Note:

Before you can edit a setting or a settings group, you must log on as a Key operator or a Power user. (see *'User roles and authorizations'* on page 102)

**Fine tune the system to fit your company's workflow and processes.**


### Tasks:

- 'Overview'  
Summary of the settings organised in different groups.
- 'System settings'
- 'Print job defaults'
- 'Copy job defaults'
- 'Scan job defaults'

(see also *'What you need to know about default settings'* on page 123)

# The 'Configuration' tab

## Illustration



## The 'Configuration' tab



**Note:**

Before you can edit a setting or a settings group, you must log on as a System administrator or a Power user. (see *'User roles and authorizations'* on page 102)


**Install the system in your infrastructure, according your standards.**

Tasks:

- 'Overview'  
Summary of the settings organised in different groups.
- 'Connectivity'  
(see *'Configure the network settings in the Océ Express WebTools'* on page 114)
- 'Scan destinations'  
(see *'Configure scan destinations'* on page 115)
- 'Pens'

## The 'Support' tab

### Illustration



### The 'Support' tab



#### Note:

Before you can access licenses you must log on as a System administrator or a Power user. (see *'User roles and authorizations'* on page 102)

#### Tasks that require contact with Océ.

##### Tasks:


- 'About'
  - Information about the Océ ColorWave 300 system software version.
  - Information about the included licenses. These are the licenses used to build the software.
- 'Media'
  - 'What is a media profile?'* on page 248
  - 'Manage media'* on page 249
  - 'Download and install a media profile'* on page 251

- 'Input Profiles'
  - 'What is an input profile?'* on page 253
  - 'Manage input profiles'* on page 254
  
- 'Licenses'
  - 'Check your licenses'* on page 326
  - 'Save the currently active licenses'* on page 328
  - 'Install a new license'* on page 329



## The 'System' tab

### Illustration



### The 'System' tab

#### **Your remote view on the system.**

This tab can be accessed by any user.

The 'System' tab is visible on all pages at the bottom of the page. When you click on the 'System' tab in the lower left corner of the screen, the system monitor pops-up.

#### Monitoring:

- The ink status.
- The available media on the printer.
- The system status (for example 'Printer paused', 'Ready to print', 'Sleeping...').
- The active job.

## Set another language for the Océ Express WebTools

### Introduction

The language setting of the Internet browser you use defines the language in which the user interface of the Océ Express WebTools is displayed.



**Note:**

This language setting does not influence the language on the user panel. On the user panel you can only toggle between the 'First language' and the 'Second language'. You can define the values for the 'First language' and the 'Second language' in the regional settings of the Océ Express WebTools (see '[Change the regional settings](#)' on page 112).



**Note:**

If the selected language cannot be supported, the standard user interface language for the Océ Express WebTools will be US English.

### Purpose

Change the language setting of the user interface of the Océ Express WebTools.

### How to change the language setting in Microsoft® Internet Explorer

1. Open Microsoft® Internet Explorer.
2. Select Tools menu - Internet options. The internet options window appears.
3. Make sure the General tab is selected.
4. Click the Languages button in the lower part of the window. Another window opens.
5. Select the language of your choice. A new language can be added to the list with the Add button.
6. Move the newly added language up in the list to the top position.
7. Click OK to confirm or Cancel to close both windows again.
8. Click Refresh in the toolbar or open another page. The language of the application will be changed.



**Note:**

It is possible that the internet options are put under a different menu, depending on the Microsoft® Internet Explorer version you use.


## How to change the language setting in Mozilla Firefox™

1. Open Mozilla Firefox™.
2. Select the Extra menu - Options. The Options window appears.
3. Click the Advanced button and make sure you have selected the General tab.
4. In the Languages section click the Choose... button. Another window opens.
5. Select the language of your choice. A new language can be added to the list with the Add button.
6. Move the newly added language up in the list to the top position.
7. Click OK to confirm or Cancel to close both windows again.
8. Click Reload in the toolbar or open another page. The language of the application will be changed.

## How to edit a setting

1. Browse to the settings group you want to edit, for example 'Preferences' - 'System settings' - 'Print queue management'.

You can find detailed information about the settings in the tooltip. The illustration below shows, for example, the tooltip information of the 'Print queue' setting.




2. You can click directly on the value of a setting if you want to edit a single setting.



### Note:

Before you can edit a setting or a settings group, you must log on as an authorized user.

For example, if you click on the value of the 'Print queue' setting a separate window opens, where the same information is displayed as in the tooltip and where you can edit the setting.



or

You can click 'Edit' in the settings group bar to access a window for all settings in the group if you want to edit more settings in the settings group.




**Note:**

Before you can edit a setting or a settings group, you must log on as an authorized user.

For example if you click 'Edit' in the 'Print queue management' settings group bar, a separate window opens, where all the settings of the settings group are listed, and where

you can edit all these settings. This overview window does not show detailed information per setting.



3. Modify the setting or settings.
4. Click 'Ok' to confirm your entries or 'Cancel' to reject your entries.

---

## View and check the settings

### Purpose

View and check the settings and the values that are stored when you save the settings file.

### When to do

- Before you save the setting and the values in the Océ Express WebTools.
- To check which settings are no longer set to the factory default value.



*Note:*

Not all settings are stored in the settings file. The network settings and the passwords for authorized users are excluded from the file for security reasons. License information is not included in the file either.

### How to view and check the settings

1. Click the 'Configuration' tab or the 'Preferences' tab.
2. Click 'View set' in the **top-right hand corner** of the screen. A new window opens.
3. Scroll through the list of settings. The first column displays the setting and the second column displays the values. A "\*" indicates that the value of the setting is different than the original factory default value.



*Note:*

You can print the information with the standard print function of your browser.

## Save the settings in a file

### Purpose

Save the settings and the values that you configured in the Océ Express WebTools in a file.

### When to do

- Duplicate the settings very easily to another printer of the same type.



*Note:*

Not all settings are stored in the settings file. The network settings are excluded from the file because the network settings cannot be duplicated to another printer. The passwords for authorized users and the passwords for remote scan destinations are excluded from the file for security reasons. License information is not included in the file either.

### How to save the settings in a file

1. Click the 'Configuration' tab or the 'Preferences' tab.
2. Click 'Save set' in the **top-right hand corner** of the screen. A new window opens.
3. Navigate to a location where you want to store the file.
4. Save the settings<hostname of printer><date>.xml file. The file name is not fixed. You can change the name if required.
5. Click 'Ok' to confirm or 'Cancel' to close the window without storing the settings file.

---

■ [Save the currently active licenses, on page 328](#)



---

## Load the settings from a file

### Purpose

Load the settings and the values for the Océ Express WebTools from a file.

### When to do

- Duplicate the settings to another printer of the same type.



#### **Caution:**

When you are logged in as a Key operator you can only load the Key operator settings. When you are logged in as a System administrator you can only load the System administrator settings. To load all the settings that are stored in the file you must log in as a Power user.



#### **Note:**

Not all settings are stored in the settings file. The network settings are excluded from the file because the network settings cannot be duplicated to another printer. The passwords for authorized users and the passwords for remote scan destinations are excluded from the file for security reasons. License information is not included in the file either.

### How to load the settings from a file

1. Click the 'Configuration' tab or the 'Preferences' tab.
2. Click 'Open set' in the **top-right hand corner** of the screen. A secondary window is opened.
3. Navigate to the location of the settings file and select the file.
4. Click 'Ok' to load the settings file or 'Cancel' to close the window without loading the settings file.

### Result

The values of the settings in the settings file overwrite the current values. The network configuration settings of the system and the passwords are not restored to prevent connectivity problems and to guarantee the integrity of the passwords.

## Restore the factory defaults

### When to do

- When you want to restore the factory default settings and values of your Océ Express WebTools.



#### **Caution:**

When you are logged in as a Key operator you can only restore the Key operator settings. When you are logged in as a System administrator you can only restore the System administrator settings. To restore all the factory default settings you must log in as a Power user.

---

### How to restore the factory defaults

1. Click the 'Configuration' tab or the 'Preferences' tab.
2. Click 'Restore defaults' in the **top-right hand corner** of the screen. A secondary window is opened.
3. Click 'Ok' to restore the factory default settings or 'Cancel' to close the window without restoring the factory defaults.












## The system monitor

### Introduction




You can open the system monitor to get an overview of the current status of the printing system. When you click on the 'System' tab in the lower left corner of the screen, the system monitor pops-up.

The system state (for example: 'Printing:') is displayed in the upper right corner of the system monitor section of the Océ Express WebTools.

### Overview of the system states

State	Icon	Description
'User intervention required'		General error message.
'System memory is full'		Status message when printer does not print because the system memory is full.
'Sleeping...'		Energy saving state: State when not all functionality is available due to printer sleeping.
'Warming up...'		State when not all functionality is available due to printer warming up.
'Initializing...'		State when the system software is initializing.
'Printer paused'		The system pauses the print queue but keeps access to all other functionality.
'Processing...'		The system is receiving or processing data.
'Ready to print'		State when there is no active job and no waiting job. When a job arrives, no user intervention is needed to start printing.
'Printing:' <job-name>		State when a print job is active.
'Processing:' <job-name>		The system is processing the job data.
'Receiving:' <job-name>		The system is receiving the job data.

### Overview of the scanner states

State	Icon	Description
'User intervention required'		General error message.
'Scanner is busy'		
'Scanner is ready'		

## Shut down or restart the system

To remotely shut down the printing system you can click 'Shut down' in the 'Support' tab.

You can also use this button to restart the system.

# Security

## Access and passwords

### User roles and authorizations

#### Introduction

The settings in the Océ Express WebTools can be configured and managed to enable the optimal performance of the Océ ColorWave 300.

You can view all the settings in the Océ Express WebTools but when you want to edit a setting, a message appears. This message indicates that the setting is password protected. You must log in, before you have the rights and authorizations to change a setting. Logging in requires a password.

#### Overview of user roles and authorizations

The table below displays the different user roles and the authorizations that belong to the role.

User role	Description
'Key operator'	Besides the normal use of the system, the Key operator takes care of the system's daily maintenance and is authorized to change all default settings in the 'Preferences' tab of the Océ Express WebTools.
'System administrator'	The System administrator takes care of the integration of the system into the IT-infrastructure of the customer. The System administrator is authorized to change all settings in the 'Configuration' tab of the Océ Express WebTools.
'Power user'	The Power user is authorized to access all functionalities of the Océ Express WebTools. It combines the 'Key operator' and 'System administrator' roles.



**Note:**

You do not need a password for the normal use of the system.

---

## Log in as an authorized user

### Purpose

In order to have write access for certain groups of settings, you must log in as an authorized user. There are 3 user roles, System administrator, Key operator and Power user who have authorization to edit specific groups of settings. You do not need to log in before you start a session. The system will only display a message when you need to log in to perform an action.

### Before you begin

Navigate through the tabs and select the value of a setting you wish to change.

### How to log in as an authorized user

1. After you click the value of the setting you want to edit, a log in window appears.
2. You can select a user role from the drop down list.



**Note:**

The user role with the required authorization is already selected.

3. Enter the password.



**Note:**

If the password is entered incorrectly, a message appears. You can enter the password again.

4. Click 'Ok' to confirm your entry.



**Note:**

Once you have logged in, the log in lasts for the duration of the browser session. If you have not been active for more than 30 minutes, the session expires and you need to login again.



**Note:**

For security reasons it may be useful to periodically change the password for the 3 access modes (Key operator, System administrator, Power user) to the Océ Express WebTools.

## Log out after your session

### Purpose

When you have finished the modification of a setting, it is advised to log out again.

### How to log out after you have finished your session

1. Click the log out hyperlink in the **top right-hand corner** of the screen.  
or
2. Close the screen of your Internet browser.



## Change the password for authorized users

### When to do

For security reasons it is advised to periodically change the password for the 3 access modes (Key operator, System administrator, Power user) to the Océ Express WebTools.

### How to change the password for authorized users

1. Click 'Configuration' - 'Connectivity' - 'Passwords'.
2. Expand the 'Passwords' section.
3. Depending on the password you want to change, select 'Key operator password', 'System administrator password' or 'Power user password'. A secondary window appears.
4. Log in as Key operator to change the key operator password. The default key operator password is KeyOp.  
Log in as System administrator to change the system administrator password. The default system administrator password is SysAdm.  
Log in as Power user to change all the passwords. The default power user password is PowUsr.



**Note:**

The passwords are case sensitive. You can only use characters from the following range:

A-Z

a-z

0-9

\_ - ~ ! ? @ # \$ % ^ \* + = , . : ; / | [ ] ( ) { }

You cannot use Chinese, Cyrillic or Japanese characters.

5. Enter the new password twice to confirm your input. The password is hidden.
6. Click 'Ok' to confirm your entries or 'Cancel' to reject your entries.

# Secure protocols

## Enable IPSec


### Introduction

IPsec is a security protocol that you can use:

- to limit the access to your network to a maximum of 5 hosts.
- to encrypt the data between these hosts and the system.

You can enable IPSec in the Océ Express WebTools. For more information on IPSec, consult the Security manual.

### Enable IPSec

1. Go to 'Configuration' - 'Connectivity' - 'IPsec'.
2. Click .
3. Click 'Enabled'.

# Enable IPv6

## Introduction

IPv6 is a internet protocol that you can use.

You can enable IPv6 in the Océ Express WebTools. For more information on IPv6, consult the Connectivity manual.

## Enable IPsec

1. Go to 'Configuration' - 'Connectivity' 'TCP/IP: IPv6'.
2. Click .
3. Click 'Enabled'.

## IPv6 settings

### Introduction

In case IPv6 is enabled, the user can change some of the IPv6 settings.

### IPv6 settings

The following settings for IPv6 are available:

- 'IPv6 Link Local address'. This address is determined automatically. The user cannot change this address.
- 'IPv6 Stateless (SLAAC) address'. This address is determined automatically. The user cannot change this address.
- 'IPv6 manual address'. The IPv6 address when set manually. Enter the value '::' or '12:00 AM:12:00 AM:12:00 AM:12:00 AM' to disable a manual IPv6 address.
- 'IPv6 manual gateway address'. The IPv6 manual gateway address when set manually. Enter the value '::' or '12:00 AM:12:00 AM:12:00 AM:12:00 AM' to disable a manual gateway


# E-shredding

## Enable or disable the E-shredding function

### Introduction

The E-shredding function allows you to securely erase jobs from the system. This prevents unauthorized people from recovering the deleted jobs. When the E-shredding function is enabled, you can select an E-shredding algorithm. You can enable the E-shredding function in the Océ Express WebTools. By factory default, the E-shredding function is disabled.

### How to enable the e-shredding function

1. Go to 'Configuration' - 'Connectivity' - 'E-shredding'.
2. Click .
3. Click the radio button for 'Enabled' or 'Disabled'.



**Note:**

When E-shredding is enabled, the system may require more time to process print, scan and copy jobs.

## Select the E-shredding algorithm

### Introduction


The E-shredding function allows you to securely erase jobs from the system. This prevents unauthorized people from accessing the deleted jobs.

You can select one of the following algorithms.

- 'Gutmann'.  
All jobs on the system are erased in 35 overwrite passes.
- 'DoD 5220.22-M'.  
All jobs on the system are erased in 3 overwrite passes.
- 'Custom' allows you to define the number of passes manually.

The factory default is 'DoD 5220.22-M'.

### How to select the E-shredding method

1. Go to 'Configuration' - 'Connectivity' - 'E-shredding' - 'E-shredding algorithm'.
2. Click .
3. From the list, select the required method.

## Specify the number of overwrite passes


### Introduction

The E-shredding function allows you to erase jobs from the system. This prevents unauthorized people from accessing the jobs. You can manually enter the required number of overwrite passes. Therefore, the setting 'E-shredding algorithm' must be set to 'Custom'. The more passes you define, the more reliable the erasing of jobs is. However, more passes take more time. You can enter any number from 1 to 35. The factory default is 3.

### Before you begin

Make sure that 'Custom' is selected as the e-shredding algorithm.

### How to specify the number of overwrite passes

1. Go to 'Configuration' - 'Connectivity' - 'E-shredding' - 'E-shredding custom number of passes'.
2. Click .
3. Enter the required number of overwrite passes.

# Configure your printing system

## Change the regional settings



*Note:*

Before you can edit a setting or a settings group, you must log on as System administrator or Power user.

The regional settings are configured during the installation of your system. If you want to change the initial configuration, you can do so in the 'Preferences' - 'System settings' - 'Regional settings'.

Define the following settings.

- 'First language' and 'Second language' of the user panel.  
You can toggle between these two languages on the user panel.
- 'Measurement unit'  
Every time you change the 'Measurement unit', the controller recalculates the values from millimeter to inches and vice versa.
- 'Media series'
- 'Date format'
- 'Time format'



---

# Configure the sleep mode timer

## Introduction

If the printer is idle for a defined period it goes into sleep mode. In sleep mode the printer uses minimal energy, because the power supply of the printer is turned off. The power supply of the embedded controller remains on.

The printer enters the sleep mode when the sleep mode timer expires.

You cannot disable the sleep mode, but you can adjust the value of the sleep mode timer (default value is 30 minutes).



**Note:**

The printer needs to start-up when it wakes up from the sleep mode.

## How to configure the time-out value of the sleep mode timer

1. Click 'Preferences' - 'System settings'.
2. Click 'Edit' in the 'Printer properties' bar or click the value of the 'Sleep mode time-out' setting.
3. Enter a new value in the Edit window and click 'Ok' to confirm your entries or 'Cancel' to reject your entries.



**Note:**

If you access the Edit window by clicking the value of the setting you want to change, the Edit window displays the minimal and maximal value you can select.



**Note:**

When the printer is in sleep mode, there are several ways to activate the system.

- send a print job.
- insert a USB mass storage device
- press a button on the user panel.

## Configure the network settings in the Océ Express WebTools

### Introduction

Some of the network settings are configured during the installation of your system. If you want to change the initial configuration or if you want to define more network settings, you can do so in the 'Configuration' - tab.



**Note:**

Before you can edit a setting or a settings group, you must log on as System administrator or Power user.

### How to configure the network settings in the Océ Express WebTools

1. Click 'Configuration' - 'Connectivity'.
2. Click 'Edit' in the settings group bar to access the 'TCP/IP: IPv4' window. You can edit all the settings of the settings group in one window.  
or
3. To edit only one setting, click a single setting value in the expanded list.  
For example, click on the value of the 'Enable DHCP' setting to display a window where you can change the value.



**Note:**

This window also contains a short explanation of the setting.

4. Click 'Ok' to confirm your entries or 'Cancel' to reject your entries.
5. Restart the system to use the new network settings.


# Configure and manage scan destinations

## Configure scan destinations

### Introduction

When you select the 'Scan' tab on the user panel a list of scan destinations is displayed. A scan destination is a place where you send your scanned file to for storage. You can define a maximum number of 10 scan destinations in the 'Configuration' - 'Scan destinations' tab.

### Illustration



### Types of scan destinations

You can scan to file to two different types of destination.

Type	Description
Local	<ul style="list-style-type: none"><li>■ <b>'Local to the Smart Inbox'</b> When you select this scan destination your scanned file is sent to the 'Scans' Inbox. This is the fixed scan destination for scan destination 1.</li><li>■ <b>'Local to USB storage device'</b> When you select this scan destination your scanned file is sent to the USB Mass storage device connected to the USB stick interface on the user panel. This is the fixed scan destination for scan destination 2.</li></ul> <p>(see <i>'Configure a local scan destination'</i> on page 117)</p>
Remote	<p>A scan destination can also be a file server or a PC of an end user.</p> <ul style="list-style-type: none"><li>■ <b>'Remote via FTP'</b> When you select this scan destination your scanned file is sent via FTP to a shared folder on a remote workstation.</li><li>■ <b>'Remote via SMB'</b> When you select this scan destination your scanned file is sent via SMB to a shared folder on a remote workstation.</li></ul> <p>(see <i>'Configure a remote scan destination'</i> on page 118)</p>

---

## Configure a local scan destination

**Note:**

Before you can edit a setting or a settings group, you must log on as System administrator or Power user.

1. Click 'Configuration' - 'Scan destinations'.
2. Click 'Edit' in a 'Scan destinations' bar.
3. Enter a name for the destination.  
This name will appear on the user panel.
4. Place a check mark in the enabled box.
5. You can select 2 different local scan destination types.
  - **'Local to the Smart Inbox'**  
When you select this scan destination your scanned files are sent to the 'Scans' Inbox. This is the fixed scan destination for scan destination 1.
  - **'Local to USB storage device'**  
When you select this scan destination your scanned files are sent to the USB Mass storage device that is connected to the USB stick interface on the user panel. This is the fixed scan destination for scan destination 2.
6. Enter a file name for your scanned files.  
The file extension depends on the scanned file type that you select when you start your scan job on the user panel.  
If you enter a generic name, for example: scan###.\*, the scanned files automatically get a unique file name. An ascending number replaces the "###".
7. Enter a start value for ###. If you enter 001, the first scanned file is named scan001.\*.
8. Click 'Ok' to confirm your entries or 'Cancel' to reject your entries.

## Configure a remote scan destination



**Note:**

Before you can edit a setting or a settings group, you must log on as System administrator or Power user.

### Create a web destination with FTP

1. Create a home directory and a subdirectory on a workstation. For example c:\Ftp\Scan
2. Enable FTP on the workstation
3. Click 'Configuration' - 'Scan destinations'.
4. Click 'Edit' in a 'Scan destinations' bar.
5. Enter a name for the scan destination.  
This name will appear on the user panel.
6. Place a check mark in the enabled box.
7. Select 'Remote via FTP'.
8. For access to the directory on the workstation through FTP, a username and password is set on the FTP server that runs on the workstation. Enter this 'Scan destination 3: remote user name' and this 'Scan destination 3: remote password' in the required fields.



**Note:**

Make sure the user has write-access privileges on the destination.

9. Enter a path name of the 'Scan destination 3: remote folder'.  
The path name is the "**hostname-of-remote-workstation[/path]**". This is case sensitive.



**Note:**

Find the system name of the remote workstation on the control panel of the workstation (Control panel - Network - Identification - System name)

10. Enter a file name for your scanned files.  
The file extension depends on the scanned file type that you select when you start your scan job on the user panel.  
If you enter a generic name, for example: scan###.\*, the scanned files automatically get a unique file name. An ascending number replaces the "###".
11. Enter a start value for ###. If you enter 001, the first scanned file is named scan001.\*.
12. Click 'Ok' to confirm your entries or 'Cancel' to reject your entries.



**Note:**

If for any reason a scanned file cannot be delivered to the remote destination, the file is sent to the local 'Scans' Inbox.

## Create a network destination with SMB

1. Create a shared folder on a workstation. For example c:\Scan
2. Click 'Configuration' - 'Scan destinations'.
3. Click 'Edit' in a 'Scan destinations' bar.
4. Enter a name for the scan destination.  
This name will appear on the user panel.
5. Place a check mark in the enabled box.
6. Select 'Remote via SMB'.
7. If you defined a user name and a password for the shared folder on the remote PC enter this 'Scan destination 3: remote user name' and this 'Scan destination 3: remote password' in the required fields.



**Note:**

Make sure the user has write-access privileges on the destination.



**Note:**

If the remote workstation uses domains you must enter "**domain\_name\username**" as the 'Scan destination 3: remote user name' and the password for this user in this domain.

8. Enter a path name of the 'Scan destination 3: remote folder'.  
The path name is the "**hostname-of-remote-workstation\sharename[path]**". This is case sensitive.



**Note:**

Find the system name of the remote workstation on the control panel of the workstation (Control panel - Network - Identification - System name)

9. Enter a file name for your scanned files.  
The file extension depends on the scanned file type that you select when you start your scan job on the user panel.  
If you enter a generic name, for example: scan###.\*, the scanned files automatically get a unique file name. An ascending number replaces the "###".
10. Enter a start value for ###. If you enter 001, the first scanned file is named scan001.\*.
11. Click 'Ok' to confirm your entries or 'Cancel' to reject your entries.



**Note:**

If for any reason a scanned file cannot be delivered to the remote destination, the file is sent to the local 'Scans' Inbox.

### Test button

1. To test the validity of the remote scan destination (FTP or SMB), use the “Test” button. The test automatically executes the following 5 steps:

- Check the remote folder syntax.
- Check the validity of the hostname.
- Check the possibility of connecting to the remote host.
- Check if the remote destination exists.
- Check the possibility of writing to the remote destination.

When all of these 5 steps are completed successfully, the following message is displayed: “The remote destination is valid.”

If one of these steps fails, an error message and error code are generated.

Error code	Possible Causes
2	<ul style="list-style-type: none"> <li>■ For SMB destination: check that remote folder &lt;remotefolder&gt; syntax conforms to \\hostname\share\[folder\...] or \&lt;IP_address&gt;\share\[folder\...]</li> <li>■ For FTP destination: check that remote folder &lt;remotefolder&gt; syntax conforms to hostname/folder[/subfolder/...] or &lt;IP_address&gt;/folder[/folder/...]</li> </ul>
3	<ul style="list-style-type: none"> <li>■ Check whether the hostname is OK.</li> <li>■ Make sure the printer is connected to your network.</li> <li>■ Check the network settings of the printer in Express Web Tools :                             <ul style="list-style-type: none"> <li>- Primary DNS suffix</li> <li>- Preferred DNS server</li> <li>- NetBios over TCP/IP is set to "Enabled"</li> <li>- Subnet mask</li> <li>- Default gateway.</li> </ul> </li> <li>■ Check with the System administrator whether the DNS server can resolve the hostname to an IPv4 address.</li> <li>■ Check that the printer's security level is set to normal.</li> <li>■ For SMB destination: if IPV6 protocol is enabled on the printer:                             <ul style="list-style-type: none"> <li>- replace hostname with its IPv4 address (if IPV6 must be enabled)</li> <li>- or Disable IPV6 on the printer (if IPV6 can be disabled)</li> </ul> </li> <li>■ If none of previous checks solve the problem: enter the remote host IPv4 address instead of the hostname</li> </ul>



Error code	Possible Causes
4	<ul style="list-style-type: none"> <li>■ Check whether the hostname or IP address is correctly typed.</li> <li>■ Check that the remote host is up and running and connected to the network.</li> </ul>
5, 6, 7	<ul style="list-style-type: none"> <li>■ Check that SMB or FTP protocol is enabled on the remote host</li> <li>■ Check that the customer network security policy (firewall/switch) does not block FTP ports</li> <li>■ For SMB destination:               <ul style="list-style-type: none"> <li>- check that the security level is set to "Normal"</li> <li>- check that the remote host supports SMB1 protocol (error code: 7)</li> </ul> </li> <li>■ For FTP destination: check that the FTP server is using port 21</li> </ul>
8	<ul style="list-style-type: none"> <li>■ Check whether the remote username and password are correct.</li> <li>■ For SMB destination: Check the remote username syntax:               <ul style="list-style-type: none"> <li>- For a remote host user: &lt;hostname&gt;\&lt;username&gt;</li> <li>or &lt;ip_address&gt;\&lt;username&gt;</li> <li>- For a domain user: &lt;domainname&gt;\&lt;username&gt;</li> </ul> </li> </ul>
9	<ul style="list-style-type: none"> <li>■ The remote destination server has reached the maximum number of connections. Check with the System administrator or try again later.</li> </ul>
10	<ul style="list-style-type: none"> <li>■ Check that the remote folder is correctly typed</li> <li>■ Check that the remote folder exists on the remote host</li> <li>■ For SMB destination: check that the share is correctly typed or the share exists on the remote host</li> <li>■ For FTP destination: check that the remote folder has "list" permissions for remote user</li> </ul>
11, 12	<ul style="list-style-type: none"> <li>■ Check that the remote user has "write" permission on the remote share (for SMB) and on the remote folder (for SMB and FTP)</li> <li>■ Check that the remote folder is not full (error code: 12)</li> <li>■ SMB destination: check that the remote username is correctly typed (may happen if "guest" account is enabled on the remote host).</li> </ul>

# Configure the pen settings

## Introduction


Normally the pen settings are defined in the application that is used to create a drawing. If the pen settings are not defined in the application, the default pen settings configured in the Océ Express WebTools are used.



**Note:**

Before you can edit a setting or a settings group, you must log on as Key operator.

## Illustration



## How to configure the pen settings

1. Click 'Configuration' - 'Pens'.
2. Click on the value of the pen number that you want to change.  
The pen settings window appears where you can configure the color, width and pattern for this pen.
3. Click 'Ok' to confirm your entries or 'Cancel' to reject your entries.

# Define your printing system preferences

## What you need to know about default settings

### Definition

Before you send print jobs to the Océ ColorWave 300, remember the following.

The values defined in the Océ Express WebTools are default values for the general system behavior. You can define a number of job settings in the Océ printer drivers or the Océ job submission tools. The settings defined in the printer drivers or the job submission tools always overrule the settings defined in the Océ Express WebTools.

# Define the system preferences

## Introduction


Before you start to use your printing system you can define the general system preferences to fine tune it to optimally fit your company's workflow and processes.



**Note:**

Before you can edit a setting or a settings group, you must log on as a Key operator.

## Illustration





## How to define the system preferences

1. Click 'Preferences' - 'System settings'.

The system settings are grouped in functional settings groups. You can find detailed information about the settings in the tooltip.

Settings group	Description
'Contact in case of error'	Person to contact in case of error.

Settings group	Description
'Regional settings'	<p>The regional settings are configured during the installation of your system. Here you can change the initial configuration.</p> <p> <b>Note:</b> You can toggle between the 'First language' and the 'Second language' on the user panel.</p> <p> <b>Note:</b> Every time you change the 'Measurement unit', the controller recalculates the values from millimeter to inches and vice versa. If you reverse to the original value of this setting a slight calculation difference can occur due to rounding differences.</p>
'Current date and time'	Set the actual date, time and time-zone.
'Print queue management'	Define how jobs are managed in the print queue.
'Smart Inbox management'	Define how jobs are managed in the Smart Inboxes.
'Logging and accounting'	Define logging and accounting data.
'Printer properties'	Define the general printer behavior.
'Scanner properties'	Define the general scanner behavior. Only available if a scanner is installed.
'Stamps 1 to 4'	Configure and enable stamps for copy jobs.
'Stamps 5 to 8'	Configure and enable stamps for copy jobs.
'Stamps 9 to 12'	Configure and enable stamps for copy jobs.

- Click 'Edit' in the settings group bar or click the value of a single setting.  
(see ['How to edit a setting'](#) on page 92)
- Click 'Ok' to confirm your entries or 'Cancel' to reject your entries.

# Define the print job preferences

## Introduction

Here you can define the **default** values for print jobs.


If you send a print job using an Océ printer driver or an Océ job submission tool, the job settings defined in the printer driver or the job submission tool always overrule the default settings defined in the Océ Express WebTools.



### Note:

Before you can edit a setting or a settings group, you must log on as a Key operator.

## Illustration



## How to define the print job preferences

1. Click 'Preferences' - 'Print job defaults'.

The system settings are grouped in functional settings groups. You can find detailed information about the settings in the tooltip.

Settings group	Contains settings that define
'Image'	the default processing of image data.
'Color management'	the look and feel of the printed colors
'Layout'	the default positioning of the image on the printed output.
'Sheet'	the default media usage.
'General rasterization settings'	how the printer processes complex files.
'HP-GL'	how the printer interprets 'HP-GL' files.
'HP-GL/2'	how the printer interprets 'HP-GL/2' files.
'CalComp'	how the printer interprets 'CalComp' files.
'PostScript/PDF'	how the printer interprets 'PostScript/PDF' files.
'TIFF'	how the printer interprets 'TIFF' files.
'ASCII'	how the printer interprets 'ASCII' files.
'DWF'	how the printer interprets 'DWF' files.

2. Click 'Edit' in the settings group bar or click the value of a single setting. (see [How to edit a setting](#) on page 92)
3. Click 'Ok' to confirm your entries or 'Cancel' to reject your entries.

## Optimize the default output quality for print jobs

### Introduction

The Océ Express WebTools offers the following settings to optimize the default output quality for print jobs.

You can find these settings in the 'Preferences' - 'Print job defaults' tab.



**Note:**

Before you can edit a setting or a settings group, you must log on as a Key operator.

### 'Print quality'

Values	Description
'Presentation'	The print speed is moderate. The output quality is optimal. Use this setting, for example, to present drawings to the customers.
'Release'	The print speed is high. The output quality is very good. This setting offers a good combination of output quality and productivity. 'Release' is the default value.
'Check'	The print speed is very high. The output quality is good.

### 'Color feel for HP-GL, HP-GL/2 and HP-RTL'

Defines the 'look and feel' of the printed colors.

Values	Description
'Océ CAD colors'	'CAD colors' gives bright saturated colors. Suggested use: line and vector drawings.



Values	Description	
'Océ enhanced colors'	'Enhanced colors' gives photo-realistic colors. Suggested use: photos or graphic art presentations. You will get the most realistic result if you set the RGB input data to the international standard your original was made in. Advanced settings:	
	'RGB input data'	'sRGB' 'Adobe RGB'
	'Rendering intent'	'Perceptual (photo)' 'Saturation (business graphics)' 'Absolute colorimetric' 'Relative colorimetric'
'Simulated printers'	Select 'Simulated printers' to get a print with similar colors as the simulated printer. Options: <ul style="list-style-type: none"> <li>■ 'Simulated Océ TCS400 CAD colors'</li> <li>■ 'Simulated non-Océ printer: vivid colors'</li> <li>■ 'Simulated non-Océ printer: match screen colors'</li> <li>■ 'Simulated non-Océ printer: no color correction'</li> </ul>	
'None, managed by application'	Select 'None, managed by application' if color management is completely done by the application that generated the print file.	

### 'Color feel for TIFF and JPEG'

Defines the 'look and feel' of the printed colors.

Values	Description
'Océ CAD colors'	'CAD colors' gives bright saturated colors. Suggested use: line and vector drawings.

Values	Description	
'Océ Enhanced colors'	'Enhanced colors' gives photo-realistic colors. Suggested use: photos or graphic art presentations. You will get the most realistic result if you set the RGB input data to the international standard your original was made in. Advanced settings:	
	'RGB input data'	'sRGB' 'Adobe RGB'
	'Rendering intent'	'Perceptual (photo)' 'Saturation (business graphics)' 'Absolute colorimetric' 'Relative colorimetric'
'Simulated printers'	Select 'Simulated printers' to get a print with similar colors as the simulated printer. Options: <ul style="list-style-type: none"> <li>■ 'Simulated Océ TCS400 CAD colors'</li> <li>■ 'Simulated non-Océ printer: vivid colors'</li> <li>■ 'Simulated non-Océ printer: match screen colors'</li> <li>■ 'Simulated non-Océ printer: no color correction'</li> </ul>	
'None, managed by application'	Select 'None, managed by application' if color management is completely done by the application that generated the print file.	

### 'Color feel for PostScript and PDF'

Defines the 'look and feel' of the printed colors.

Values	Description
'Océ CAD colors'	'CAD colors' gives bright saturated colors. Suggested use: line and vector drawings.

Values	Description						
'Océ Enhanced colors'	'Enhanced colors' gives photo-realistic colors. Suggested use: photos or graphic art presentations. You will get the most realistic result if you set the RGB input data or CMYK input data to the international standard your original was made in. Advanced settings:						
	<table border="1"> <tr> <td>'RGB input data'</td> <td>'sRGB' 'Adobe RGB'</td> </tr> <tr> <td>'CMYK input data'</td> <td>'Euroscale coated' 'Euroscale uncoated' 'Euroscale coated (SWOP)' 'US web uncoated'</td> </tr> <tr> <td>'Rendering intent'</td> <td>'Perceptual (photo)' 'Saturation (business graphics)' 'Absolute colorimetric' 'Relative colorimetric'</td> </tr> </table>	'RGB input data'	'sRGB' 'Adobe RGB'	'CMYK input data'	'Euroscale coated' 'Euroscale uncoated' 'Euroscale coated (SWOP)' 'US web uncoated'	'Rendering intent'	'Perceptual (photo)' 'Saturation (business graphics)' 'Absolute colorimetric' 'Relative colorimetric'
'RGB input data'	'sRGB' 'Adobe RGB'						
'CMYK input data'	'Euroscale coated' 'Euroscale uncoated' 'Euroscale coated (SWOP)' 'US web uncoated'						
'Rendering intent'	'Perceptual (photo)' 'Saturation (business graphics)' 'Absolute colorimetric' 'Relative colorimetric'						
'Simulated printers'	Select 'Simulated printers' to get a print with similar colors as the simulated printer. Options: <ul style="list-style-type: none"> <li>■ 'Simulated Océ TCS400 CAD colors'</li> <li>■ 'Simulated non-Océ printer: vivid colors'</li> <li>■ 'Simulated non-Océ printer: match screen colors'</li> <li>■ 'Simulated non-Océ printer: no color correction'</li> </ul>						
'None, managed by application'	Select 'None, managed by application' if color management is completely done by the application that generated the print file.						

### 'Color feel for DWF'

Defines the 'look and feel' of the printed colors.

Values	Description
'Océ CAD colors'	'CAD colors' gives bright saturated colors. Suggested use: line and vector drawings.

Values	Description
'Océ Enhanced colors'	'Enhanced colors' gives photo-realistic colors. Suggested use: photos or graphic art presentations. You will get the most realistic result if you set the RGB input data to the international standard your original was made in. Advanced settings:
	'RGB input data' <span style="float: right;">'sRGB'</span> <span style="float: right;">'Adobe RGB'</span>
	'Rendering intent' <span style="float: right;">'Perceptual (photo)'</span> <span style="float: right;">'Saturation (business graphics)'</span> <span style="float: right;">'Absolute colorimetric'</span> <span style="float: right;">'Relative colorimetric'</span>
'Simulated printers'	Select 'Simulated printers' to get a print with similar colors as the simulated printer. Options: <ul style="list-style-type: none"> <li>■ 'Simulated Océ TCS400 CAD colors'</li> <li>■ 'Simulated non-Océ printer: vivid colors'</li> <li>■ 'Simulated non-Océ printer: match screen colors'</li> <li>■ 'Simulated non-Océ printer: no color correction'</li> </ul>
'None, managed by application'	Select 'None, managed by application' if color management is completely done by the application that generated the print file.

### 'Printing of gray colours'

Defines how shades of gray are printed.

Values	Description
'Use black ink only'	'Use black ink only' is the default value.
'Use all ink colors'	'Use all ink colors' is only valid when the setting 'Print quality' is 'Presentation'.

# Define the copy job preferences and copy templates

## Introduction

Here you can define the general copy job settings and four copy templates.

## What you need to know about copy templates

Copy templates enable you to easily perform copy jobs that you do very often. The job templates appear on the user panel when you select 'COPY'.

With a copy template you can pre-define the settings you need for a copy job. You only need to set the job settings once and you can store the settings in a job template that is presented on the user panel. You can re-use the job template for each next job without the need to redefine all the settings every time. The user panel offers 4 job templates for copy jobs.

The job template function supports the green button approach: the user only needs to select a template and start a job with the required settings instead of having to define all the settings manually for every job.



**Note:**


When you select a copy template on the user panel, you can still change the individual values of all settings.



**Note:**

Before you can edit a setting or a settings group, you must log on as a Key operator.

## Illustration



## How to define the copy job preferences

1. Click 'Preferences' - 'Copy job defaults'.

The system settings are grouped in functional settings groups. You can find detailed information about the settings in the tooltip.

Settings group	Description
'General copy job settings'	Default copy job settings that refer to all copy jobs.
'Copy template 1: Name and description'	The name and description you enter here are visible on the user panel when you select 'COPY'.
'Copy template 1: Original'	Settings that refer to the original.
'Copy template 1: Image and layout'	Settings that determine the default processing of image data and the default positioning of the image on the printed output.

Settings group	Description
'Copy template 1: Sheet'	Settings that determine the default media usage.

**Note:**

You can define the same settings for copy template 2, 3 and 4.

2. Click 'Edit' in the settings group bar or click the value of a single setting.  
(see [How to edit a setting](#) on page 92)
3. Click 'Ok' to confirm your entries or 'Cancel' to reject your entries.

# Optimize the default output quality for copy jobs

## Introduction

The Océ Express WebTools offers the following settings to optimize the default output quality for copy jobs. You can define a default output quality for each copy job template. You can find these settings in the 'Preferences' - 'Copy job defaults' tab.



**Note:**  
Before you can edit a setting or a settings group, you must log on as a Key operator.

## 'Original type color copy'

The quality of the printed output is optimized based on the type of the color original that is copied.

Values	Description
'Artwork'	This value is used for 3D CAD rendering, mixed content, consumer graphics and point of sales graphics drawings.
'Line/text'	This value is advised for line drawings and design drawings. Lines and text are optimized, a light background is compensated.
'Map'	This value is used for maps, logo and business color, business graphics and 3D CAD rendering drawings. 'Map' is default value for copy jobs.
'Poster/photo'	'Poster/photo' is the advised value for photos. The output quality is high.
'Folded line/text'	'Folded line/text' is advised for line and design drawings that are folded. This mode suppresses the "folding line".

## 'Original type grayscale copy'

The quality of the printed output is optimized based on the type of the original that is copied.

Values	Description
'Line/text'	'Line/text' is default value for copy jobs. This value is advised for line drawings and design drawings. Lines and text are optimized, a light background is compensated.



Values	Description
'Colored original'	'Colored original' is the advised value for colored originals like maps, 3D-CAD drawings, consumer graphics or rasterized photos. The output is optimized for the reproduction of the color information. The system compensates for a gray background and for light wrinkles.
'Photo'	'Photo' is the advised value for photos. The output quality is high.
'Blueprint'	'Blueprint' is the advised value for blueprints. The information on the original is inverted. White lines will be black, the blue background will be white.
'Dark original'	'Dark original' is the advised value for originals with a dark background. The output is optimized especially for dark transparent originals. The system compensates for the dark background and the actual information on the original is optimized.
'Folded line/text'	'Folded line/text' is advised for line and design drawings that are folded. This mode suppresses the "folding line".

### 'Background compensation'

Values	Description
'On'	If you select 'Auto' the system decides depending on the original type whether background compensation will be on or off.
'Off'	
'Auto'	

### 'Print quality'

Values	Description
'Presentation'	The print speed is moderate. The output quality is optimal. Use this setting, for example, to present drawings to the customers.

Values	Description
'Release'	The print speed is high. The output quality is very good. This setting offers a good combination of output quality and productivity. 'Release' is the default value.
'Check'	The print speed is very high. The output quality is good.

### 'Lighter/darker'

Values	Description
Numeric value between -5 and +5	Increase this value if you want your printed output to be darker. Decrease this value if you want your printed output to be lighter. 0 is the default value.

---

# Define the scan job preferences and scan templates

## Introduction

Here you can define the general scan job settings and four scan templates.

## What you need to know about scan templates

Scan templates enable you to easily perform scan jobs that you do very often. The job templates appear on the user panel when you select 'SCAN'.

With a scan template you can pre-define the settings you need for a scan job. You only need to set the job settings once and you can store the settings in a job template that is presented on the user panel. You can re-use the job template for each next job without the need to redefine all the settings every time. The user panel offers 4 job templates for scan jobs.

The job template function supports the green button approach: the user only needs to select a template and start a job with the required settings instead of having to define all the settings manually for every job.



**Note:**


When you select a scan template on the user panel, you can still change the individual values of all settings.



**Note:**

Before you can edit a setting or a settings group, you must log on as a Key operator.

## Illustration



## How to define the scan job preferences

1. Click 'Preferences' - 'Scan job defaults'.

The system settings are grouped in functional settings groups. You can find detailed information about the settings in the tooltip.

Settings group	Description
'General scan job settings'	Default scan job settings that refer to all scan jobs.
'Scan template 1: Name and description'	The name and description you enter here are visible on the user panel when you select 'SCAN'.
'Scan template 1: Original'	Settings that refer to the original.

---

Settings group	Description
'Scan template 1: File'	Settings that refer to the destination and the file type of the scanned file. You can select one of the scan destinations that you enabled in the 'Configuration' - 'Scan destinations' tab. (see <i>'Configure scan destinations'</i> on page 115)

2. Click 'Edit' in the settings group bar or click the value of a single setting.  
(see *'How to edit a setting'* on page 92)
3. Click 'Ok' to confirm your entries or 'Cancel' to reject your entries.

# Optimize the default output quality for scan jobs

## Introduction

The Océ Express WebTools offers the following settings to optimize the default output quality for scan jobs. You can define a default output quality for each scan job template. You can find these settings in the 'Preferences' - 'Scan job defaults' tab.



**Note:**  
Before you can edit a setting or a settings group, you must log on as a Key operator.

## 'Original type when scanning to color'

The quality of the scanned file is optimized based on the type of the original that is scanned.

Values	Description
'Artwork'	This value is used for 3D CAD rendering, mixed content, consumer graphics and point of sales graphics drawings. 'Artwork' is default value.
'Line/text'	'Line/text' is advised for line drawings and design drawings. Lines and text are optimized, a light background is compensated.
'Map'	This value is used for maps, logo and business color, business graphics and 3D CAD rendering drawings.
'Poster/photo'	'Poster/photo' is the advised value for photos and posters. The output quality is high.
'Folded line/text'	'Folded line/text' is advised for line and design drawings that are folded. This mode suppresses the "folding line".

## 'Original type when scanning to grayscale or black-and-white'

The quality of the scanned file is optimized based on the type of the original that is scanned.


Values	Description
'Line/text'	'Line/text' is advised for line drawings and design drawings. Lines and text are optimized, a light background is compensated. 'Line/text' is the default value.

Values	Description
'Colored original'	'Colored original' is the advised value for colored originals like maps, 3D-CAD drawings, consumer graphics or rasterized photos. The output is optimized for the reproduction of the color information. The system compensates for a gray background and for light wrinkles.
'Photo'	'Photo' is the advised value for photos. The output quality is high.
'Blueprint'	'Blueprint' is the advised value for blueprints. The information on the original is inverted. White lines will be black, the blue background will be white.
'Dark original'	'Dark original' is the advised value for originals with a dark background. The output is optimized especially for dark transparent originals. The system compensates for the dark background and the actual information on the original is optimized.
'Folded line/text'	'Folded line/text' is advised for line and design drawings that are folded. This mode suppresses the "folding line".

### 'Background compensation'

Values	Description
'On'	If you select 'Auto' the system decides depending on the original type whether background compensation will be on or off.
'Off'	
'Auto'	

### 'Resolution (dpi)'

Values	Description
'100'	Use this setting to define the resolution of the scanned images. The higher the resolution, the better the image quality.   <b>Note:</b> A higher resolution increases the file size.
'200'	
'300'	
'400'	
'600'	

### 'Lighter/darker'

Values	Description
Numeric value between -5 and +5	Increase this value if you want your printed output to be darker. Decrease this value if you want your printed output to be lighter. 0 is the default value.

### 'File type'

Values	Description
'TIFF' 'Compression for TIFF' 'File organization for TIFF'	Use this setting to define the file type of your scanned file. You can also define the default compression method, file organization or quality per file type. Depending on the color mode and file type you select, the values for the compression mode and organization will change.
'PDF/A' 'Compression for PDF' / 'JPEG quality for PDF'	For some file types, the compression and organization settings cannot be set in all situations.
'JPEG' 'Quality for JPEG'	





# Manage jobs on your printing system

## The Smart Inbox and Jobs Queue concept

### Definition

Smart Inboxes are used for customized job management.

Concept	The Jobs Queue	The Smart Inbox
Metaphor	Production belt 	Personal mailboxes 
User intention	<ul style="list-style-type: none"> <li>■ get the job printed as soon as possible</li> </ul>	<ul style="list-style-type: none"> <li>■ send jobs to the system</li> <li>■ organize jobs</li> </ul>
Used to	<ul style="list-style-type: none"> <li>■ get feedback of printer progress</li> <li>■ cancel requests</li> <li>■ change priority (local)</li> </ul>	<ul style="list-style-type: none"> <li>■ keep together sets of documents from various origins</li> <li>■ organize documents over various Smart Inboxes, to easily retrieve jobs</li> <li>■ reprint jobs or change settings of jobs that are already sent to the printer</li> </ul>

### Jobs in a Smart Inbox

You can use Smart Inboxes to manage your jobs. When you open the 'Jobs' tab in the Océ Express WebTools the Smart Inbox section displays an overview of the Smart Inboxes. Define one or more Smart Inbox names that allow you to easily organize and access your jobs.

The following jobs are placed in a Smart Inbox.

**Scan jobs**, if the selected scan destination is set to 'Local to the Smart Inbox'.

If you select a remote scan destination ('Configuration' - 'Scan destinations') it is possible that the scanned file cannot be delivered to this destination. In that case the scanned file will also be placed in the 'Scans' Smart Inbox.

### Copy jobs

If you want your copy jobs to appear in a Smart Inbox, you must enable the 'Preferences' - 'System settings' - 'Smart Inbox management' - 'Display a Smart Inbox with all jobs' setting. Your copy job is then displayed in the 'View all' Smart Inbox. The 'Preferences' - 'System settings' - 'Smart Inbox management' - 'Save printed jobs in a Smart Inbox' - setting determines if copy jobs that have been printed will be kept in the Smart Inbox for reprint or not.

**Print jobs**, sent via printer drivers, applications or Océ Publisher Express.

In the printer driver, application or job submitter you can enter the name of the Smart Inbox you want to print to.

When you use the Océ Windows® Printer Driver and the 'Preferences' - 'System settings' - 'Print queue management' - 'Destination for new print jobs' is set to 'As specified in the job ticket', you can also enable or disable 'Direct print'. When 'Direct print' is enabled your print job will be sent to the print queue immediately. When 'Direct print' is disabled your print job is kept in the Smart Inbox and you must send the print job to the print queue manually.

## Smart Inbox functionality

### 'View job information'

To view the job information click on the job name in the Smart Inbox.

### 'Delete'

To delete a job from the Smart Inbox select the job and click 'Delete'.

### 'Edit' (not for 'Scans' Smart Inbox)

To edit the job settings of a job select the job and click 'Edit'. A window opens where you can change the 'Number of sets' setting and the 'Collate' setting.

### 'Print'

To print a job select the job and click 'Print'. The job is copied into the Job Queue when the 'Preferences' - 'System settings' - 'Print queue management' - 'Print queue' setting is set to 'On'. The 'Preferences' - 'System settings' - 'Smart Inbox management' - 'Save printed jobs in a Smart Inbox' - setting determines if jobs that have been printed will be kept in the Smart Inbox for reprint or not.

### 'Save' (only for 'Scans' Smart Inbox)

This button allows you to save a scanned file.

---

**'Delete all'** (only for 'View all' Smart Inbox)

To delete all the jobs from all Smart Inboxes click the 'Delete all' button.



*Note:*

The icon in front of the job name provides status information about the job. Detailed information about the status is displayed in the tooltip.



*Note:*

When a Smart Inbox contains many jobs you can sort the jobs by clicking on a column name (for example: 'Job name' or 'Time created'). You can also change the display method of the jobs in the Smart Inbox. Select 'List view' if you want to display all jobs. Select 'Group view' if you want to display only the groups of your sort criterion in the Smart Inbox.



*Note:*

The 'View all' Smart Inbox is only available if you enable the 'Preferences' - 'System settings' - 'Smart Inbox management' - 'Display a Smart Inbox with all jobs' setting.

## Job Queue functionality

**'View job information'**

To view the job information click on the job name in the queue.

**'Top'**

To increase the print priority of a job in the queue you can select the job and click 'Top' to place the job on top of the queue.

**'Delete'**

To delete a job from the Job Queue select the job and click 'Delete'.

**'Delete all'**

To empty the Job Queue completely click the 'Delete all' button.



*Note:*

The icon in front of the job name provides status information about the job. Detailed information about the status is displayed in the tooltip.



*Note:*

When a job is printed, the job is removed from the Job Queue.

# Use Smart Inboxes in a multiple-user environment

## Introduction

A multiple-user environment is a working environment where users directly send jobs to the printer, collect their own prints and make their own copies and scans. In this environment it is important for a user to have easy access to his personal jobs.

## Illustration



## How to set up the Smart Inboxes in a multiple-user environment

1. Open the 'Preferences' - 'System settings' tab and select 'Edit' in the 'Smart Inbox management' bar.
2. Enter the following values (example).

Setting	Value
'Display a Smart Inbox with all jobs'	'Disabled'
'Allow printing from Smart Inbox'	'Everyone'
'Save printed jobs in a Smart Inbox'	'Enabled'
'Printed jobs in Smart Inbox: job lifetime'	For example: 8 hours
'Printed jobs in Smart Inbox: maximum number of jobs'	For example: 100

## Use Smart Inboxes in a repro environment

### Introduction

A repro environment is a working environment where a repro operator handles all the jobs. In this environment the repro operator can use the 'Smart Inbox' to organize his daily work.

### Illustration



### How to set up the Smart Inboxes in a repro environment

1. Open the 'Preferences' - 'System settings' tab and select 'Edit' in the 'Smart Inbox management' bar.
2. Enter the following values (example).

Setting	Value
'Display a Smart Inbox with all jobs'	'Enabled'
'Allow printing from Smart Inbox'	'Login needed' Note: repro operators control the jobs
'Save printed jobs in a Smart Inbox'	'Enabled'
'Printed jobs in Smart Inbox: job lifetime'	For example: 8 hours
'Printed jobs in Smart Inbox: maximum number of jobs'	For example: 100

## Open or create a Smart Inbox

### Open or create a Smart Inbox in the 'Smart Inbox' section

1. Select the 'Jobs' tab.
2. In the 'Smart Inbox' section click 'Open Smart Inbox'.
3. Click on the blank field to open a drop-down list with all Smart Inboxes available on your system that contain one or more jobs. You can open an existing Smart Inbox from the list or you can type the name of a new Smart Inbox.
4. Press **Enter** or click on 'Smart Inbox'.  
The Smart Inbox is now displayed in the 'Smart Inbox' section.

### Open or create a Smart Inbox in Océ Publisher Express

1. Select the 'Jobs' tab.
2. Click on 'Create new job' in the Océ Publisher Express section.
3. In the 'Workflow' section click on the Smart Inbox field to open a drop-down list with all Smart Inboxes available on your system that contain one or more jobs. You can open an existing Smart Inbox from the list or you can type the name of a new Smart Inbox.
4. Click 'Ok' to send the print job to the Smart Inbox.  
The Smart Inbox is now displayed in the 'Smart Inbox' section.

---

## Delete a Smart Inbox

---

**Caution:**

When you delete a 'Smart Inbox', you only delete the view on the 'Smart Inbox', but not the content. To permanently delete the jobs from a 'Smart Inbox' you must select the jobs in the 'Smart Inbox' and click 'Delete'.

---

### How to delete a Smart Inbox

1. Select the 'Jobs' tab.
2. To delete a Smart Inbox click on the X - button at the right side of the 'Smart Inbox' bar.





# **Chapter 5**



## **Use the Océ ColorWave 300 multifunction printer**

## Pause, resume or delete an active job

### Introduction

This section describes how to pause, resume or delete an active job.

### How to 'Pause' or 'Resume' an active print job

Action	Remarks
<p>To pause the printer: In the 'QUEUE' screen use the lower left soft key on the user panel to 'Pause' the printer.</p>	
<p>In the 'QUEUE' screen use the lower right soft key to 'Resume' the printer.</p>	

### How to delete an active print job

If you use the	Then	Result
User panel	Press the stop button	A dialog box appears on the user panel.

If you use the	Then	Result
Océ Express WebTools	Open the 'Jobs' tab. In the 'Jobs - Queue' section tick the box in front of the job you want to delete and click 'Delete'.	The system aborts and deletes the job immediately. The deleted job is in the Smart inbox.

### How to delete an active print job (printer active - scanner inactive)

Step	Action	Result
1	Press the stop button. A dialog box appears: 'Are you sure you want to abort the current job' with the job name.	The machine stops printing after the current page has been printed.
2	<ul style="list-style-type: none"> <li>■ Press 'Abort' to abort and stop the job directly.</li> <li>■ Press 'Continue': The job is continued.</li> </ul>	
3	In case you 'Abort' the job, a dialog box appears: 'Delete job from Smart Inbox as well?' <ul style="list-style-type: none"> <li>■ Press 'Yes' to confirm that you really want to delete the job from the Smart Inbox.</li> <li>■ Press 'No' when you don't want to delete the job from the Smart Inbox.</li> </ul>	

### How to delete an active copy job (printer active - scanner active)

Step	Action	Result
1	Press the stop button. A dialog box appears: 'Copy job has been stopped' and 'Release original?'	The machine stops scanning.

Step	Action	Result
2	<ul style="list-style-type: none"><li>■ Press 'Yes' to confirm that you want to release the original. The scanner releases the original.</li><li>■ Press 'No' if you do not want to transport the original automatically. Follow the instructions to remove the original.</li></ul>	The scan of the original is stopped and the original is removed.

### How to delete an active scan job (printer inactive - scanner active)

Step	Action	Result
1	Press the stop button. A dialog box appears: 'Scan job has been stopped' and 'Release original?'	The machine stops scanning.
2	<ul style="list-style-type: none"><li>■ Press 'Yes' to confirm that you want to release the original. The scanner releases the original.</li><li>■ Press 'No' if you do not want to transport the original automatically. Follow the instructions to remove the original.</li></ul>	The scan of the original is stopped and the original is removed.

### How to delete an active print job with Océ Express WebTools







Step	Action	Result
1	Open the 'Jobs' tab.	
2	In the 'Jobs - Queue' section tick the box in front of the job you want to delete and click 'Delete'.	The system aborts and deletes the job immediately. The deleted job is in the Smart inbox.

## The job states






### Introduction

When a job is placed in a Smart Inbox or in the Queue, the icon in front of the job name gives information about the status of the job.

### Overview of the job states in the Smart Inbox


State	Icon	Description
Receiving		Indicates that the Smart Inbox is receiving the job data.
New		Indicates that a new job is available in the Smart Inbox.
Queued		Indicates that the job is copied to the queue and waiting to be printed.
Printed		Indicates that the job has been printed.
Attention needed		General error message.
Account data missing		State when the account data for the job is missing.

### Overview of the job states in the Queue

State	Icon	Description
Receiving		Indicates that the Queue is receiving the job data.
Processing		Indicates that the Queue is processing the job data.
Ready to print		Indicates that the job is ready for printing.
Scheduled		Indicates that the job is waiting to be printed.
Printing		Indicates that the job is currently being printed.

## The job states

---

State	Icon	Description
Attention needed		General error message.


# Clear the system

## When to do


If you want to remove all the jobs from the system.

## How to clear the system

1. From the 'HOME' screen on the printer user panel select the 'System' tab.
2. Select the 'Setup' tab.
3. Use the scroll wheel to select 'Clear system' ('Remove all jobs') wizard and confirm with the confirmation button (above the scroll wheel).



4. Follow the steps in the wizard.



5. Select 'Home' to return to the 'HOME' screen.

# Basic scan jobs

## Introduction to scan jobs

A basic scan job only takes three steps. Feed the original face up, select 'Scan' on the user panel and press the start button. Every other type of scan job is called an extended scan job.

An extended scan job takes some additional steps, where you select a specific scan template and, if necessary, change the predefined scan job settings on the user panel. The scan templates are defined in the Océ Express WebTools (see *[Define the scan job preferences and scan templates](#)* on page 139). When you select 'Scan', the user panel shows four scan templates. The scan templates provide access to the different settings per scan template. You can use the scroll wheel to see all the predefined settings. When the scan job is finished, the scanned file is placed in the Smart Inbox 'Scans'.



---

## Feed the original

---

**Caution:**

The scanner cannot scan an original that is thicker than 0.8 mm (0.6 mm is guaranteed, 0.8 mm is maximum) or rigid originals.

---

**Caution:**

Do not pull back the original when it is already fed into the scanner. To release the original, press the stop button on the user panel and open the scanner with the 2 levers.

---

### How to feed the original

1. Feed the original face up and centered on the original feeding table.

**Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.



2. The scanner takes the original.

## Auto-feed the original

### Introduction

The auto-feed functionality enables you to improve your productivity. When you activate the auto-feed functionality, you don't need to press the green button every time you scan a document. The scanner is activated automatically and after the scan procedure, the scanner releases the original automatically.

When auto-feed is enabled, the green button blinks.



**Note:**

The auto-feed functionality will be disabled when you navigate to the 'Queue', 'System' or 'Print' tab and when the operator panel reverts to the home screen after the specified time-out period.



**Note:**

You can change the settings of your copy or scan job before you feed the originals.

### How to autofeed the original

1. Feed the first original face up and centered on the original feeding table.

**Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.



2. The scanner takes the original.
3. Press the green button twice.  
You can double-click the green button or wait for the green button to light up for the second time. As long as the operator panel displays the dialog 'Press green button again to activate auto-feed' you can activate this functionality. The green button will now start to blink.

**Note:**

You can de-activate the auto-feed functionality by pressing the green button once more.

4. Wait for the operator panel to display 'Auto-feed next original' before feeding the next original.

## Do a basic scan job

1. Feed the original face up and centered on the original feeding table.




**Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.



2. Select 'Scan' on the user panel.



3. Press the start button.

## Result

You do a basic scan job in 3 steps. The basic scan job uses the settings of the first scan template.

# Extended scan jobs

## Introduction to scan jobs

A basic scan job only takes three steps. Feed the original face up, select 'Scan' on the user panel and press the start button. Every other type of scan job is called an extended scan job.

An extended scan job takes some additional steps, where you select a specific scan template and, if necessary, change the predefined scan job settings on the user panel. The scan templates are defined in the Océ Express WebTools (see *'Define the scan job preferences and scan templates'* on page 139). When you select 'Scan', the user panel shows four scan templates. The scan templates provide access to the different settings per scan template. You can use the scroll wheel to see all the predefined settings. When the scan job is finished, the scanned file is placed in the Smart Inbox 'Scans'.

## Do an extended scan job

1. Feed the original face up and centered on the original feeding table.




**Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.



2. Select 'Scan' on the user panel.




3. Open the 'Scan' tab with the confirmation button above the scroll wheel.
4. Select your scan template.


If you want to change the pre-defined settings of the selected scan template, use the confirmation button to open the scan template and display an overview of the pre-defined settings groups.



5. Scroll to the settings group you want to change.



6.
  - Open the settings group you want to change with the confirmation button and scroll to the setting you want to change.
  - Open this setting, scroll through the settings values and select the correct value with the confirmation button.
  - Change the other settings in the settings group if necessary.
  - Select 'OK' to return to the overview of the predefined settings groups.




7. Repeat steps 5 and 6 until you have set all the correct values for your scan job.
8. Press the start button.

## Available settings for scan jobs


### Introduction

The Océ ColorWave 300 provides a lot of settings to manage all your different scan jobs. These settings are used for extended scan jobs. The following table gives an overview and a very short description of the available settings. You can find a detailed description of each setting in the Océ Express WebTools.



### Settings group: 'Destination'

Setting	Settings values	Function
'Destination'	You can select one of the names of the scan destinations that you configured in the Océ Express WebTools. Examples: Local USB stick.	'The destination to put the scans into.'    (see ' <i>File type</i> ' on page 174)


### Settings group: 'File type'

Setting	Settings values	Function
 <b>Note:</b> Depending on the color mode and file type you select the values for the compression mode and organization will change. For some file types, the compression and organization settings cannot be set in all situations. (see also ' <i>Configure scan destinations</i> ' on page 115)		








Setting	Settings values	Function
'Color'	'Color' 'Grayscale' 'Black&white'	'Defines whether a color, grayscale or black-and-white scan must be made. Not all combinations of 'Color mode' and 'File type' are valid. Changing 'Color mode' resets 'File type', 'Compression for TIFF' and 'Compression for PDF' to a default value.'
		
'File type'	'TIFF' 'TIFF multipage' 'PDF/A' 'PDF multipage' 'JPEG' 'CAL S'	'The file type of the scanned image. The list of file types depends on scan to color, grayscale, or black-and-white: CAL S is only available when scanning to black-and-white; JPEG is not available when scanning to black-and-white.'
		
'Organization'	'Raw' 'Striped' 'Tiled'	'The file organization when scanning to TIFF.'
'Compression'	'LZW' 'Packbits' 'None' 'Flate' 'JPEG' 'Group 4' 'Group 3'	The compression type when scanning to TIFF or to PDF.
'JPEG quality'	'Maximum' 'High' 'Medium' 'Low'	'The image quality when scanning to PDF with JPEG compression. With a lower quality, the compression increases giving a smaller file size.'

### Settings group: 'Resolution'





Setting	Settings values	Function
'Resolution'	'100' '200' '300' '400' '600'	'The resolution of the scanned image in dpi.' 

### Settings group: 'Original'



Setting	Settings values	Function
'Original'	If scan to color: 'Artwork' 'Line/text' 'Map' 'Poster/photo' 'Folded line/text' If scan to grayscale or black and white: 'Line/text' 'Colored original' 'Photo' 'Blueprint' 'Dark original' 'Folded line/text'	The type of original. 
'Backgnd comp'	'On' 'Off' 'Auto'	Reduce the background noise of the image. 

Setting	Settings values	Function
'Width detect'	'Auto'	<p>The width of the original is automatically detected by the scanner.</p> 
	'Standard'	<p>'Ao' 'A1' 'A2' 'A3' 'A4' 'A5' 'E+ (36")' 'B1 (707 mm)' 'B2 (19.69 in)'</p> <p>The width of the original is a standard size.</p>  <p><b>i</b> <i>Note:</i> Depend on the media series you defined in the Océ Express WebTools</p>
	'Custom'	<p>210 to 914 mm</p> <p>The width of the original is a custom size.</p> 

### Settings group: 'Remove strip'

Setting	Settings values	Function
'Top'	0 to 400 mm	'Erase a strip from the beginning of the original.' 
'Bottom'	0 to 400 mm	'Erase a strip from the bottom of the original.' 
'Left'	0 to 400 mm	'Erase a strip from the left side of the original.' 
'Right'	0 to 400 mm	'Erase a strip from the right side of the original.' 


## Settings group: 'Light and mirror'

Setting	Settings values	Function
'Lighter/darker'	-5 to +5	<p>Increase the value for lighter prints; decrease for darker prints.</p> 
'Mirror'	'On' 'Off'	<p>'When 'on', the image is mirrored along the vertical axis (the media transport direction).'</p> <p>This setting is useful for dark transparent originals.</p> 


## 'File type'

Depending on the color mode and file type you select the values for the compression mode and organization will change. For some File types, the Compression and Organization settings cannot be set in all situations.


### Color mode: Color

'Color' mode	'File type'	'Organization'	'Compression'	'JPEG quality'
	'TIFF' 'TIFF multi-page'	'Raw' 'Striped' 'Tiled'	'LZW' 'Packbits' 'None'	Not applicable
	'PDF/A' 'PDF multi-page'	Not applicable	'Flate' 'None'	Not applicable
			'JPEG'	'Maximum' 'High' 'Medium' 'Low'
	'JPEG'	Not applicable	Not applicable	'Maximum' 'High' 'Medium' 'Low'

### Color mode: Grayscale

'Color' mode	'File type'	'Organization'	'Compression'	'JPEG quality'
'Grayscale' 	'TIFF'	'Raw'	'LZW'	Not applicable
	'TIFF multi-page'	'Striped'	'Packbits'	
		'Tiled'	'None'	
	'PDF/A'	Not applicable	'Flate'	Not applicable
'PDF multi-page'		'None'		
			'JPEG'	'Maximum'
				'High'
				'Medium'
				'Low'
	'JPEG'	Not applicable	Not applicable	'Maximum'
				'High'
				'Medium'
				'Low'

### Color mode: Black and White

'Color' mode	'File type'	'Organization'	'Compression'	'JPEG quality'
'Black&white' 	'TIFF'	'Raw'	'Group 4'	Not applicable
	'TIFF multi-page'	'Striped'	'Group 3'	
		'Tiled'	'Packbits'	'None'
	'PDF/A'	Not applicable	'Group 4'	Not applicable
'PDF multi-page'			'Flate'	
			'None'	
	'CALS'	Not applicable	Not applicable	Not applicable

# Make a scan and erase a margin

## Introduction

Use 'Remove strip' to scan an original with a strip and remove the strip from the scanned file. You can remove a strip from the leading, the trailing, the left or the right side of the original.

## Before you begin

If you must enter the same value for a setting very often, you can set this value as the default value for that setting in the Océ Express WebTools.

After you press the start key, the user panel always shows the job number and status of the job. A copy job appears temporarily in the 'Jobs - Queue' section of the Océ Express WebTools, a scan job appears in the Smart Inbox 'Scans'.



**Caution:**

When you remove a strip, make sure that you scan all the required information.

## How to make a scan and remove a strip





1. Feed the original face up and centered on the original feeding table.



**Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.

2. Select 'Scan' on the user panel.
3. Open the 'Scan' tab with the confirmation button above the scroll wheel.
4. Define the job settings.

			
The 'Top' margin strip	The 'Bottom' strip	The 'Left' margin	The 'Right' margin

- Open a template with the confirmation button.



- Scroll to 'Remove strip' and open this setting with the confirmation button.
  - Scroll to 'Top', 'Bottom', 'Left' or 'Right', define the value with the scroll wheel or numeric keys and confirm.
5. Press the start button.

## Result

The Océ ColorWave 300 scans the original without a strip.

# Basic copy jobs

## Introduction to copy jobs

A basic copy job only takes two steps. Feed the original face up and press the start button. Every other type of copy job is called an extended copy job.

An extended copy job takes some additional steps, where you select a specific copy template and, if necessary, change the predefined copy job settings on the user panel. The copy templates are defined in the Océ Express WebTools (see *[Define the copy job preferences and copy templates](#)* on page 133). When you select 'Copy', the user panel shows four copy templates. The copy templates provide access to the different settings per copy template. You can use the scroll wheel to see all the predefined settings.

---

## Feed the original

---

**Caution:**

The scanner cannot scan an original that is thicker than 0.8 mm (0.6 mm is guaranteed, 0.8 mm is maximum) or rigid originals.

---

**Caution:**

Do not pull back the original when it is already fed into the scanner. To release the original press the red stop button on the user panel.

---

### How to feed the original

1. Feed the original face up and centered on the original feeding table.

**Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.



2. The scanner takes the original.

## Auto-feed the original

### Introduction

The auto-feed functionality enables you to improve your productivity. When you activate the auto-feed functionality, you don't need to press the green button every time you scan a document. The scanner is activated automatically and after the scan procedure, the scanner releases the original automatically.

When auto-feed is enabled, the green button blinks.



**Note:**

The auto-feed functionality will be disabled when you navigate to the 'Queue', 'System' or 'Print' tab and when the operator panel reverts to the home screen after the specified time-out period.



**Note:**

You can change the settings of your copy or scan job before you feed the originals.

### How to autofeed the original

1. Feed the first original face up and centered on the original feeding table.

**Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.



2. The scanner takes the original.
3. Press the green button twice.  
You can double-click the green button or wait for the green button to light up for the second time. As long as the operator panel displays the dialog 'Press green button again to activate auto-feed' you can activate this functionality. The green button will now start to blink.

**Note:**

You can de-activate the auto-feed functionality by pressing the green button once more.

4. Wait for the operator panel to display 'Auto-feed next original' before feeding the next original.

## Do a basic copy job

1. Feed the original face up and centered on the original feeding table.




**Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.



The 'Copy' tab is automatically activated on the user panel.



**Note:**

The description of the first copy template is displayed. A basic copy job uses the settings defined in the first copy template.

2. Press the start button.

## Result

You do a basic copy job in 2 steps. The basic copy job uses the settings of the first copy template.

# Extended copy jobs

## Introduction to copy jobs

A basic copy job only takes two steps. Feed the original face up and press the start button. Every other type of copy job is called an extended copy job.

An extended copy job takes some additional steps, where you select a specific copy template and, if necessary, change the predefined copy job settings on the user panel. The copy templates are defined in the Océ Express WebTools (see *[Define the copy job preferences and copy templates](#)* on page 133). When you select 'Copy', the user panel shows four copy templates. The copy templates provide access to the different settings per copy template. You can use the scroll wheel to see all the predefined settings.



## Do an extended copy job

1. Feed the original face up and centered on the original feeding table.



**Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.




The 'Copy' tab is automatically activated on the user panel.




2. Open the 'Copy' tab with the confirmation button above the scroll wheel.
3. Select your copy template.


If you want to change the pre-defined settings of the selected copy template, use the confirmation button to open the copy template and display an overview of the pre-defined settings groups.



4. Scroll to the settings group you want to change.



5. ■ Open the settings group you want to change with the confirmation button and scroll to the setting you want to change.
- Open this setting, scroll through the settings values and select the correct value with the confirmation button.
  - Change the other settings in the settings group if necessary.
  - Select 'OK' to return to the overview of the predefined settings groups.



6. Repeat step 4 and 5 until you have set all the correct values for your copy job.
7. Press the start button.

## Available settings for copy jobs


### Introduction





The Océ ColorWave 300 provides a lot of settings to manage all your different copy jobs. These settings are used for extended copy jobs. The following table gives an overview and a very short description of the available settings. You can find a detailed description of each setting in the Océ Express WebTools.


### Settings group: 'Print mode'

Setting	Settings values	Function
'Color'	'Color' 'Grayscale'	Define the type of original.
'Quality'	'Check' 'Release' 'Presentation'	The print quality of the copy


### Settings group: 'Original'

Setting	Settings values	Function
'Original'	Color original: 'Line/text' 'Artwork' 'Map' 'Poster/photo' 'Folded line/text' Grayscale original: 'Line/text' 'Colored original' 'Photo' 'Blueprint' 'Dark original' 'Folded line/text'	Define the type of original you use. 



Setting	Settings values	Function
'Backgnd comp'	'On' 'Off' 'Auto'	Reduce the background noise of the image. 
'Width detect'	'Auto'	The width of the original is automatically detected by the scanner. 
	'Standard'	'A0' 'A1' 'A2' 'A3' 'A4' 'A5' 'E+ (36")' 'B1 (707 mm)' 'B2 (19.69 in)' Scales the image to fit the selected media size.    <b>Note:</b> Depend on the media series you defined in the Océ Express WebTools


Setting	Settings values	Function
	'Custom'	210 to 914 mm The width of the original is a custom size. 

### Settings group: 'Media'


Setting	Settings values	Function
'Roll selection'	'Auto' 'Roll 1' (description of media type and media size loaded on roll 1) 'Roll 2' (description of media type and media size loaded on roll 2)	Define the media feed to copy or print on. When you select 'Auto' the printer automatically selects the media roll. 

### Settings group: 'Scale'


Setting	Settings values	Function
'1:1'		Scales to 100%.
'To fit'	'A0' 'A1' 'A2' 'A3' 'A4' 'E+ (36")' 'B1 (707 mm)' 'B2 (19.69 in)'	Scales the image to fit the selected media size.    <b>Note:</b> Depend on the media series you defined in the Océ Express WebTools



Setting	Settings values	Function
'Custom'	10 - 1000 '%'	<p>Scales the image to a custom percentage.</p> 

### Settings group: 'Finishing'



Setting	Settings values	Function
'Output'	'Lower tray' 'Top Delivery Tray'	<p>The location to deposit the sheet.</p>  <p><i>i</i> <b>Note:</b> Not all media types can be delivered to the 'Top Delivery Tray'.</p>


### Settings group: 'Sheet size'

Setting	Settings values	Function
'Cut method'	'Synchro' 'Standard'	<p>'Determines the cut size of the print. 'Standard': the print is cut to a standard media size (DIN, ANSI, ...). 'Synchro': the print length depends on the image.'</p> 




Setting	Settings values	Function
'Top'	0 to 400 mm	Adds a blank strip at the beginning of the output. 
'Bottom'	0 to 400 mm	Adds a blank strip at the bottom of the output. 

### Settings group: 'Positioning'

Setting	Settings values	Function
'Alignment'	'Top left' 'Top' 'Top right' 'Left' 'Center' 'Right' 'Bottom left' 'Bottom' 'Bottom right'	'Aligns the image on the media.' 
'Shift horizontal'	- 914 mm to + 914 mm	'Shifts the image in the horizontal direction (after alignment to one of the positions given in 'Alignment').' 


Setting	Settings values	Function
'Shift vertical'	- 1219 mm to + 1219 mm	'Shifts the image in the vertical direction (after alignment to one of positions given in 'Alignment').' 

**Settings group: 'Remove strip'**

Setting	Settings values	Function
'Top'	0 to 400 mm	'Erase a strip from the beginning of the original.' 
'Bottom'	0 to 400 mm	'Erase a strip from the bottom of the original.' 
'Left'	0 to 400 mm	'Erase a strip from the left side of the original.' 







Setting	Settings values	Function
'Right'	0 to 400 mm	'Erase a strip from the right side of the original.'







### Settings group: 'Erase area'


Setting	Settings values	Function
'Hor offset'	0 to 914 mm	'The horizontal offset where the erase area starts.'
'Vert offset'	0 to 6000 mm	'The vertical offset where the erase area starts.'
'Width'	0 to 914 mm	'The width of the area to erase.'
'Length'	0 to 6000 mm	'The length of the area to erase.'


**Settings group: 'Stamp'**

Setting	Settings values	Function
'Stamp'	'None' 'Date/time' 'Confidential' 'Draft' 'Copy' 'For review' 'Stamp6' ... 'Stamp12'	Copy with a stamp 
'Position'	'Top' 'Middle' 'Bottom'	'The position of the stamp inside the legend.' 
'Size'	'Small' 'Large'	'The size of the stamp.' 
'Color'	'Light gray' 'Gray' 'Dark gray' 'Black'	'The color of the stamp.' 


### Settings group: 'Drawing method'

Setting	Settings values	Function
'Method'	'DIN' 'Afnor' 'Ericsson'	Defines which drawing method is used for the legend position.   The icon shows the word 'Afnor' in a bold, sans-serif font above three horizontal yellow bars of varying lengths.
'Legend'	'Top' 'Bottom'	'Defines whether the legend is located at the top (leading) or the bottom (trailing).'

### Settings group: 'Light and mirror'

Setting	Settings values	Function
'Lighter/darker'	-5 to +5	Increase the value for lighter prints; decrease for darker prints.   A simple icon of a lit lightbulb with a yellow glow and a blue base.
'Mirror'	'On' 'Off'	'When 'on', the image is mirrored along the vertical axis (the media transport direction).'

### Settings group: 'Sort'

Setting	Settings values	Function
'Sort'	'By page' 'By set'	If you want to copy multiple sheets, you can indicate how the copied sheets must be sorted. 

# Make multiple sets of copies

## Introduction

You can use the 'Create set' option to make multiple sets of copies.

## Before you begin

If you must enter the same value for a setting very often, you can set this value as the default value for that setting in the Océ Express WebTools.

After you press the start key, the user panel always shows the job number and status of the job. A copy job appears temporarily in the 'Jobs - Queue' section of the Océ Express WebTools, a scan job appears in the Smart Inbox 'Scans'.

## How to make multiple sets of copies sorted by set

1. Feed the original face up and centered on the original feeding table.



### Note:

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.

The 'Copy' tab is automatically activated on the user panel.

2. Open the 'Copy' tab with the confirmation button above the scroll wheel.
3. Define the job settings.



- Open a template with the confirmation button.  
The 'Create set' option appears at the lower left corner of the screen.
- Select 'Create set' with the lower left soft key.  
The 'Close set' option appears at the lower left corner of the screen.
- Scroll to 'Sort', define 'By set' and confirm with the with confirmation button. This setting is disabled after you press the start button for the first time.
- Press 'OK'.
- Change the settings for your first original if necessary.
- Define the number of copies and press the start button.  
You can not change the number of copies after you press the start button for the first time.

- Feed the next original, define the settings for this original if necessary and press the start button.  
You can use the lower right soft key to return to the default settings of your copy template.  
Repeat this step until all originals are fed.
4. Select 'Close set' with the lower left soft key.

## How to make multiple sets of copies sorted by page

1. Feed the first original face up.  
The scanner takes the original.
2. Open the 'Copy' tab with the confirmation button above the scroll wheel.
3. Define the job settings.



- Open a template with the confirmation button.  
The 'Create set' option appears at the lower left corner of the screen.
  - Select 'Create set' with the lower left soft key.  
The 'Close set' option appears at the lower left corner of the screen.
  - Scroll to 'Sort', define 'By page' and confirm with the with confirmation button. This setting is disabled after you press the start button for the first time.
  - Press 'OK'.
  - Change the settings for your first original if necessary.
  - Define the number of copies and press the start button.  
You can not change the number of copies after you press the start button for the first time.
  - Feed the next original, define the settings for this original if necessary and press the start button.  
You can use the lower right soft key to return to the default settings of your copy template.  
Repeat this step until all originals are fed.
4. Select 'Close set' with the lower left soft key.

## Result

The Océ ColorWave 300 copies a set of originals sorted by set or by page.

# Make a copy with a stamp

## Introduction

A stamp is a pre-defined text you can set on every copy.

## Before you begin

If you must enter the same value for a setting very often, you can set this value as the default value for that setting in the Océ Express WebTools.

After you press the start key, the user panel always shows the job number and status of the job. A copy job appears temporarily in the 'Jobs - Queue' section of the Océ Express WebTools, a scan job appears in the Smart Inbox 'Scans'.

## How to make a copy with a stamp

1. Feed the original face up and centered on the original feeding table.




### Note:

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.

The 'Copy' tab is automatically activated on the user panel.

2. Open the 'Copy' tab with the confirmation button above the scroll wheel.
3. Define the job settings.



- Open a template with the confirmation button.
  - Scroll to 'Stamp' and open this setting with the confirmation button.
  - Scroll to 'Stamp', select a stamp with the scroll wheel and confirm.
  - Scroll to 'Position', select the correct position with the scroll wheel and confirm.
  - Scroll to 'Size', select the correct size with the scroll wheel and confirm.
  - Scroll to 'Color', select the correct color with the scroll wheel and confirm.
4. Define the number of copies and press the start button.

## Result

The copy contains the selected stamp.

## Scale to another media size

### Introduction

You can use the 'Scale' setting to copy to a larger or smaller media format. Use one of the following methods to scale a copy.

- Select another media format with the 'To fit' setting.
- Adjust a value in terms of percentage with the 'Custom' setting.  
You can adjust a value between 25 and 400%. A value lower than 100% reduces the copy, a value greater than 100% enlarges the copy.

### Before you begin

If you must enter the same value for a setting very often, you can set this value as the default value for that setting in the Océ Express WebTools.

After you press the start key, the user panel always shows the job number and status of the job. A copy job appears temporarily in the 'Jobs - Queue' section of the Océ Express WebTools, a scan job appears in the Smart Inbox 'Scans'.

### How to copy to another media size

1. Feed the original face up and centered on the original feeding table.



#### Note:

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.

The 'Copy' tab is automatically activated on the user panel.

2. Open the 'Copy' tab with the confirmation button above the scroll wheel.
3. Define the job settings.



- Open a template with the confirmation button.
  - Scroll to 'Scale' and open this setting with the confirmation button.
  - Scroll to 'To fit', select a standard media format from the media series you use and confirm.
4. Define the number of copies and press the start button.



## Result

The Océ ColorWave 300 copies to another media size.

## Make a copy and add a strip

### Introduction

You can use a strip to file a drawing.

Use 'Sheet size' to copy an original without a strip and add a strip to the copy. You can add a strip at the top or bottom side of a copy.

Use 'Remove strip' to copy an original with a strip and remove the strip from the copy. You can erase a margin from the top, the bottom, the left or the right side of the original.

### Before you begin

If you must enter the same value for a setting very often, you can set this value as the default value for that setting in the Océ Express WebTools.

After you press the start key, the user panel always shows the job number and status of the job. A copy job appears temporarily in the 'Jobs - Queue' section of the Océ Express WebTools, a scan job appears in the Smart Inbox 'Scans'.

### How to make a copy and add a strip

1. Feed the original face up and centered on the original feeding table.




**Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.

The 'Copy' tab is automatically activated on the user panel.

2. Open the 'Copy' tab with the confirmation button above the scroll wheel.
3. Define the job settings.



- Open a template with the confirmation button.
  - Scroll to 'Sheet size' and open this setting with the confirmation button.
  - Scroll to 'Top' or 'Bottom', define the value with the scroll wheel or numeric keys and confirm.
4. Define the number of copies and press the start button.

## Result

The Océ ColorWave 300 adds a trailing or leading strip to the copy.

## Make a copy and erase a margin

### Introduction

You can use a strip to file a drawing.

Use 'Sheet size' to copy an original without a strip and add a strip to the copy. You can add a strip at the top or bottom side of a copy.

Use 'Remove strip' to copy an original with a strip and remove the strip from the copy. You can erase a margin from the top, the bottom, the left or the right side of the original.

### Before you begin

If you must enter the same value for a setting very often, you can set this value as the default value for that setting in the Océ Express WebTools.

After you press the start key, the user panel always shows the job number and status of the job. A copy job appears temporarily in the 'Jobs - Queue' section of the Océ Express WebTools, a scan job appears in the Smart Inbox 'Scans'.



#### **Caution:**

When you erase a margin, make sure that you copied all the required information.

---

### How to make a copy and erase a margin (a strip)

1. Feed the original face up and centered on the original feeding table.




#### **Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.

The 'Copy' tab is automatically activated on the user panel.

2. Open the 'Copy' tab with the confirmation button above the scroll wheel.
3. Define the job settings.



The 'Top' margin	The 'Bottom' margin	The 'Left' margin	The 'Right' margin
------------------	---------------------	-------------------	--------------------

- Open a template with the confirmation button.
  - Scroll to 'Remove strip' and open this setting with the confirmation button.
  - Scroll to 'Top', 'Bottom', 'Left' or 'Right', define the value with the scroll wheel or numeric keys and confirm.
4. Define the number of copies and press the start button.

## Result

The Océ ColorWave 300 copies the original without a strip. You can also use this setting to copy a specific area of the original. (see [Make a copy of a specific area of an original](#) on page 206).

## Make a copy of a specific area of an original

### Introduction

You can make a copy of a specific area of an original with the 'Remove strip' setting. Define the following margins to specify the area.

- 'Top'
- 'Bottom'
- 'Left'
- 'Right'

### Before you begin

If you must enter the same value for a setting very often, you can set this value as the default value for that setting in the Océ Express WebTools.

After you press the start key, the user panel always shows the job number and status of the job. A copy job appears temporarily in the 'Jobs - Queue' section of the Océ Express WebTools, a scan job appears in the Smart Inbox 'Scans'.



#### **Caution:**

When you erase a margin, make sure that you copied all the required information.

---

### How to copy a specific area of an original

1. Feed the original face up and centered on the original feeding table.




#### **Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.

The 'Copy' tab is automatically activated on the user panel.

2. Open the 'Copy' tab with the confirmation button above the scroll wheel.
3. Define the job settings.



The 'Top' margin	The 'Bottom' margin	The 'Left' margin	The 'Right' margin
------------------	---------------------	-------------------	--------------------

- Open a template with the confirmation button.
  - Scroll to 'Remove strip' and open this setting with the confirmation button.
  - Scroll to 'Top', define the value with the scroll wheel or numeric keys and confirm.
  - Scroll to 'Bottom', define the value with the scroll wheel or numeric keys and confirm.
  - Scroll to 'Left', define the value with the scroll wheel or numeric keys and confirm.
  - Scroll to 'Right', define the value with the scroll wheel or numeric keys and confirm.
  - Press 'OK'
  - Scroll to 'Positioning' and open this setting with the confirmation button.
  - Scroll to 'Alignment', select 'Center' with the scroll wheel and confirm.
4. Define the number of copies and press the start button.



**Note:**

You can use the 'Alignment' 'Shift horizontal' and 'Shift vertical' to adjust the defined position of the specified area.

**Result**

The Océ ColorWave 300 copies a specific area of the original to the specified position on the copy.

## Make a copy and erase a specific area of an original

### Introduction

You can make a copy without a specific area of an original with the 'Erase area' setting. You can use 2 settings to define the dimensions of the delete area and you can use 2 settings to define the relative position of the delete area on the sheet.

Define the relative position of the 'Erase area' with the following settings:

- 'Hor offset': Horizontal offset where the delete area starts.
- 'Vert offset': Vertical offset where the delete area starts.

Define the dimensions of the delete area:

- 'Width'
- 'Length'

### Before you begin

If you must enter the same value for a setting very often, you can set this value as the default value for that setting in the Océ Express WebTools.

After you press the start key, the user panel always shows the job number and status of the job. A copy job appears temporarily in the 'Jobs - Queue' section of the Océ Express WebTools, a scan job appears in the Smart Inbox 'Scans'.



#### **Caution:**

When you copy without a specific area, make sure that you copied all the required information.

---

### How to copy without a specific area of an original

1. Feed the original face up and centered on the original feeding table.







#### **Note:**

You do not need to center the original precisely. The exact position of the original is automatically detected by the scanner.

The 'Copy' tab is automatically activated on the user panel.

2. Open the 'Copy' tab with the confirmation button above the scroll wheel.
3. Define the job settings.



			
The 'Hor offset'	The 'Vert offset'	The 'Width'	The 'Length'

- Open a template with the confirmation button.
  - Scroll to 'Erase area' and open this setting with the confirmation button.
  - Scroll to 'Hor offset', define the value with the scroll wheel or numeric keys and confirm.
  - Scroll to 'Vert offset', define the value with the scroll wheel or numeric keys and confirm.
  - Scroll to 'Width', define the value with the scroll wheel or numeric keys and confirm.
  - Scroll to 'Length', define the value with the scroll wheel or numeric keys and confirm.
  - Press 'OK'
4. Define the number of copies and press the start button.

## Result

The Océ ColorWave 300 copies an original without the specified area.

# Send print jobs

## What you need to know before you send your print jobs

### Definition

Before you send print jobs to the Océ ColorWave 300, remember the following.


- The values defined in the Océ Express WebTools are default values for the general system behavior. You can define a number of job settings in the Océ printer drivers or the Océ job submission tools. The settings defined in the printer drivers or the job submission tools always overrule the settings defined in the Océ Express WebTools.
- Make sure that you define and load the correct media for your job.
- Make sure that you define the correct job settings. For example, orientation, rotation, and media type.

## Use Océ Publisher Express to send a print job

### Introduction



Océ Publisher Express is a job submitter that is integrated in the Océ Express WebTools.

### Illustration



### How to use Océ Publisher Express to send a print job

Step	Action	Remarks
1	Open your web browser.	Use one of the following web browsers <ul style="list-style-type: none"> <li>■ Microsoft® Internet Explorer 7 (or higher)</li> <li>■ Mozilla Firefox™ 2.0 (or higher)</li> </ul>
2	Enter the URL <b>http://'printer name'</b> or IP address in your workstation browser to connect to the Océ Express WebTools.	'Printer name' is the name of your Océ ColorWave 300 printer.

Step	Action	Remarks
3	Open the 'Jobs' tab,	<p>This tab displays the following.</p> <ul style="list-style-type: none"> <li>■ The Océ Publisher Express section.</li> <li>■ An overview of all jobs that are currently available in the 'Jobs - Queue'.</li> <li>■ An overview of all the Smart Inboxes that currently contain on or more jobs.</li> </ul>
4	Click on 'Create new job' in the Océ Publisher Express section.	A separate window opens.
5	<p>Click on 'Add file' and use the <b>Browse...</b> button to select the file you want to print.</p> <p> <b>Note:</b> If the Top Delivery Tray is used and you add multiple files in one job: Add the files in reverse order (e.g. file<sub>3</sub>, file<sub>2</sub>, file<sub>1</sub> instead of file<sub>1</sub>, file<sub>2</sub> and file<sub>3</sub>). This to prevent you from having to re-order the printed files.</p> <p> <b>Note:</b> In case the file is generated with the Océ Windows® Printer Driver these settings prefer over the Océ Publisher Express job settings.</p>	<p>You can print documents with the following data formats</p> <ul style="list-style-type: none"> <li>■ - HP-GL - .hp, .hpg, .hpgl</li> <li>■ - HP-GL/2 - .hp2</li> <li>■ - HP RTL - .rtl</li> <li>■ - CALS - .cls, .cal</li> <li>■ - NIRS - .nir, .nif</li> <li>■ - CalComp - .cc, .906, .907, .951, .crf, .pci</li> <li>■ - Edmics (C4) - .c4</li> <li>■ - TIFF - .tif</li> <li>■ - PostScript 3 - .ps (optional)</li> <li>■ - PDF - .pdf (optional)</li> <li>■ - JPEG - .jpg, .jpeg</li> <li>■ - DWF, DWF/X</li> </ul>
6	Change the 'Settings' and the 'Preset' if necessary.	Job settings that you change in Océ Publisher Express always overrule the default settings defined in the Océ Express WebTools.

Step	Action	Remarks
7	In the 'Workflow' section enter the name of the Smart Inbox you want to print to and click 'Ok' to send the print job to the Smart Inbox.	You can easily create a new Smart Inbox if you enter a new Smart Inbox name.

## Use the Océ Windows® Printer Driver to send a print job

### Introduction

Océ provides the Océ Windows® Printer Driver that allows you to send print jobs to your Océ ColorWave 300. This driver is a mixed raster-vector HP-GL/2 printer driver that allows you to print from any application under Windows XP®, Windows Vista® or Windows Server® 2003 to your Océ printer.



**Note:**

More information about how to install, configure and use the driver is available in the documentation provided with the Océ Windows® Printer Driver.


- the Océ Windows® Printer Driver Online Help
- the Océ Windows® Printer Driver User manual



**Note:**

The Océ ColorWave 300 is delivered with a driver pack CD-ROM. You can also download the latest Océ drivers, free of charge, from our Web site [www.oce.com](http://www.oce.com).

## Illustration



## How to use the Océ Windows® Printer Driver to send a print job

Step	Action	Remarks
1	Open the file that you want to print in the source application.	AutoCAD® 2000 or any other Windows application
2	From the 'File' menu of the application, click 'Print'.	
3	Select the Océ ColorWave 300 in the 'Printer' area of the 'Print' dialog box.	
4	Click 'Properties'.	
5	Check all tabs in the driver and change the settings for this job if necessary.	
6	Click 'OK' to send the print job to the print queue.	

# Use the Océ PostScript® 3 Driver to send a print job

## Introduction

Océ provides the Océ PostScript® 3 Driver that allows you to send print jobs to your Océ ColorWave 300.



**Note:**

You need a license to be able to print PostScript® files on the Océ ColorWave 300.




**Note:**

More information about how to install, configure and use the driver is available in the documentation provided with the Océ PostScript® 3 Driver.

- the Océ PostScript® 3 Driver Online Help
- the Océ PostScript® 3 Driver Installation manual

## Illustration



## How to use the Océ PostScript® 3 Driver to send a print job

Step	Action	Remarks
1	Open the file that you want to print in the source application.	



---

Step	Action	Remarks
2	From the 'File' menu of the application, click 'Print'.	
3	Select the Océ ColorWave 300 in the 'Printer' area of the 'Print' dialog box.	
4	Click 'Properties'.	You can define the default print job settings in the Océ Express WebTools.
5	Activate the Océ Job Ticket to overrule the default values for the job settings.	
6	Check and change the Printer Features settings if necessary.	
7	Click 'OK' to send the print job to the print queue.	

## Use FTP to send a print job to the Océ ColorWave 300

### Introduction

The Océ ColorWave 300 supports printing through FTP (URL: **ftp://<hostname or IP address> /jobs**).

If you send your print job through FTP the default Océ Express WebTools settings are leading.

### How to send a print job via FTP

You can print the files through FTP in the following ways.

- Via a command line prompt
- Enter the address **ftp://<hostname or IP address> /jobs** in for example Windows Explorer.
- Via an FTP application
- From a Web browser

The Océ ColorWave 300 has a dedicated FTP Jobs folder. You cannot delete or change this folder. It is created at installation and protected.

The most convenient way to print files through FTP is to drag and drop the files or to copy and paste the files, into this 'Jobs' folder on the FTP site of your Océ ColorWave 300 controller. The documents in the folder are printed on the Océ ColorWave 300.

### Web browsers that support job submission through FTP

Level of functionality	Web browser	Operation
Supports drag and drop of files	Microsoft® Internet Explorer 7 (or higher) Mozilla Firefox™ 2.0 (or higher)	Drag the jobs into the 'Jobs' folder on the FTP site of your Océ ColorWave 300.
Supports copy and paste of files.	Microsoft® Internet Explorer 7 (or higher) Mozilla Firefox™ 2.0 (or higher)	Paste the jobs into the 'Jobs' folder on the FTP site of your Océ ColorWave 300.

## Use LPR to send a print job to the Océ ColorWave 300

### Introduction

The Océ ColorWave 300 supports printing through LPR.

If you send your print job through LPR the default Océ Express WebTools settings are leading.

### How to send a print job via LPR

Type the following line command after the DOS prompt: **lpr -S** <hostname or IP address>  
**-P** <print queue name> <file name>.



*Note:*

You can use any name for <print queue name>, for example **jobs**.

## Print a job from the Smart Inbox

### How to print a job from the Smart Inbox using the Océ Express WebTools

1. Select the 'Jobs' tab in the Océ Express WebTools.
2. Select the correct Smart inbox.
3. Select the job and click 'Print'. The job is copied to the Jobs Queue.

## Print a file from a USB mass storage device or flash drive

1. Insert USB mass storage device in the USB stick interface on the user panel.
2. The system automatically selects the print tab.



**Note:**

When the first template in the Scan tab is a Scan to USB template, the system selects the Scan tab.



3. Open the print tab with the confirmation button above the scroll wheel. The content of your USB mass storage device is displayed.
4. Use the scroll wheel to browse to the file you want to print. You can select or deselect the desired file with the confirmation button.
 

You can also select multiple files:

  - Press 'Select more...'. Use the scroll wheel to browse to the desired files with scroll wheel. You can select or deselect the files with the confirmation button.
  - Press 'Select all' when you want to print all the files from a folder.



**Note:**

You can only select multiple files from one folder.

5. If necessary, you can edit the settings of your job with the lower right softkey.



**Note:**

In case multiple files are selected the setting is the same for all files.

6. Use the start button to start printing.



# **Chapter 6**

## **Ensure the best output quality**

# Introduction to how to ensure the best output quality

## Introduction

This chapter describes how to make sure you have the best quality for your scan and print jobs.

It is important to know that the quality of your output depends on both the scan quality of the scanner and the print quality of the printer.

Output quality scanner

The scanner has one method to ensure the best output quality: Calibrate the scanner. See *'Calibrate the scanner'* on page 302.

Output quality printer

- The printer offers several methods that help you to define the best print mode for your job. These methods are described in the **Define the output quality of the printer** section of this chapter.
- The printer has 3 methods that help you to identify and analyze changes in the output quality, the 'Quality check' print, the 'Tone scale area check' print, and the 'Demo print'. The **Check the output quality of the printer** section of this chapter describes these 3 methods.
- When you find problems with the output quality, the **Optimize the output quality on the printer** section of this chapter helps you to correct the problems.

To optimize the colors of your printed output, you can adjust the Color Management settings. The **Color Management** section of this chapter gives an overview of these Color Management settings.

## When to do

Only do actions to optimize the output quality based on the information supplied in the 'Check the output quality' section.

## When you are not satisfied with the printer output quality, use the following procedure

1. Make sure that you loaded and defined the **correct media type** on the printer. Use the 'Change media type' wizard to change the media type defined on the system. *'Replace / Install the media'* on page 276. Also make sure you defined the correct media type for your job.



2. Make sure you defined the **correct output mode** for your job. *'Output type, output quality and print speed'* on page 229.
3. When you have defined the correct media and the correct print mode, and you are still not satisfied with the output quality, use the wizards to achieve optimal output quality. *'Optimize the output quality on the printer'* on page 268.
4. Use the prints generated by the 'Quality check' print, the 'Tone scale area check' print and the 'Demo print' to evaluate the quality of the prints and the colors.

# Optimize the output quality of the scanner

## Calibrate the scanner

### Introduction

You can calibrate the scanner when you are not satisfied with the copy or scan quality. Use the calibration wizard on the printer user panel to calibrate the scanner.

### Before you begin

Clean the scanner before you start the calibration procedure. Dirty parts in the scanner can decrease copy and scan quality. (See '[Calibrate the scanner](#)' on page 302).



**Caution:**

Handle the calibration sheet with care.

---



**Caution:**

Do not touch the black area of the calibration sheet with your fingers.

---



**Caution:**

Before you use the calibration sheet wipe off any dust from the calibration sheet.

---

### How to calibrate the scanner

1. From the 'HOME' screen select the 'System' tab.
2. Select the 'Setup' tab.

- Use the scroll wheel to go to the 'Scanner calibration' ('Calibrate the scanner') wizard.



- Open this section with the confirmation button.
- Insert the scanner calibration sheet<sup>1</sup> as instructed in the wizard.
- Press the start button to start the scanner calibration.  
The message 'Calibrating, please wait... do not open the scanner.' appears.



**Note:**  
'Calibrating the scanner takes between 5 to 10 minutes.'



**Note:**  
<sup>1</sup> The scanner calibration sheet code number is **1060077525**.

# Define the output quality of the printer

## The quality modes

### Introduction

The Océ ColorWave 300 enables you to select the correct quality mode for your output requirements. You can define the required quality mode in the printer driver. You can define the default quality mode in the Océ Express WebTools.

### The Quality modes

Use these modes to define the output quality. You can select the following.

The output quality

Quality mode	Function
'Check'	The print speed is maximum. This quality mode is used for fast printing of (line) drawings with good output quality. For other types of jobs, like print jobs with area coverages, you can use this quality mode to check if all the information is visible on the printed output. For these print jobs the output quality is good.
'Release'	The print speed is very high. This quality mode is best for drawings, very good for images and provides a good combination of output quality and productivity. In this quality mode the printer will automatically optimize the print quality and the productivity based on the file content. Drawings will be printed twice as fast as images, resulting in optimal productivity and quality for most customers. The Océ ColorWave 300 further offers <b>Dynamic switching Technology</b> . In case a print job has mixed contents (drawings and images), the printer will adjust the print quality and the productivity automatically during the print process, without customer intervention.
'Presentation'	Select this quality mode if you need the best possible output quality. Especially for images, posters. The print speed is high.

## Output type, output quality and print speed

### Introduction

The type of your printed output depends on the following parameter.

- The color mode ('Grayscale' / 'Color')

The quality of your printed output depends on the following parameters.

- The media type
- The quality mode
- The print speed
  - The lower the print speed, the better the output quality.

The following table describes the relation between these parameters.

### The relation between the output type and the quality parameters

The relation between the output quality parameters


Color mode	Quality mode	Print speed for all media (per A0 (E-size), not including the drying time and the processing time) (minutes' seconds'')
'Grayscale'	'Check'	0' 41''
	'Release'	Between 1' 00'' and 3' 40'', dependant on file content (the printer automatically optimizes between print quality and productivity).
	'Presentation'	3' 40''
'Color'	'Check'	1' 03''
	'Release'	Between 3' 05'' and 6' 15'', dependant on file content (the printer automatically optimizes between print quality and productivity).
	'Presentation'	9' 15''

## Recommended media types and quality modes

### Introduction

The selection of the media and the quality modes depends on the application of the output. The tables give you an idea of which media type and quality modes to use in a work process.


### 2D CAD monochrome drawing



[190] Example 2D CAD monochrome drawing  
CAD drawings - Grayscale

When to use	Recommended media type	Recommended Quality mode
To check or release a drawing	'Paper 70-80g' 'Paper 56g' 'Paper Japan 64g' 'Paper 90g' 'Paper 20 lb' 'Recycled paper 20 lb' 'Paper 24 lb' 'Recycled paper 70-80g' 'Transparent paper Japan'	'Grayscale' 'Check' 'Release'

## 2D CAD color drawing



[191] Example 2D CAD color drawing

2D CAD color

When to use	Recommended media type	Recommended quality mode
To check or release a drawing	'Paper 90g' 'Paper 24 lb' 'Coated paper 90-130g' 'High qual. coated paper 120-170g' 'High qual. coated paper Japan' 'Coated paper 24 lb' 'Recycled paper 70-80g' 'Recycled paper 20 lb'	'Color' 'Check' 'Release'

## 3D CAD and rendering drawing



[192] Example of 3D CAD and rendering

3D CAD and rendering - Color

When to use	Recommended media type	Recommended quality mode
To check or release a drawing	'Coated paper 90-130g' 'High qual. coated paper 120-170g' 'High qual. coated paper Japan' 'Coated paper 24 lb' 'Photo matte' 'Photo semi-matte (instant dry)' 'Photo gloss' 'Photo gloss (instant dry)'	'Color' 'Release' 'Presentation'

Business graphics drawing



[193] Example of Business graphics

Business graphics - Color

When to use	Recommended media type	Recommended quality mode
To release or present a document	'Paper 90g' 'Paper 24 lb' 'Coated paper 90-130g' 'High qual. coated paper 120-170g' 'High qual. coated paper Japan' 'Coated paper 24 lb' 'Coated paper Japan'	'Color' 'Release' 'Presentation'



## Logo and business color drawing




[194] Example of logo and business color

Logo and Business - Color

When to use	Recommended media type	Recommended quality mode
To release or present a document	'Paper 90g' 'Paper 24 lb' 'Coated paper 90-130g' 'High qual. coated paper 120-170g' 'High qual. coated paper Japan' 'Coated paper 24 lb' 'Recycled paper 70-80g' 'Recycled paper 20 lb'	'Color' 'Release' 'Presentation'

## Map drawing



[195] Example of Map - Color

Map - Color

When to use	Recommended media type	Recommended quality mode
To release or present a document	'Paper 90g' 'Paper 24 lb' 'Coated paper 90-130g' 'High qual. coated paper 120-170g' 'High qual. coated paper Japan' 'Coated paper 24 lb' 'Matte film'	'Color' 'Release' 'Presentation'

Point of sales graphics drawing



[196] Example of Point of sales graphics

Point of sales graphics - Color

When to use	Recommended media type	Recommended quality mode
To release or present a document	'Paper 90g' 'Paper 24 lb' 'Coated paper 90-130g' 'High qual. coated paper 120-170g' 'High qual. coated paper Japan' 'Coated paper 24 lb' 'Coated paper Japan'	'Color' 'Release' 'Presentation'

## Consumer graphics drawing




[197] Example of Consumer graphics

Consumer graphics - Color

When to use	Recommended media type	Recommended quality mode
To present a document	'Coated paper 90-130g' 'High qual. coated paper 120-170g' 'High qual. coated paper Japan' 'Coated paper 24 lb' 'Coated paper Japan' 'Photo gloss' 'Photo gloss (instant dry)'	'Color' 'Presentation'

## Photo realistic impression drawing



[198] Example of a photo realistic impression

Photo realistic impression - Color

When to use	Recommended media type	Recommended quality mode
To release or present a drawing	'Coated paper 90-130g' 'High qual. coated paper 120-170g' 'High qual. coated paper Japan' 'Coated paper 24 lb' 'Photo matte' 'Photo semi-matte (instant dry)' 'Photo gloss' 'Photo gloss (instant dry)'	'Color' 'Release' 'Presentation'


Photo



[199] Example of a photo  
Photos - Color

When to use	Recommended media type	Recommended quality mode
To release or a photo	'Coated paper 90-130g' 'High qual. coated paper 120-170g' 'High qual. coated paper Japan' 'Coated paper 24 lb' 'Photo matte' 'Photo semi-matte (instant dry)' 'Photo gloss' 'Photo gloss (instant dry)'	'Color' 'Release' 'Presentation'

## Mixed content drawing



[200] Example drawing with Mixed content

Mixed content - Color

When to use	Recommended media type	Recommended quality mode
To release or present a document	'Paper 90g' 'Paper 24 lb' 'Coated paper 90-130g' 'High qual. coated paper 120-170g' 'High qual. coated paper Japan' 'Coated paper 24 lb' 'Coated paper Japan'	'Color' . 'Release' 'Presentation'


# Color Management

## 'Color Management'

Path: 'Preferences' 'Print job defaults' 'Color management'

Depending on the type of file you want to print, the Océ ColorWave 300 offers different color-information conversions. You can select the 'Color Management' settings in the Océ Express WebTools, that give the best results for the color-information conversion. The tables below give an overview of the possible 'Color Management' settings per 'File type'.

### 'Color Management' settings in the Océ Express WebTools



### 'Color feel for HP-GL, HP-GL/2 and HP-RTL'

Defines the 'look and feel' of the printed colors.

Values	Description	
'Océ CAD colors'	'CAD colors' gives bright saturated colors. Suggested use: line and vector drawings.	
'Océ enhanced colors'	'Enhanced colors' gives photo-realistic colors. Suggested use: photos or graphic art presentations. You will get the most realistic result if you set the RGB input data to the international standard your original was made in. Advanced settings:	
	'RGB input data'	'sRGB' 'Adobe RGB'
	'Rendering intent'	'Perceptual (photo)' 'Saturation (business graphics)' 'Absolute colorimetric' 'Relative colorimetric'
'Simulated printers'	Select 'Simulated printers' to get a print with similar colors as the simulated printer. Options: <ul style="list-style-type: none"> <li>■ 'Simulated Océ TCS400 CAD colors'</li> <li>■ 'Simulated non-Océ printer: vivid colors'</li> <li>■ 'Simulated non-Océ printer: match screen colors'</li> <li>■ 'Simulated non-Océ printer: no color correction'</li> </ul>	
'None, managed by application'	Select 'None, managed by application' if color management is completely done by the application that generated the print file.	

### 'Color feel for TIFF and JPEG'

Defines the 'look and feel' of the printed colors.

Values	Description
'Océ CAD colors'	'CAD colors' gives bright saturated colors. Suggested use: line and vector drawings.

Values	Description	
'Océ Enhanced colors'	'Enhanced colors' gives photo-realistic colors. Suggested use: photos or graphic art presentations. You will get the most realistic result if you set the RGB input data to the international standard your original was made in. Advanced settings:	
	'RGB input data'	'sRGB' 'Adobe RGB'
	'Rendering intent'	'Perceptual (photo)' 'Saturation (business graphics)' 'Absolute colorimetric' 'Relative colorimetric'
'Simulated printers'	Select 'Simulated printers' to get a print with similar colors as the simulated printer. Options: <ul style="list-style-type: none"><li>■ 'Simulated Océ TCS400 CAD colors'</li><li>■ 'Simulated non-Océ printer: vivid colors'</li><li>■ 'Simulated non-Océ printer: match screen colors'</li><li>■ 'Simulated non-Océ printer: no color correction'</li></ul>	
'None, managed by application'	Select 'None, managed by application' if color management is completely done by the application that generated the print file.	

### 'Color feel for PostScript and PDF'

Defines the 'look and feel' of the printed colors.

Values	Description
'Océ CAD colors'	'CAD colors' gives bright saturated colors. Suggested use: line and vector drawings.



Values	Description						
'Océ Enhanced colors'	<p>'Enhanced colors' gives photo-realistic colors. Suggested use: photos or graphic art presentations. You will get the most realistic result if you set the RGB input data or CMYK input data to the international standard your original was made in.</p> <p>Advanced settings:</p>						
	<table border="1"> <tr> <td>'RGB input data'</td> <td>'sRGB' 'Adobe RGB'</td> </tr> <tr> <td>'CMYK input data'</td> <td>'Euroscale coated' 'Euroscale uncoated' 'Euroscale coated (SWOP)' 'US web uncoated'</td> </tr> <tr> <td>'Rendering intent'</td> <td>'Perceptual (photo)' 'Saturation (business graphics)' 'Absolute colorimetric' 'Relative colorimetric'</td> </tr> </table>	'RGB input data'	'sRGB' 'Adobe RGB'	'CMYK input data'	'Euroscale coated' 'Euroscale uncoated' 'Euroscale coated (SWOP)' 'US web uncoated'	'Rendering intent'	'Perceptual (photo)' 'Saturation (business graphics)' 'Absolute colorimetric' 'Relative colorimetric'
'RGB input data'	'sRGB' 'Adobe RGB'						
'CMYK input data'	'Euroscale coated' 'Euroscale uncoated' 'Euroscale coated (SWOP)' 'US web uncoated'						
'Rendering intent'	'Perceptual (photo)' 'Saturation (business graphics)' 'Absolute colorimetric' 'Relative colorimetric'						
'Simulated printers'	<p>Select 'Simulated printers' to get a print with similar colors as the simulated printer.</p> <p>Options:</p> <ul style="list-style-type: none"> <li>■ 'Simulated Océ TCS400 CAD colors'</li> <li>■ 'Simulated non-Océ printer: vivid colors'</li> <li>■ 'Simulated non-Océ printer: match screen colors'</li> <li>■ 'Simulated non-Océ printer: no color correction'</li> </ul>						
'None, managed by application'	Select 'None, managed by application' if color management is completely done by the application that generated the print file.						

### 'Color feel for DWF'

Defines the 'look and feel' of the printed colors.

Values	Description
'Océ CAD colors'	'CAD colors' gives bright saturated colors. Suggested use: line and vector drawings.

Values	Description
'Océ Enhanced colors'	'Enhanced colors' gives photo-realistic colors. Suggested use: photos or graphic art presentations. You will get the most realistic result if you set the RGB input data to the international standard your original was made in. Advanced settings:
	'RGB input data' 'sRGB' 'Adobe RGB'
	'Rendering intent' 'Perceptual (photo)' 'Saturation (business graphics)' 'Absolute colorimetric' 'Relative colorimetric'
'Simulated printers'	Select 'Simulated printers' to get a print with similar colors as the simulated printer. Options: <ul style="list-style-type: none"><li>■ 'Simulated Océ TCS400 CAD colors'</li><li>■ 'Simulated non-Océ printer: vivid colors'</li><li>■ 'Simulated non-Océ printer: match screen colors'</li><li>■ 'Simulated non-Océ printer: no color correction'</li></ul>
'None, managed by application'	Select 'None, managed by application' if color management is completely done by the application that generated the print file.

## 'Color feel'

One of the options you have to finetune your output quality is to adjust the 'Color Management' settings.

With the 'Color Management' setting 'Color feel' you can finetune the **look and feel** of the printed colors.

Overview of the 'Color feel' settings.

'Color feel' settings	Description
'Océ CAD colors'	This setting gives bright saturated colors. Advised for: line and vector drawings.
'Océ enhanced colors'	This setting gives photo-realistic colors. Advised for: photos or graphic art presentations. If you select 'Océ enhanced colors' you can also adjust the advanced Color Management settings. <ul style="list-style-type: none"> <li>■ 'Enhanced colors: RGB input data'</li> <li>■ 'Enhanced colors: CMYK input data' (only for 'File type''PostScript® , PDF')</li> <li>■ 'Enhanced colors: Rendering intent'</li> </ul>
'Simulated Océ TCS400 CAD colors'	Use this setting to get a print with colors similar to the Océ TCS400 printer.
'Simulated non-Océ printer: vivid colors'*	Use this setting to get a print with colors similar to a non-Océ printer, that prints vivid colors.
'Simulated non-Océ printer: match screen colors'*	Use this setting to get a print with colors similar to a non-Océ printer, that prints match screen colors.
'Simulated non-Océ printer: no color correction'	Use this setting to get a print with colors similar to a non-Océ printer, that prints without color correction.
'None, managed by application'	Use this setting if your color management is completely done by the application that generated the print file.

## Océ 'Enhanced colors: RGB input data'

One of the options you have to finetune your output quality is to adjust the 'Color Management' settings.

If the 'Color Management' setting 'Color feel' is set to 'Océ enhanced colors' you can define the Océ 'Enhanced colors: RGB input data' setting. This setting specifies the source color space for printing RGB images, objects and text and allows the Océ ColorWave 300 to select the best conversion from the source's RGB-colour space to the printer's CMYK colors (color mapping).

Overview of the 'Enhanced colors: RGB input data' settings.

Océ 'Enhanced colors: RGB input data'	Description
'sRGB'	This setting specifies the source space of a generic computer monitor.
'Adobe RGB'	This setting specifies an RGB color space developed by Adobe in 1998.

## Océ 'Enhanced colors: CMYK input data'

One of the options you have to finetune your output quality is to adjust the 'Color Management' settings.

If the 'Color Management' setting 'Color feel' is set to 'Océ enhanced colors' you can define the Océ 'Enhanced colors: CMYK input data' setting. This setting simulates printing to an offset press standard.

Overview of the 'Enhanced colors: CMYK input data' settings.

Océ 'Enhanced colors: CMYK input data'	Description
'Euroscale coated'	This setting uses an offset press standard often used in Europe for printing separations and proofs on coated media.
'Euroscale uncoated'	This setting uses an offset press standard often used in Europe for printing separations and proofs on uncoated media.
'US web coated (SWOP)'	This setting uses an offset press standard often used in the US for printing separations and proofs on coated media.
'US web uncoated'	This setting uses an offset press standard often used in the US for printing separations and proofs on uncoated media.



**Note:**


In most cases the default setting as defined in the Océ Express WebTools gives the best result ('Euroscale coated' for Europe and Asia, 'US web coated (SWOP)' for the USA).


## Océ 'Enhanced colors: Rendering intent'

One of the options you have to finetune your output quality is to adjust the 'Color Management' settings.

If the 'Color Management' setting 'Color feel' is set to 'Océ enhanced colors' you can define the Océ 'Enhanced colors: Rendering intent' setting. Use this setting if the color space that your print file was made in does not fully comply with the color space of the printer (color conversion).

Overview of the Océ 'Enhanced colors: Rendering intent' settings.

'Enhanced colors: Rendering intent'	Description
'Perceptual (photo)'	This setting optimizes the output to produce best results for photographic or scanned images.
'Saturation (business graphics)'	This setting optimizes the output of bright, saturated colors.
'Absolute colorimetric'	This setting provides the highest accuracy in rendering RGB colors into CMYK colors, including rendering the source's white.   <b>Note:</b> The slightly bluish cast of the monitor background might be noticeable as bluish white in the lightest tones of the printed output. A slight yellow tone can occur in the white tones of a PDF/TIFF original or an HP-GL type document.

'Enhanced colors: Rendering intent'	Description
'Relative colorimetric'	<p>This setting provides a high accuracy in rendering RGB colors into CMYK colors, but maps the source's white to the media's white point, so that any monitor background color cast is eliminated. Though the printed output will be colorful, this setting may lead to a loss of contrast in the dark areas. This setting is advised for business graphics when 'Saturation (business graphics)' does not give the required result.</p> <p> <b>Note:</b> If you generate a color scan-to-file job in TIFF format on an Océ TCS400, an Océ TCS500 or an Océ TDS450, 'Perceptual (photo)' gives the best result.</p>

**Note:**

It is advised to use the default setting ('Perceptual (photo)') as specified in the Océ Express WebTools or 'Relative colorimetric' to get the best overall result.

# Media

## What is a media profile?

### Definition

A media profile is also called an Océ Media Profile (OMP file). The media profile contains a number of preset values that give the best print result per media type for your system. By default the system already has a number of media profiles available after installation, but due to changes in the production methods for media, the profiles can also change over time. When a new version is available you can retrieve the new profile from the corporate web site.

### Attributes

For each media type the media profile optimizes a number of settings.

- Mixing of colors (Cannot be modified).
- Amount of ink applied on the media (Cannot be modified).
- Drying time correction.
- Cut length correction.

### Example

When you download a media profile from the corporate web site the file name can consist of the following information.

<Product name> <media name><version number><media code and version><file extension>

ColorWave300\_Paper\_1.3(IJMo20\_Version01).omp



## Manage media

### About manage the media

The 'Support' - 'Media' tab in the Océ Express WebTools allows you to manage the media that are active on your system.

You can use the 'Support' - 'Media' tab to perform the following tasks.

- Check the current media settings.
- Check the media settings of a single media.
- Edit and save the media dependent settings.

### Check the current media settings

Click 'Support' - 'Media' to view the current 'media type' settings.

You can view the following settings:

- 'Category'  
Four categories of media: 'Paper', 'Coated paper', 'Photopaper' and 'Films and transparencies' are defined for the Océ ColorWave 300.
- 'Media type'  
'Media type' is the media name on the user interface.
- 'Media label'  
'Media label' is the name of the media on the media box.



**Note:**

The supported 'media types' and 'media labels' for the Océ ColorWave 300 are listed on ['Preferred Océ media names'](#) on page 355.

### Check the media settings of a single media

Media settings of a single media

Step	Action
1	Click 'Support' - 'Media' to view the current 'media type' settings.

Step	Action
2	Click the name of the 'Media type' to access a secondary window with the following detailed information: <ul style="list-style-type: none"><li>■ 'Category'</li><li>■ 'Media type'</li><li>■ 'Media label'</li><li>■ 'File name'</li><li>■ 'Version'</li><li>■ 'Install date'</li><li>■ 'Drying time correction'</li><li>■ 'Cut length correction'</li></ul>

### Edit and save the media dependent settings

Edit and save media dependent settings

Step	Action
1	Click 'Support' - 'Media' to view the current 'media type' settings.
2	Click the check box of the 'Media type' you want to edit.
3	Click the 'Edit' button.
4	The following options are available: <ul style="list-style-type: none"><li>■ 'Media label' Correct the label of the media.</li><li>■ 'OMP' file: Update the Océ Media Profile. Note: If an older version of the file was active, this file will be overwritten by the new file.</li><li>■ 'Drying time correction' Correct the drying time of the media.</li><li>■ 'Cut length correction' Correct the cut length of the media.</li></ul>

## Download and install a media profile

### Introduction

The Océ Express WebTools offers an option to download and install a Océ media profile (omp) file for a specific media type.

You can find these settings in the 'Support' - 'Media' tab.

### When to do

When a new media profile is available or an existing media profile needs to be updated you can retrieve the required media profile from the corporate web site.



**Note:**

Log on as system administrator or power user

### How to download a media profile

This example shows the download and installation of the omp file for IJM222 Top Photo Plus Gloss.

1. Select the 'Support' - 'Media' tab in the Océ Express WebTools.
2. Visit <http://mediaguide.oce.com>.
3. Click 'Continue' in the Wide format printer section.
4. Select Océ ColorWave 300 in the Printer name section and click 'Continue'.
5. Select one, more or all media types and click 'Continue'.
6. Click on the icon in the 'Profiles' column (rightmost) of the IJM222 Top Photo Plus Gloss media.
7. Select one of the media profiles and click 'Download'.  
The file 'ColorWave300\_789\_00\_IJM222\_PLC222\_010.zip' is downloaded to a location on your workstation.
8. Close the window.
9. Unzip the file. The omp file 'ColorWave300\_PhotoGloss\_3.IJM222-v090415.omp' is extracted.
10. Select the media 'Photopaper', 'Photo gloss', 'IJM222, IPG-ZA: Océ Top Photo Plus Gloss; GIPPLS7: Océ Glossy Photo Paper
11. Select 'Edit'.
12. Select update file.  
Browse to the downloaded omp file and select this file.
13. If required you can adapt the 'Drying time correction' and the 'Cut length correction'
14. Click on 'OK'.

15. The new media dependent data (omp file) is activated after the next restart.
16. Restart the system.

## Result

After the restart of the system the new media profile is activated.

# Input profiles

## What is an input profile?

### Definition

An input profile is also called an Océ Input Profile (OIP file).

The input profile changes the output of the printer to match the output of a simulated printer (For example: 'Simulated Océ TCS400 CAD colors' ) on a certain media type and print mode as much as possible. The input profiles are used for color management of simulated printers.

By default the system already has a number of input profiles available after installation. When a new version is available you can retrieve the new profile from the corporate web site.

### Attributes

An input profile contains the following information:

- Color management profiles for the simulated printer
- Media type
- Print mode

## Manage input profiles

### About manage the media

The 'Support' - 'Input Profiles' tab in the Océ Express WebTools allows you to manage the input profiles that are active on your system.

You can use the 'Support' - 'Input Profiles' tab to perform the following tasks.

- Check the current input profiles.
- Activate an input profile.
- Install a new input profile.

### Check the current input profiles

Click 'Support' - 'Input Profiles' to view the current 'media type' settings.


You get an overview of the current input profiles.

Each input profile contains the following information:

- 'Type of media': uncoated, coated or gloss media.
- 'Media code': media number (for example ijm...).
- 'Print mode': normal or best mode.
- 'Source': Pre-installed or Custom.
- 'Description': Name of the input profile with the simulated media type and print mode.
- 'Status': One of the input profiles can be activated.

### Activate an input profile

Activate an input profile

Step	Action
1	Click 'Support' - 'Input Profiles' to view the current installed 'Input Profiles'.
2	Click the check box of the input profile you want to activate.
3	Click the 'Enable' button.
4	The status of the selected input profile' is changed to 'Active'.   <b>Note:</b> The new input profile is activated after the next restart.

---

## Install a new input profile

Install a new input profile

Step	Action
1	Click 'Support' - 'Input Profiles' to view the current installed 'Input Profiles'.
3	Click the 'Install' button.
4	Browse to the location of the new input profile. Select the input profile. Click on the 'OK' button.

# Check the output quality of the printer

## 'Demo print'

### Introduction

You can make a demo print to get an impression of the print capabilities of the Océ ColorWave 300.

The Océ ColorWave 300 has 4 demo prints:


- '2D CAD monochrome'
- '2D CAD color'
- 'Mixed content'
- 'Consumer graphics'

Use the 'Test prints' ('Print a demo or test image') wizard on the printer user panel to select one of the demo prints.

### How to make a demo print

The system prints the 'Demo print' in the 'Release' quality mode. The demo print takes several minutes to print. You are recommended to use 'Coated paper 90-130g' for the 'Demo print'.

1. From the 'HOME' screen select the 'System' tab.
2. Select the 'Setup' tab.
3. Use the scroll wheel to go to the 'Test prints' ('Print a demo or test image') wizard.



4. Open this section with the confirmation button.
5. Use the scroll wheel to select one of the 4 demo prints:
  - '2D CAD monochrome'
  - '2D CAD color'



- 'Mixed content'
- 'Consumer graphics'

6. Press the start button.

## 'Quality check' print

### Introduction

The 'Quality check' print option is a quick method to help you find the cause of an unsatisfactory output quality. The 'Quality check' print option is especially useful to check the quality of printed lines.

Use the 'Test prints' ('Print a demo or test image') wizard on the printer user panel to trace output quality problems. *'Output quality problems' on page 263*

### How to make a quality check print

The system prints the 'Quality check' print in the 'Presentation' quality mode. The system uses a minimum of media for the 'Quality check' print. You are recommended to use 'Coated paper 90-130g' for the 'Quality check' print.

Do the following to make a 'Quality check' print.


1. From the 'HOME' screen select the 'System' tab.
2. Select the 'Setup' tab.
3. Use the scroll wheel to go to the 'Test prints' ('Print a demo or test image') wizard. Open this section with the confirmation button.
4. Use the scroll wheel to select the 'Quality check'.
5. Press the start button.
6. Check the output for the problems.

## 'Tone scale area check' print

### Introduction

The 'Tone scale area check' print option can be used, upon request of a helpdesk, to indicate areas with unsatisfactory output quality.

### Illustration



[203] Tone scale area check print

### How to make a 'Tone scale area check' print

The system prints the 'Tone scale area check' print in the 'Presentation' quality mode. You are recommended to use A0 / 36" for the 'Tone scale area check' print.

Do the following to make a 'Tone scale area check' print.

1. From the 'HOME' screen select the 'System' tab.
2. Select the 'Setup' tab.
3. Use the scroll wheel to go to the 'Test prints'/'Print a demo or test image' wizard. Open this section with the confirmation button.
4. Use the scroll wheel to select the 'Tone scale area check'.
5. Press the start button.
6. Check the output for problems.

## Use the 'Tone scale area check' print to test the scanner

On request of the helpdesk the 'Tone scale area check' print can be used to indicate scanner problems. Use the 'Scan to USB' option.

1. Feed the 'Tone scale area check' print face up, landscape and centered on the original feeding table.
2. Select 'Scan' on the user panel.
3. Open the 'Scan' tab with the confirmation button above the scroll wheel.
4. Use the scroll wheel to select or create a scan template with the following settings:
  - 'Destination': 'USB stick'
  - 'File type': 'Color', 'JPEG'
  - 'Resolution (dpi)': 400
  - 'Original': 'Map',
- 5.5. 'Insert USB device'.
6. Press the start button.
7. After the scan to USB is finished, remove the USB mass storage device and send the (scanned) file to the helpdesk.

# 'Color reference chart' print

## Introduction

The 'Color reference chart' print gives an overview of the print job settings, copy job settings and advised media settings for a specific input type. Use the 'Test prints' ('Print a demo or test image') wizard on the printer user panel to print the 'Color Reference Chart'.

## Illustration



Colour Reference Chart

Océ ColorWave™ 300



Printing for Professionals

### Jump to One

Input Type	Print job settings			Copy job settings		Advised media settings
	Resolution	Colour tone	Rendering mode	Original type	Copy output	
	• Check • Release			• Lineart • Check • Release	• Overlay • Check • Release	<ul style="list-style-type: none"> <li>• Recycled paper 24.5"</li> <li>• Paper 24.5"</li> <li>• Recycled paper 18.5"</li> <li>• Recycled paper 16.5"</li> <li>• Recycled paper 14.5"</li> <li>• Paper 24.5"</li> </ul>
	• Check • Release	• Enhanced		• Lineart • Check • Release	• Colour • Check • Release	<ul style="list-style-type: none"> <li>• Paper 24.5"</li> <li>• Coated paper 24.5"</li> <li>• Recycled paper 18.5"</li> <li>• Recycled paper 16.5"</li> <li>• Recycled paper 14.5"</li> <li>• High speed coated paper 24.5"</li> </ul>
	• Release • Presentation	• Enhanced colour	• Perceptual (Smart) • Relative colourimetry	• Mix • Mix • Release • Presentation	• Colour • Release • Presentation	<ul style="list-style-type: none"> <li>• Coated paper 24.5"</li> <li>• High speed coated paper 24.5"</li> <li>• High speed coated paper 18.5"</li> <li>• High speed coated paper 16.5"</li> <li>• High speed coated paper 14.5"</li> <li>• Paper 24.5"</li> <li>• Coated paper 24.5"</li> <li>• Recycled paper 18.5"</li> <li>• Recycled paper 16.5"</li> <li>• Recycled paper 14.5"</li> <li>• High speed coated paper 24.5"</li> </ul>
	• Release • Presentation	• Enhanced colour	• Separation	• Mix • Mix • Release • Presentation	• Colour • Release • Presentation	<ul style="list-style-type: none"> <li>• Paper 24.5"</li> <li>• Coated paper 24.5"</li> <li>• Paper 24.5"</li> <li>• Coated paper 24.5"</li> <li>• Recycled paper 18.5"</li> <li>• Recycled paper 16.5"</li> <li>• Recycled paper 14.5"</li> <li>• High speed coated paper 24.5"</li> </ul>
	• Release • Presentation	• Enhanced colour	• Relative colourimetry	• Mix • Mix • Release • Presentation	• Colour • Release • Presentation	<ul style="list-style-type: none"> <li>• Paper 24.5"</li> <li>• Coated paper 24.5"</li> <li>• Paper 24.5"</li> <li>• Coated paper 24.5"</li> <li>• Recycled paper 18.5"</li> <li>• Recycled paper 16.5"</li> <li>• Recycled paper 14.5"</li> <li>• High speed coated paper 24.5"</li> </ul>
	• Release • Presentation	• Enhanced colour	• Perceptual (Smart)	• Mix • Mix • Release • Presentation	• Colour • Release • Presentation	<ul style="list-style-type: none"> <li>• Paper 24.5"</li> <li>• Coated paper 24.5"</li> <li>• Paper 24.5"</li> <li>• Coated paper 24.5"</li> <li>• Recycled paper 18.5"</li> <li>• Recycled paper 16.5"</li> <li>• Recycled paper 14.5"</li> <li>• High speed coated paper 24.5"</li> </ul>
	• Release • Presentation	• Enhanced colour	• Relative colourimetry	• Mix • Mix • Release • Presentation	• Colour • Release • Presentation	<ul style="list-style-type: none"> <li>• Paper 24.5"</li> <li>• Coated paper 24.5"</li> <li>• Paper 24.5"</li> <li>• Coated paper 24.5"</li> <li>• Recycled paper 18.5"</li> <li>• Recycled paper 16.5"</li> <li>• Recycled paper 14.5"</li> <li>• High speed coated paper 24.5"</li> </ul>
	• Release • Presentation	• Enhanced colour	• Perceptual (Smart)	• Mix • Mix • Release • Presentation	• Colour • Release • Presentation	<ul style="list-style-type: none"> <li>• Paper 24.5"</li> <li>• Coated paper 24.5"</li> <li>• Paper 24.5"</li> <li>• Coated paper 24.5"</li> <li>• Recycled paper 18.5"</li> <li>• Recycled paper 16.5"</li> <li>• Recycled paper 14.5"</li> <li>• High speed coated paper 24.5"</li> </ul>
	• Release • Presentation	• Enhanced colour	• Perceptual (Smart)	• Mix • Mix • Release • Presentation	• Colour • Release • Presentation	<ul style="list-style-type: none"> <li>• Paper 24.5"</li> <li>• Coated paper 24.5"</li> <li>• Paper 24.5"</li> <li>• Coated paper 24.5"</li> <li>• Recycled paper 18.5"</li> <li>• Recycled paper 16.5"</li> <li>• Recycled paper 14.5"</li> <li>• High speed coated paper 24.5"</li> </ul>
	• Release • Presentation	• Enhanced colour	• Perceptual (Smart)	• Mix • Mix • Release • Presentation	• Colour • Release • Presentation	<ul style="list-style-type: none"> <li>• Paper 24.5"</li> <li>• Coated paper 24.5"</li> <li>• Paper 24.5"</li> <li>• Coated paper 24.5"</li> <li>• Recycled paper 18.5"</li> <li>• Recycled paper 16.5"</li> <li>• Recycled paper 14.5"</li> <li>• High speed coated paper 24.5"</li> </ul>
	• Release • Presentation	• Enhanced colour	• Relative colourimetry	• Mix • Mix • Release • Presentation	• Colour • Release • Presentation	<ul style="list-style-type: none"> <li>• Paper 24.5"</li> <li>• Coated paper 24.5"</li> <li>• Paper 24.5"</li> <li>• Coated paper 24.5"</li> <li>• Recycled paper 18.5"</li> <li>• Recycled paper 16.5"</li> <li>• Recycled paper 14.5"</li> <li>• High speed coated paper 24.5"</li> </ul>

Release the optimum print quality.

1. Check the job settings.
2. Check the copy settings.
3. Use the user panel to make a Quality check print and evaluate the result.

Check the optimum print quality.

1. Check the job settings.
2. Check the copy settings.
3. Check the recommended settings on the user panel.

For detailed information, check the User Manual on www.oca.com.



Edition 1

[204] Color reference chart

## How to make a 'Color reference chart' print



**Note:**

The 'First language:' setting (in the Océ Express WebTools) is used for the language of the "Color reference chart" .

1. From the 'HOME' screen select the 'System' tab.
2. Select the 'Setup' tab.
3. Use the scroll wheel to go to the 'Test prints' ('Print a demo or test image') wizard. Open this section with the confirmation button.
4. Use the scroll wheel to select the 'Color reference chart'.
5. Press the start button.

# Output quality problems

## Introduction


The Océ ColorWave 300 offers three possibilities to check the quality of your printed output.

- Make a quality check print
- Make a tone scale area print
- Make a demo print.

This section describes the problems you can analyze by making one of these check prints. The **Optimize print quality** section describes how you can solve problems with the quality '*Optimize the output quality on the printer*' on page 268.



## Overview of output quality problems - Graininess

Graininess problems




Graphical representation of the problem	Description
	<p><b>Color specific graininess</b></p> <p>Perform an 'Optimize print quality' test. The test checks all printheads and the printer compensates for missing nozzles.</p> <p><b>Note:</b> After the 'Optimize print quality' test is completed, the printer may ask you to replace a printhead. In this case, take out the printhead and clean the contact area with a lintfree cloth. If the printhead is still not accepted, insert a new printhead.</p>

## Overview of output quality problems - Stripes and Banding

Stripes and Banding problems


Graphical representation of the problem	Description
 <p>A 10 cm vertical blue bar with thin, horizontal white stripes running across its entire width. To the right of the bar is a vertical double-headed arrow labeled '10 cm'. Further right is an upward-pointing arrow labeled 'Paper feed'.</p>	<p><b>Small stripes over the entire width of the print (color independent)</b> Perform an 'Optimize print quality' test.</p> <p><b>Note:</b> This problem can occur in all print modes.</p>
 <p>A 10 cm vertical blue bar with thin, horizontal white stripes that are not uniform in width and are scattered across the bar. To the right of the bar is a vertical double-headed arrow labeled '10cm'. Further right is an upward-pointing arrow labeled 'Paper feed Direction'.</p>	<ul style="list-style-type: none"><li>■ <b>Thin (White) Stripes or weak lines (Nozzle dropouts)</b></li><li>■ <b>Stripes per primary color</b></li><li>■ <b>Stripes in parts / dotted lines but also over the entire width</b></li></ul> <p>Usually you will find these stripes only in the check mode. In this mode some of these lines are acceptable, because there is no nozzle compensation.</p> <p>The nozzle compensation, that is used in the release mode and in the presentation mode, will correct the lines.</p> <ul style="list-style-type: none"><li>■ If these lines are unacceptable, switch to a slower mode ('Release' or 'Presentation'). Perform an 'Optimize print quality' test. The test checks all print-heads and the printer compensates for missing nozzles.</li><li>■ Check if the maintenance cassette is clean. If necessary, clean the wipers with a moist, lintfree cloth.</li></ul>



Graphical representation of the problem	Description
	<p><b>Stripes perpendicular to the paper feed direction</b></p> <p>In check mode the width of these lines is 12 mm.</p> <p>In release mode the lines are smaller (3-6 mm) and less visible.</p> <p>Perform an 'Optimize print quality' test.</p> <p><b>Note:</b> After the 'Optimize print quality' test is completed, the printer may ask you to replace a printhead. In this case, take out the printhead and clean the contact area with a lintfree cloth and re-insert the printhead. If the printhead is still not accepted, insert a new printhead.</p>
	<p><b>Banding in specific colors</b></p> <p>Perform an 'Optimize print quality' test.</p>
	<p><b>Banding in all colors with alternating light and dark bands (bands can have different widths)</b></p> <p>Perform an 'Optimize print quality' test.</p> <p>If the problems persist, repeat the 'Optimize print quality' test.</p>



### Overview of output quality problems - Waves / Cockle


Waves / Cockle problems

Graphical representation of the problem	Description
	<p><b>Waves and or light stripes in the paper feed direction</b></p> <p>Bands can consist of waves and / or slight color differences of approximately 1cm. Check if the correct media is defined on the system.</p> <p>If yes, select a different media type.</p> <p>When the printer applies a lot of ink the paper can cockle. Use premium papers or coated papers because they have a better resistance towards waving (also called cockle). If the problem persists, the use of heavier media will reduce cockle.</p> <p>The following papers will never show cockle.</p> <ul style="list-style-type: none"> <li>■ 'High qual. coated paper 120-170g'</li> <li>■ 'Photo gloss'</li> </ul>

### Overview of output quality problems - Colors

Color problems

Graphical representation of the problem	Description
	<p><b>Weak and polluted lines</b></p> <p>Select the 'Océ CAD colors' setting from the 'Color Management' menu in the Océ Express WebTools or Océ Windows Printer Driver.</p>
	<p><b>Blue lines and areas appear purple</b></p> <p>Select the 'Océ CAD colors' setting from the 'Color Management' menu in the Océ Express WebTools or Océ Windows Printer Driver.</p>

Graphical representation of the problem	Description
 <p data-bbox="274 378 372 402">EXPECTED</p> <p data-bbox="461 378 532 402">RESULT</p>	<p data-bbox="719 232 1162 296"><b>Colors appear too dark and dark areas are clipped</b></p> <p data-bbox="719 300 1162 429">Select 'Océ enhanced colors' setting from the 'Color Management' menu in the Océ Express WebTools or Océ Windows Printer Driver.</p> <p data-bbox="719 433 1162 496">Set the subset 'Rendering intent' to 'Perceptual (photo)'.</p>

# Optimize the output quality of the printer

## Optimize the output quality on the printer

### Introduction

This section describes different methods that you can use to optimize the output quality on the printer.

### Problem analysis and solutions

Problem analysis and solutions

Problem	Method of analysis	Solutions
The color of one area merges with the color of another area	'Quality check' print	<ul style="list-style-type: none"><li>■ The media type defined on the printer must be the same as the media available on the printer. When the media type defined on the printer is not the same as the media available on the printer, use the 'Change media type' wizard to change the media type <i>Replace / Install the media</i> on page 276</li><li>■ Use coated media</li><li>■ Use the default drying time</li><li>■ Remove the printer from high humidity conditions.</li></ul>
The color of one line runs into the color of another line	'Quality check' print	<ul style="list-style-type: none"><li>■ The media type defined on the printer must be the same as the media available on the printer. When the media type defined on the printer is not the same as the media available on the printer, use the 'Change media type' wizard to change the media type <i>Replace / Install the media</i> on page 276</li><li>■ Use coated media</li><li>■ Use the default drying time</li><li>■ Remove the printer from areas of high humidity.</li></ul>

Problem	Method of analysis	Solutions
White stripes in filled areas	'Quality check' print	<ul style="list-style-type: none"> <li>■ Use the 'Presentation' quality mode <i>'Output type, output quality and print speed'</i> on page 229</li> <li>■ Use the 'Optimize print quality' wizard to correct the problem <i>'Use the Print quality' wizard</i> on page 272.</li> </ul>
The output color is not the same as the original color	'Quality check' print	<ul style="list-style-type: none"> <li>■ Make sure you define the correct software settings, for example the correct pen settings.</li> <li>■ Use the 'Presentation' quality mode</li> </ul>
The length and width measurements are different from the original	'Quality check' print	<ul style="list-style-type: none"> <li>■ Make sure you defined the correct scale settings</li> <li>■ Use the 'Presentation' quality mode</li> <li>■ Use the 'Optimize print quality' wizard to correct the problem.</li> <li>■ In case of a media length deviation, adjust the 'Cut length correction' in the Océ Express WebTools.</li> <li>■ In case of an image length deviation, set the 'Vertical print optimization' to 'Size accuracy' and adjust the image length correction in the Océ Express WebTools.</li> </ul>
The colored lines are not well aligned or blurred	'Quality check' print	<ul style="list-style-type: none"> <li>■ Use the 'Presentation' quality mode</li> <li>■ Use the 'Optimize print quality' wizard to correct the problem.</li> <li>■ When failing printheads cause this problem, use the 'Replace printhead' wizard to replace the failing printheads <i>'Replace a defective printhead'</i> on page 284.</li> </ul>

Problem	Method of analysis	Solutions
Missing sections in lines or stepped lines	'Quality check' print	<ul style="list-style-type: none"> <li>■ Use the 'Presentation' quality mode</li> <li>■ Use the 'Optimize print quality' wizard to correct the problem.</li> <li>■ When failing printheads cause this problem, use the 'Replace printhead' wizard to replace the failing printheads.</li> </ul>
Missing parts of characters	'Quality check' print	<ul style="list-style-type: none"> <li>■ Use the 'Presentation' quality mode</li> <li>■ Use the 'Optimize print quality' wizard to correct the problem.</li> </ul>
Ink saturation causes the media to cockle	'Demo print'	<ul style="list-style-type: none"> <li>■ The media type defined on the printer must be the same as the media available on the printer. When the media type defined on the printer is not the same as the media available on the printer, use the 'Change media type' wizard to change the media type</li> <li>■ Use coated media.</li> <li>■ Use the default drying time.</li> <li>■ Remove the printer from areas of high humidity.</li> </ul>
The individual ink drops merge on the media	'Demo print'	Coalescence occurs in the 'Check' mode when you print on high gloss photopaper. Use the 'Release' or 'Presentation' quality mode
Problems with the nozzles cause drop-out	'Demo print'	<ul style="list-style-type: none"> <li>■ Use the 'Optimize print quality' wizard to correct the problem.</li> <li>■ A defective or end-of-life maintenance cassette can cause this problem. Use the 'Replace cassette' wizard to replace the maintenance cassette <i>'Replace the maintenance cassette'</i> on page 290</li> </ul>

Problem	Method of analysis	Solutions
The print contains regular horizontal light or dark bands	'Demo print'	<ul style="list-style-type: none"> <li>■ The media type defined on the printer must be the same as media roll available on the printer. When the media type defined on the printer is not the same as the media available on the printer, use the 'Change media type' wizard to change the media type</li> <li>■ Use the 'Presentation' quality mode</li> <li>■ Use the 'Optimize print quality' wizard to correct the problem.</li> </ul>
Color consistency problems	N/A	<ul style="list-style-type: none"> <li>■ Some types of media can discolor with age. Check that the media is new and that is stored correctly.</li> <li>■ Remove the printer from areas of high humidity.</li> </ul>

## Use the 'Print quality' wizard

### Introduction

The printer user panel contains the 'Print quality' ('Optimise print quality') wizard that helps you to correct the problems with the output quality. The wizard performs the following actions.

- Nozzle check: detect weak or failing nozzles.  
The Océ ColorWave 300 automatically compensates the detected nozzles in future prints to make sure that print quality is optimal.
- Align the print heads and optimize the paper transport.

During the 'Print quality' wizard, the system performs an alignment. The alignment requires the use of media. Make sure at least one roll of the following defined media:

- 'Paper 70-80g'
- 'Paper 90g'
- 'Coated paper 90-130g'
- 'High qual. coated paper 120-170g'
- 'Coated paper 24 lb'
- 'Coated paper Japan'
- 'Photo gloss (instant dry)'
- 'Paper 24 lb'
- 'Recycled paper 70-80g'
- 'Recycled paper 20 lb'

is loaded before you enter the 'Print quality' wizard.



**Note:**

A minimum roll width of 53 cm (20.9") is required for the calibration.



**Note:**

You can start the 'Print quality' wizard from the printer user panel.

### When to do

Before you start the 'Print quality' wizard, first check the following.


- Did you use the correct media type?
- Did you use the correct print mode?




Only start the wizard when you are sure that you used the correct media type and the correct print mode, and the output quality is still not satisfactory.

## How to use the 'Print quality' wizard

1. From the 'HOME' screen select the 'System' tab.
2. Select the 'Setup' tab.
3. Use the scroll wheel to go to the 'Print quality' ('Optimise print quality') wizard.




4. Open this section with the confirmation button.



5. Press the 'Next >' softkey to enter the wizard.  
The screen displays the message 'Select roll to use'.  
You can only calibrate on the defined media types. When calibration is not possible with the loaded media, the system asks you to load the correct media. When calibration is


possible with one of the rolls, the system automatically uses the correct roll of media. When calibration is possible with both rolls, continue with step 5.



Use the scroll wheel to select the required roll and press the confirmation button to select a media roll for the calibration.

- 6. Press the 'Next >' softkey.

The screen displays the message 'Preparing media...' The system prepares for the quality check.



The screen displays feedback about the calibration process. The system does a nozzle failure recovery and alignment.

You can stop the calibration process at any time. Press the key for 'Cancel' to stop the calibration process.

In case more than 75 nozzles fail, a 'Printheads failing' message appears. Then you must replace the print head using the 'Printheads' ('Replace printhead') wizard.

# **Chapter 7**

## **Maintain the Océ Color-Wave 300 multifunction printer**

# Replace the media

## Replace / Install the media

### Introduction

The Océ ColorWave 300 contains two rolls of media. Appendix A (of the User Manual) contains a list of the supported media types and media sizes.


This section describes how to remove and load a roll of media.

### When to do

Change a roll when a job needs a media type or size that is not on one of the rolls. Change the media type that is defined on the system when one roll is empty and the other available media type does not correspond.

### How to remove a roll of media


1. Press the media unload button on the right-hand side of the roll.



[219] Press the media unload button


The media automatically retracts from the printer.

2. Use both hands to remove the roll.




[220] Remove the roll

3. Both far ends of the roll contain roll holders with handles. Lift the handles to release the roll holders.



[221] Release the roll holders

4. Remove the roll holders.



[222] Remove the roll holders

### How to load a new media roll

1. Insert the roll holder in both ends of the new media roll.
2. Press the handles down to fasten the roll holders.

- 3. Put the green saddles into position at the ends of the track.



[223] Green saddles

- 4. Use both hands to place both roll holders in the green saddles on the printer.
- 5. Use both hands to slide the media under the paper guide. Place the media on the printer as shown in the figure below.



The media loads into the printer from the top of the media roll. Make sure the media makes contact with the transport rollers.

6. The printer automatically draws the media into the correct position.
7. Follow the steps in the wizard on the user panel:
  - Select the correct media type for the new media roll.
  - Select the clean-cut length.
    - Options:
      - No strip
      - Long strip (preferred if the new media on the core is dirty).
      - Short strip.



*Note:*

The printer automatically detects the width of the media.



---

# Ink

## Replace the ink tanks

### Introduction

The Océ ColorWave 300 contains the following four ink tanks.

- One tank for the cyan ink.
- One tank for the magenta ink.
- One tank for the yellow ink.
- One tank for the black ink.

The ink level card on the printer user panel indicates the ink level of each color as a percentage.

You can replace the ink tanks at any time. A wizard is not required.

### When to do

You must replace an ink tank when the ink level indicator on the printer user panel shows 0%.



**Note:**

While you replace the ink tank, the printer can continue to print on the ink present in an intermediate ink storage tank inside the printer.




**Note:**

If you do not replace the ink tank in time a pop-up message appears on the screen. The pop-up message displays the message 'Out of [color] ink. Replace ink tank'. The printer stops and immediate action is required.


### How to remove an ink tank

1. The user panel indicates a message: 'Color' ink tank empty. For example: 'Yellow ink tank empty.'  
Select the 'Solve' option with the lower right soft key to start the 'Ink tank' wizard.  
or  
From the 'HOME' screen, select the 'System' tab.  
Select the 'Setup' tab.

Use the scroll wheel to go to the 'Ink tank' ('Replace ink tank') wizard.



Open this section with the confirmation button.



2. Press the ink tank inward and upward to release the ink tank.
3. Pull the ink tank straight out of the slot.  
The indication for the removed tank on the printer user panel changes into a dashed line.

## How to place an ink tank

---



### **Caution:**

Make sure that you only use Océ ColorWave 300 ink tanks. Using other ink tanks will damage your printer!

---



### **Caution:**

Make sure that you replace an ink tank with a tank that contains ink of the same color.

---

1. Hold the ink tank with the color of the label towards you.  
The ink tanks are arranged in the same sequence as shown on the user panel. From left to right, the sequence of the ink tanks is black, cyan, magenta, yellow, black (KCMY). A label on the ink tank indicates the color of the ink in the ink tank.

**Note:**

Do not shake the ink tank or touch the opening of the ink tank.

2. Slide the ink tank into the slot until you feel a resistance and stop.

**Note:**

The ink tank fits only in one way . The ink tank fits only into the slot dedicated for the color. When you attempt to place the ink tank the wrong way or in the wrong slot, the ink tank will not fit. Do not attempt to force it.

3. Press the ink tank inward and downward until the ink tank clicks into place. When the printer detects the full ink tank, the ink level indicator on the printer user panel displays 100%.

**Note:**

The printer first refills the intermediate ink storage tank. Therefore the ink level indicator on the printer user panel can decrease to about 95%.

## Replace a defective printhead

### Introduction

The Océ ColorWave 300 contains the following nine print heads.

Overview print heads

Quantity	Color	Print head position (indicated on the print head carriage)
3	Black (K)	1, 2, 3
2	Cyan (C)	4, 5
2	Magenta (M)	6, 7
2	Yellow (Y)	8, 9

Always follow the instructions in the wizard on the printer user panel when you replace a defective print head.

After you replace a defective print head, the system performs an alignment. The alignment requires the use of media. If you enter the 'Printheads' ('Replace printhead') wizard while no media is present, the printer asks you to load a roll of media first.



**Note:**

Only replace a defective print head using the 'Printheads' ('Replace printhead') wizard.



**Note:**

A print head is defective when the print head has an electric defect or a major number of nozzles fail. You cannot continue to print before the print head is replaced.

### When to do

The system displays an error message and prompts you to replace the defective printheads. Only replace the printheads the system indicates.



**Caution:**

Only replace printheads when they are defective. Changing printheads that are not defective will shorten the printhead lifetime and cause problems with the ink system.


---

**Caution:**

Always store printheads near the printer or allow the printheads to adjust to the printers environmental conditions before you insert them in to printer.

**How to remove a print head**

1. From the 'HOME' screen select the 'System' tab.
2. Select the 'Setup' tab.
3. Use the scroll wheel to go to the 'Printheads' ('Replace printheads') wizard.



4. Open this section with the confirmation button.
5. An introduction screen displays the message 'Use this wizard to replace printheads. A roll is needed for calibration.'




6. Press the key for 'Next >'.  
The screen displays the message 'Select roll to use'.  
The system does a calibration at the end of the wizard. You can only calibrate on the defined media types *'Use the 'Print quality' wizard' on page 272*. When calibration is not possible with the media available on the printer, the system asks you to load the correct media. When calibration is possible with one of the rolls, the system automatically uses the correct media roll. When calibration is possible with both rolls, use the scroll wheel to select the media roll and press the confirmation button to select the roll.
7. Press the key for 'Next >'.


The screen displays the message 'Carriage moving into position...' while the carriage moves to the center.

The screen displays 'Open printhead door.'


8. 'Open printhead door.'




The screen displays the message 'Replace printheads' and the print head(s) that you must replace. Find the correct print head number on the print head carriage.



9. Press the front of the print head cover to unlock the cover.



10. Open the print head cover.




11. Pull out the print head and remove it.



### How to place a print head


1. Remove the protective tape from the new print head.

Hold the print head at the top.



*Note:*

Do not touch the contact and nozzle areas of the print head after you remove the protective tape.





2. Place the new print head in the print head holder.  
The print head only fits in one way.
3. Close the print head cover.
4. After you replaced the defective print head, press the soft key for 'Next >'
5. The screen displays the message 'Make sure that all printhead covers are properly closed.'



Press the key for 'Done'.

The screen displays the message 'Close printhead door.'

6. 'Close printhead door.'
7. The screen displays 'Preparing calibration..'.  
The calibration process takes several minutes.  
You can stop the calibration process at any time. Press the key for 'Cancel' to stop the calibration process.



**Note:**

If you cancel the calibration, the printer restarts the calibration process when a new print job starts.



**Note:**

If the printer rejects the new print head during the 'Replace printheads' procedure, remove the print head, clean the contact area with a lint-free cloth and re-insert the print head.



**Note:**

Also check the maintenance cassette after you replaced a print head. See ['Replace the maintenance cassette' on page 290](#). Check if all wipers are present and clean. Excessive ink remains on the wipers can damage the print heads. Wipe the wiper blades with a moist cloth to increase the lifetime of the print heads.

## Replace the maintenance cassette

### Introduction

The maintenance cassette wipes the printheads and caps the printhead nozzles. During the print process, the printhead carriage regularly moves to the right-hand side of the printer to spit some ink droplets into the maintenance cassette. These actions are necessary to keep the printheads in optimal condition. After about 5 000 m<sup>2</sup> of output (the exact value depends on the print modes you use) the printer indicates that you must replace the maintenance cassette.

### When to do

Replace the maintenance cassette when user panel displays the message 'Replace maintenance tray'. The print quality can deteriorate. Replace the cassette as soon as possible.



#### **Caution:**

Do not remove the maintenance cassette when you are not in the wizard. You can seriously damage the printheads. When you open the maintenance door outside the wizard, an error message prompts you to close the door.

---

### How to remove the maintenance cassette

1. From the 'HOME' screen select the 'System' tab.
2. Select the 'Setup' tab.
3. Use the scroll wheel to go to the 'Maintenance tray' ('Replace maintenance tray') section.
4. Open this section with the confirmation button.
5. An introduction screen displays the message 'Use this wizard to replace the maintenance tray.'




6. Press the 'Next >' key.


The screen displays the message 'Carriage moving to center position...' while the carriage moves to the center.

Then, the screen displays the message 'Open maintenance door.'

7. Open the door to the maintenance cassette.  
The screen displays the message 'Remove tray.'
8. Press the green grip to the left to release the cover that gives access to the maintenance cassette.



9. Pull out the maintenance cassette.



**Note:**

Always store the old maintenance cassette in a horizontal position to prevent the spilling of ink. Be careful with the ink on the maintenance cassette.



**Note:**

The packing of the new maintenance cassette also includes a plastic zip lock waste bag. Use this bag to dispose of the old maintenance cassette.

### How to place the maintenance cassette

1. The screen displays the message 'Place new maintenance tray.'
2. Slide the new maintenance cassette into the cassette holder.
3. Close the cover of the maintenance cassette . The cover locks automatically.
4. 'Close maintenance door.'
5. The screen displays the message 'Is the tray you placed used or new?'



**Caution:**

Make sure that you select the correct option. Never select 'New' for a used cassette. This can seriously damage your print heads.

---

6. Press the key for 'Used' or 'New'.  
Select 'Used' if you inserted a cassette that was used before. The end-of-life counter is not reset to zero.  
Select 'New' if you inserted a cassette that was not used before. The end-of-life counter is reset to zero.
7. The screen displays the message 'Carriage moving to home position...'
8. The maintenance cassette is replaced.

---

## Refill the ink tube

### Introduction


The Océ ColorWave 300 has ink tubes between the intermediate reservoirs and the print heads. The ink tubes must be filled with ink to keep the print heads functioning.

### When to do

Check whether the ink tubes are filled with ink on a regular basis. No air (bubbles) should be visible in the ink tubes.

### How to check the ink level in the ink tubes

1. Open the print head door.
2. Look at the ink tubes through the hole in the cover of the carriage.
3. Specification: You should see no air (bubbles) in the ink tubes.



4. If air is visible in the ink tube carry out: How to fill the ink tube.

### How to fill the ink tube

1. From the 'HOME' screen, select the 'System' tab.  
Select the 'Setup' tab.  
Use the scroll wheel to go to the 'Ink tube' ('Fill ink tube') wizard.  
Open this section with the confirmation button.
2. Follow the instructions in the wizard:
  - Carriage moving into position.
  - Open the print head door.
  - Push back the top delivery tray.
  - Open the top door.

- Make sure the maintenance tray is in position.
  - Remove the print head with air in the tube or empty tube.
3. Take the ink filling tool.



[243] Ink filling tool

4. Place the metal tube in the hole of the pump.



[244] Metal tube of ink filling tool



[245] Metal tube placed on pump

5. Place the other side of the ink filling tool at the empty ink tube.



[246] Black side of the ink filling tool



[247] Ink filling tool on empty ink tube

6. Push 'Yes' to start the pump. Wait until the ink starts to move into the ink filling tool and the air is out of the tube.
7. Remove the ink filling tool from the ink tube and hold it up.
8. Wait until the ink is out of the ink filling tool.
9. Push 'No' to stop the pump.
10. Remove the ink filling tool.
11. Follow the instruction of the wizard to get the system up and running.



**Note:**

If needed: Repeat this procedure for another ink tube with air.



**Note:**

Clean the ink filling tool with water.

## Océ ColorWave 300 system with very low volume

1. For customers
  - printing less than 1 000 m<sup>2</sup> per year with normal ink coverage
  - or customers printing only color
  - or customers with prolonged periods of non-operation the Océ ColorWave 300 has a print head maintenance option.

The print head maintenance activity depends on the printed volume. When the option is activated, the system will monitor the printed volume and perform the necessary maintenance activity automatically. Contact the Océ service organization to activate this option.



*Note:*

The Océ ColorWave 300 engine needs to be switched on (Example: standby or sleep mode) to enable the print head maintenance option.



## Remote consumables reading

### Introduction

An administrator can remotely read out the Océ ColorWave 300 consumables settings for administrative purposes.

The following Océ ColorWave 300 information is available:

- Basic settings of the system
- Print head information for each color
- Ink tank information for each color
- Maintenance Cassette usage.


### Read the information

1. Start a Web browser (e.g. Internet Explorer) on your workstation.
2. Fill in the URL: `http://<hostname>/servlet/ALGetResourceCounters?identification=1`  
Fill in the correct hostname or IP address of your system.
3. You will get an overview of the consumables information.

# Maintain the scanner

## Clean the scanner

### Introduction



	Component	Description / Function
1	original size ruler	Use this ruler to measure the original.
2	original feed rollers	A set of rollers used to transport the original.
3	scanner top cover	Top cover of the scanner.
4	scanner open levers	Lever to open the top cover of the scanner.
5	original support rollers	A set of rollers to guide the original.
6	scanner top cover rollers	A set of rollers in the top cover to guide the original.
7	original sensors	Sensors to detect the original.
8	transparent contact plates	Cover of the image sensors.
9	original feeding table	Use this table if you feed the original into the scanner.

---

	Component	Description / Function
-	original guide	Guides the original over the scanner to the front.

### When to do

The copy and scan quality can decrease if

- The transparent contact plates (8) are dirty or static.
- The original support rollers (5) are dirty and you use transparent originals.

In that case you must clean the scanner to ensure top quality output.

### How to clean the scanner

1. Use both hands to push up the left and right scanner open levers (4) to fully open the scanner top cover (3).

A locking mechanism prevents the scanner top cover from closing.



**Caution:**

To clean the scanner, use the soft lint-free towels from the scanner cleaning kit.

2. Use a towel that has been moistened with water and firmly wrung out to clean the following parts of the scanner.

- The original support rollers (5)  
Rotate the rollers to clean them.
- The transparent contact plates (8)  
Wipe off any soiled areas.



3. Wipe all the cleaned parts once again using a dry towel.



**Warning:**

Take care not to get your fingers caught in the scanner top cover.

4. Press the scanner top cover down gently with both hands to close it.



**Note:**

Check that the left and right scanner open levers are locked into position.

# Calibrate the scanner

## Introduction

You can calibrate the scanner when you are not satisfied with the copy or scan quality. Use the calibration wizard on the printer user panel to calibrate the scanner.

## Before you begin

Clean the scanner before you start the calibration procedure. Dirty parts in the scanner can decrease copy and scan quality. (See '*Calibrate the scanner*' on page 302).



**Caution:**

Handle the calibration sheet with care.

---



**Caution:**

Do not touch the black area of the calibration sheet with your fingers.

---




**Caution:**

Before you use the calibration sheet wipe off any dust from the calibration sheet.

---

## How to calibrate the scanner

1. From the 'HOME' screen select the 'System' tab.
2. Select the 'Setup' tab.
3. Use the scroll wheel to go to the 'Scanner calibration' ('Calibrate the scanner') wizard.



4. Open this section with the confirmation button.

5. Insert the scanner calibration sheet<sup>1</sup> as instructed in the wizard.
6. Press the start button to start the scanner calibration.  
The message 'Calibrating, please wait... do not open the scanner.' appears.

**Note:**

'Calibrating the scanner takes between 5 to 10 minutes.'

**Note:**

<sup>1</sup> The scanner calibration sheet code number is **1060077525**.

# Update

## Update the system software

### Introduction

The Océ Express WebTools offers an option to update the system software.

You can find these settings in the 'Support' - 'Update' tab.

The update option has the following functionality:

- load and remotely apply security and system software patches onto the controller
- check the last patch successfully applied
- check the execution status of the latest patch applied ('Success' or 'Failure').

### When to do

Each time a security patch or a controller software patch needs to be remotely installed on the controller.

### Before you begin

- Download the security or system update patch from the Océ website (Downloads/Security page of your product on <http://global.oce.com>) or
- Get the controller software patch provided by your Océ representative.



*Note:*

Log on as a system administrator.

### Update the system software and check the status

1. Navigate to 'Support' - 'Update' tab.
2. Select the 'Update' button.
3. Click 'Ok' to confirm your entries or 'Cancel' to reject your entries.
4. Browse to the location of the patch file(\*.oce).  
Select the file and click 'Open'.
5. Click 'Ok' to confirm your entries or 'Cancel' to reject your entries.
6. You are now ready to update the software. A warning message is indicated.  
Click 'Ok' to confirm your entries or 'Cancel' to reject your entries.
7. The update starts. At the end of the process, the controller reboots.  
Click 'Ok' to open the Océ Express WebTools.



8. Navigate to 'Support' - 'Update' tab.
9. Log on as a system administrator.
10. Check that the 'Last execution status' of the patch is 'Success': the installation was successful.



**Note:**

When the status is 'Failure': Click on 'Open the log of the last patch applied on the controller' and read the information to determine the cause of the problem. If the log file provides no solution, contact your Océ representative.



# **Chapter 8**

## **System messages and solutions**

# The printer

## Overview




### Definition

This table gives an overview of the possible error messages and system messages of the printer and refers to the possible solution.

Error message / System message	Description / solution
'Required media not available'	The media required for the job is not available on the printer. See <i>'Replace / Install the media'</i> on page 276
'Roll empty'	The end of the roll of media is reached while you print See <i>'Replace / Install the media'</i> on page 276
'Close maintenance door' / 'Close top cover.'	A door or cover is open, although you are not in a wizard See <i>'Cover or door opened'</i> on page 310
'Remove media'	A media jam occurred See <i>'Remove jammed media'</i> on page 313
'Temperature out of range' /'Humidity out of range'	Excessive temperature or humidity. See <i>'Temperature or humidity out of range'</i> on page 315
'Warning Carriage away from home position too long'	The carriage is away from its home position too long See <i>'Carriage away from home position too long'</i> on page 316

### Printhead error messages

The table below gives an overview of the printhead-related error codes.



Error code	Description	Customer action
4501 - 4509	Excessive leakage current detected for head [1...9] Printhead failing Replace printed [1...9]	Replace the printhead by using the wizard.   <b>Note:</b> Never re-insert a printhead that has caused this problem.
4551 - 4559	Head defective during printing	Printhead is probably not placed correctly. Remove and re-insert the printhead at the original position.   <b>Note:</b> If the problem persists you must replace the printhead.
4571 - 4579	Head too hot during printing	You can ignore this problem by pushing the 'OK' button.   <b>Note:</b> If the problem re-occurs after a short time you must replace the printhead.
4581 - 4589	Head [1....9] keeps heating	Replace the printhead by using the wizard.
4951 - 4959	WOM memory failure for head [ 1.....9]	Service warning only. No customer intervention needed.
4961 - 4969	Heating of head [1.....9] failed	Continue printing until the message 'Replace printhead' displays on the user panel. Then replace the printhead by using the wizard.

## Cover or door opened

### Cover or door opened

When you open a cover accessing the wizard, the system produces a double warning signal. When you open a door or cover during printing, the printer stops. A message on the printer user panel tells you to close the cover. Close the cover to continue.

Examples:



*Note:*

When the cover or door is opened while the printer prints a job, the print is cut after you close the cover. Then the whole print job is restarted.



## Remove jammed media

### Introduction

When a media jam occurs, the system produces a double audio signal. When a jammed media error occurs on the system, immediately remove the jammed media to prevent damage to the printer.

The system handles the error recovery for the jammed media through a series of dialog boxes. Use the following procedure to remove the jammed media.

#### Job recovery

The Océ ColorWave 300 is equipped with a job recovery function that safeguards users against data loss in case of a printer failure. After a restart, the data submitted to the printer before the crash will be automatically processed and printed. This means that jobs do not have to be re-submitted after a printer malfunction, thus saving valuable time for the users.

### How to remove jammed media

---


**Caution:**

Never use a knife to cut loose the jammed media. When you use a knife to cut loose the media, you can damage the printer.

---

1. Open the cover or door that the printer user panel indicates.

### Examples:



2. Use a pair of scissors to cut loose the media.
3. Remove the jammed media from the output side of the printer.
4. Press the softkey for 'Next >' to confirm that you removed the jammed media.
5. Close the cover or door that the printer user panel indicates.
6. Insert the roll of media in the printer.  
The printer is ready for use.



#### *Note:*

When you remove the media from the front of the printer, there is a risk of ink pollution in the media feed section.

## Temperature or humidity out of range

### Temperature or humidity out of range

The system produces a short interrupted audio signal.

When this error persists, contact your local Océ service organization.

## Carriage away from home position too long

---



**Caution:**

When the carriage stays away from its home position too long, the printheads become dry. When the printheads are dry, you must replace the printheads.

---

### Carriage away from home position too long

Always replace the printheads or the maintenance cassette in one continuous action to prevent the drying of the printhead nozzles.

When you replace a printhead or the maintenance cassette, the carriage moves to the centre. When the carriage is in the center too long, the system produces an error signal.

# The scanner

## Clear an original jam on the scanner

### Introduction

When an original jam occurs on the scanner, the message 'Scanner original jam' appears on the user panel. You must remove the original from the scanner.

If an original jam occurs often:

- Check if you use the correct type of original.
- Check if you must use a carrier sheet.
- Check if the original is damaged before you insert it.

### How to remove a jammed original

1. Use both hands to push up the left and right scanner open levers to fully open the scanner top cover.

A locking mechanism prevents the scanner top cover from closing.



2. Remove the original.  
Pull the original from the scanner or from the originals exit at the front.
3. Press the scanner top cover down gently with both hands to close it.



*Note:*

Check that the left and right scanner open levers are locked into position.

4. Make the original smooth and feed the original.

# **Chapter 9**

## **License management**

## Introduction to managing licenses

### Introduction

The Océ applications and options are protected against unauthorized use. You need to activate the license to enable an application or option for use. The 'Support' - 'Licenses' tab in the printer enables you to manage the licenses very easily.

This section describes the following.

- The basic concept of the licenses.
- How to manage the licenses.



## The 'Licenses' tab in the Océ Express WebTools

### Introduction

The 'Support' - 'Licenses' tab has the following possibilities.

### Possibilities

- View the current active licenses
- Get the host id of the Océ system
- Save the active licenses
- You can activate new licenses or saved licenses.

## The basic workflow of 'Support' - 'Licenses' activation

### Introduction

Before you can work with licenses, you must access to the Océ Express WebTools. The following workflow describes per step when to use which possibility.

### The workflow

1. View the current active licenses.  
You can make a list of new options you need and make a list of license numbers. Océ needs the list of new options and the license numbers to create a new license file.
2. Get the host id of the Océ system.  
Océ needs the host id of your Océ system to create a new license file.
3. Send the list of new options you need, the list of license numbers and the host id to Océ.  
Océ creates and delivers one or more new license files.
4. Create a back-up of the current active licenses if necessary.  
Save the current active licenses to do so.
5. Activate the licenses.

The license activation job guides you through the following steps.


- 1. Locate the license file
- 2. Preview the new active licenses
- 3. Accept the end user license agreement
- 4. Finish the license activation job
- 5. Restart the Océ system.

# Océ License Logic

## Introduction

When you navigate to the 'Support' - 'Licenses' tab in the Océ Express WebTools, you get access to the Océ License Logic application.

## Overview Océ License Logic functionality

Function	Description
View the current active licenses.	You can make a list of new options you need and make a list of license numbers. Océ needs the list of new options and the license numbers to create a new license file.
Get the host id of the Océ system.	Océ needs the host id of your Océ system to create a new license file.
Create a back-up of the current active licenses if necessary.	Save the current active licenses to do so.
Activate the licenses.	<p>Perform a license activation job to do so. The license activation job guides you through the following steps.</p> <ul style="list-style-type: none"> <li>■ 1. Locate the license file</li> <li>■ 2. Preview the new active licenses</li> <li>■ 3. Accept the end user license agreement</li> <li>■ 4. Finish the license activation job</li> <li>■ 5. Restart the Océ system.</li> </ul> <p> <b>Note:</b> Perform the license activation job for each license file.</p>

## The structure of license files and licenses

### Introduction

A license file contains a license per option of your Océ system. You can view the current active licenses with Océ 'Support' - 'Licenses' tab in the Océ Express WebTools. You can preview the new active licenses during the license activation job.

### A license file contains licenses of the same license-type

A license file you receive from Océ contains only licenses of the same license-type. The following license types are possible.


- Demo
- Resale.


If you order demo and resale licenses, you receive 2 license files.

### What you see per situation

What you see per situation depends on the license file you use.

What you see depends on the situation

Situation	What do you see
View the current active licenses.	You see the following. <ul style="list-style-type: none"> <li>■ All current active demo licenses</li> <li>■ All current active resale licenses</li> <li>■ All current other not active options.</li> </ul>
Océ delivered one or more license files.	You see one of the following options. <ul style="list-style-type: none"> <li>■ A demo license file</li> <li>■ A resale license file</li> <li>■ A demo license file and a resale license file.</li> </ul>
Preview the demo licenses during the license activation job if you use the license file with demo licenses.	You see the following. <ul style="list-style-type: none"> <li>■ All current active demo licenses</li> <li>■ All new active demo licenses.</li> </ul> <p> <b>Note:</b> You cannot see the current active resale licenses at this point.</p>

Situation	What do you see
<p>Preview the resale licenses during the license activation job if you use the license file that contains the resale licenses.</p>	<p>You see the following.</p> <ul style="list-style-type: none"> <li>■ All current active resale licenses</li> <li>■ All new active resale licenses.</li> </ul> <p> <b>Note:</b> You cannot see the current active demo licenses at this point.</p>
<p>Preview the demo and resale licenses during the license activation job if you use the saved licenses of your back-up file.</p>	<p>You see the following.</p> <ul style="list-style-type: none"> <li>■ All demo licenses that were active at the time you created the back-up file</li> <li>■ All resale licenses that were active at the time you created the back-up file</li> </ul>
<p>The license activation job is finished.</p>	<p>You see the following.</p> <ul style="list-style-type: none"> <li>■ All current active demo licenses</li> <li>■ All new active demo licenses</li> <li>■ All current active resale licenses</li> <li>■ All new resale licenses</li> <li>■ All current other not active options.</li> </ul>

## Check your licenses

### About the licenses

The 'Support' - 'Licenses' tab in the Océ Express WebTools allows you to manage the licenses that are active on your system. A license is needed to activate certain functions on your Océ ColorWave 300.

You can use the 'Support' - 'Licenses' tab to perform the following tasks.

- View the current active licenses.
- Get the host id of the Océ system.
- Save the active licenses.
- Perform a license activation job.  
You can activate new licenses or saved licenses.

### License information overview

Click 'Support' - 'Licenses' to view the available licenses.

You can view the license information for the following purposes.

- Check the active licenses on license state, license type and license duration.
- Check how long a demo license is valid.
- View all options available for your Océ system.  
The list of options depends on the type and version of the Océ system.
- Make a list of new options you need.
- Make a list of license numbers.

Information	Description
'Option'	<p>This field displays the name of the option. For Océ ColorWave 300 the following licenses are available.</p> <ul style="list-style-type: none"> <li>■ 'Océ ColorWave 300 license'</li> <li>■ 'Security'</li> <li>■ 'Queue management'</li> <li>■ 'Accounting'</li> <li>■ 'Copy with Océ Scanner Express'</li> <li>■ 'Scan-to-file with Océ Scanner Express'</li> <li>■ 'Scan-to-color with Océ Scanner Express'</li> <li>■ 'Copy and scan templates'</li> <li>■ 'Copy stamping'</li> <li>■ 'Adobe® Japanese PostScript® fonts'</li> <li>■ 'Adobe® Simplified Chinese PostScript® fonts'</li> <li>■ 'Adobe® Korean PostScript® fonts'</li> <li>■ 'Adobe® Traditional Chinese PostScript® fonts'</li> <li>■ 'Adobe® PostScript® 3 / PDF'</li> </ul>
'State'	<p>This field displays one of the following license states.</p> <ul style="list-style-type: none"> <li>■ 'Authorized'. You are authorized to use the function.</li> <li>■ 'Not authorized'. You are not authorized to use the function, you need to get a license for the function.</li> <li>■ 'Expired'. Your license was a temporary license. You need to get a new license to use the function.</li> </ul>
'License type'	<p>This field displays one of the following license types.</p> <ul style="list-style-type: none"> <li>■ 'Resale'.</li> <li>■ 'Demo'.</li> </ul>
'Duration in days'	This field displays the time your license is valid.
'License number'	This field displays a license number.

# Save the currently active licenses

## Introduction

You can save all current active licenses of different licenses types into one single file.

## Purpose

Save the current active licenses for the following purposes.

- Collect and save all active licenses of different types into one single file
- Create a back-up file before you start a license activation job.

## When to do

Save the current active licenses before you start a license activation job or to save the current license situation.

## How to save the license information

1. Click 'Support' - 'Licenses' to display the license information page.
2. You need to log on as System administrator or Power user if you are not logged on already.
3. Click the 'Save' button.  
The 'Save licenses' window opens.
4. Select a directory, enter the file name and click the 'Save' button to back up the currently active licenses.

## Result

All currently active resale and demo licenses are stored into one single file.



# Install a new license

## Introduction

The Océ applications and optional functions are protected against unauthorized use. You need to activate the license to enable an application or optional function for use. The 'Licenses' tab enables you to upload new license files to activate a license.

## Purpose

- Upload a new license file.
- Extend the existing license on your Océ ColorWave 300.



**Note:**

After the license is uploaded you must restart your system to activate the license file.

## How to get a new license file

1. Click 'Support' - 'Licenses' to display the license information page.
2. The login window appears. Log on as System administrator or Power user.
3. Click the host id hyperlink to display the host id information.
4. Copy the id and send the host id information to your Océ representative together with a list of options that you require.
5. After receiving the license file(s), store the file(s) on the network.



**Caution:**


It is advised to store the license information of the currently active license files in a back-up file before you activate a new license file. Use the 'Save' button to store the current license files information.

---


## Upload a new license

1. Click 'Support' - 'Licenses' to display the license information page.
2. Log on as System administrator or Power user.


3. Click 'Activate' to open a browser window to search for the license file on the network.




#### 4. Browse the network and select the license file.



- Click 'Next >' to check the license information.



- Click 'Next >' to read the End user license information. Read this information carefully.



- Check the "I accept" tick box.
- Click 'Finish' to start the activation of the license file.
- Restart the system to activate the changes.

## Result

- If you have updated an expired license, the new license file overwrites the previous license file.
- If you have uploaded a new license, the license state in the overview is changed from 'Not authorized' to 'Authorized'.

---

■ [Save the currently active licenses, on page 328](#)



# **Chapter 10**

## **Software options**

# Océ Repro Desk Studio

## Océ Repro Desk Studio

### Introduction

Océ Repro Desk Studio provides end-users (designers, information consumers, document distribution specialists) a simple uniform way of viewing and printing technical documents, with integrated accounting capabilities.



*Note:*

For this application a separate user manual is available.

### Key product features

- Easy-to-use application for printing to one or more multiple printers, or your external print provider.
- True WYSIWYG previewing for most common document formats.
- Integrated accounting for complete cost recovery.
- Automatic job distribution to the most suitable printer.
- One application to print either in-house or externally at your reprographer.
- Low investment on hardware PC.



---

# Account management

## An overview of Océ Account Center

### Introduction

Use Océ Account Center to manage the account information of print jobs, copy jobs and scan jobs for your Océ devices.



**Note:**


For this application a separate user manual is available.

### Definition

Océ Account Center consists of the following two software modules.

- **Océ Account Console.**  
Océ Account Console runs on a PC that functions as a server. Access to the Océ Account Console application is password protected and limited to authorized personnel. The administrator uses Océ Account Console to create the account information dialog. The administrator publishes the account information dialog for the Océ Express WebTools, the user panel and other applications.  
The bookkeeper uses Océ Account Console to retrieve and export the log data. The bookkeeper uses the log data for accounting purposes.
- **Océ Account Logic.**  
Océ Account Logic software is part of the Océ Express WebTools. The software enables the user to enter account information for print jobs, copy jobs and scan jobs.

**Illustration**



**User roles and tasks in Océ Account Center**

Users	Tasks
1) Administrator	<ul style="list-style-type: none"> <li>■ Create, manage and delete the account dialog.</li> <li>■ Publish the account dialog to the Océ Express WebTools and the user panel.</li> </ul>
2) Users	<ul style="list-style-type: none"> <li>■ Use the dialog of the Océ Express WebTools to enter the account information for print jobs, copy jobs and scan jobs.</li> </ul>
3) Bookkeeper	<ul style="list-style-type: none"> <li>■ Retrieve and use the account information of print jobs, copy jobs and scan jobs that is stored on the embedded controller of your Océ device. The log data serves as input for the accounting reports and invoices.</li> </ul>

# **Chapter 11**

## **Network and Security settings**

## Check or adapt the network settings

### Introduction

The 'Network settings' wizard on the printer user panel gives the option to check or adapt the network of the system.




#### **Caution:**

Detailed network knowledge is needed to change the network settings.

---


### How to check or adapt

1. From the 'HOME' screen select the 'System' tab.
2. Select the 'Setup' tab.
3. Use the scroll wheel to go to the 'Network settings' ('Connect to the network') wizard.



4. Open this section with the confirmation button.
5. The screen displays the **current** network settings:
  - 'IP address'
  - 'Subnet mask'
  - 'Def. gateway'
  - 'DNS'
  - 'Prim. WINS'
  - 'Sec. WINS'

- 'Netw. speed'



6. Two options are possible:

- Press the 'Cancel' key in case you only want to read and check the network settings.
- Press the 'Begin' key in case you want to adapt the network settings.

Follow the wizard to fill in the network settings.

## Check or adapt the security settings

### Introduction

The 'Security' wizard on the printer user panel gives the option to check or adapt the security settings of the system.




#### **Caution:**

Detailed network knowledge is needed to change the security settings.


---

### How to check or adapt

1. From the 'HOME' screen select the 'System' tab.
2. Select the 'Setup' tab.
3. Use the scroll wheel to go to the 'Security' ('Configure settings') wizard.



4. Open this section with the confirmation button.
5. The screen displays the security level and the active network access options:



6. Two options are possible:
  - Press the 'Back' key in case you only want to check the security settings.
  - Press the 'Next >' key in case you want to adapt the security level.  
Follow the wizard to adapt the security level.

---

Overview of the security levels and the network access options:

'Security level:'	'Network access options:'
'Normal'	'LPR printing, FTP scan-to-file (passive mode), DHCP' 'HTTP (and Océ Express WebTools), FTP printing, FTP data retrieval (active mode)' 'SNMP, DNS, SMB, FTP scan-to-file (active mode)'
'Medium'	'LPR printing, FTP scan-to-file (passive mode), DHCP' 'HTTP (and Océ Express WebTools), FTP printing, FTP data retrieval (active mode)'
'High'	'LPR printing, FTP scan-to-file (passive mode), DHCP'





# **Appendix A**

## **Specifications of the Océ ColorWave 300**

## Specifications Océ ColorWave 300 printer

Technology	Thermal inkjet with Océ Dynamic Switching.
Print heads	9 Semi-permanent print heads with 640 nozzles. <ul style="list-style-type: none"> <li>■ 3 Black print heads (Pigment ink)</li> <li>■ 2 Cyan print heads</li> <li>■ 2 Magenta print heads</li> <li>■ 2 Yellow print heads.</li> </ul>
Print resolution	True: 600 dpi x 600 dpi.
Ink tanks	Black ink: 200 or 400 ml disposable ink tanks. Color ink (CMY): 180 or 350 ml disposable ink tanks.
Ink level monitoring	Ink level indication on the printer user panel and remote. Out of ink signalling.
Print speed	Black&White <ul style="list-style-type: none"> <li>■ 1 Ao ('E' size)(portrait) per 41 seconds.</li> </ul> Color <ul style="list-style-type: none"> <li>■ 1 Ao ('E' size) (portrait) per 1 minute and 3 seconds.</li> </ul>
Maximum productivity	Grayscale <ul style="list-style-type: none"> <li>■ 65 m<sup>2</sup>/h</li> <li>■ 699.5 ft<sup>2</sup>/h</li> </ul> Color <ul style="list-style-type: none"> <li>■ 48 m<sup>2</sup>/h</li> <li>■ 516.5 ft<sup>2</sup>/h</li> </ul>
Minimum pen thickness	0.080 mm 0.0031 inch
Media sources	2 front loadable rolls
Media core diameter	2" (50 millimeters) Optional: 3" (76.2 millimeters)
Maximum roll length	120 meters 393.7 ft
Output delivery	Front-accessible 'Lower receiving tray' (standard) Top delivery tray (optional) Folder (optional)

Output sizes	<p>Width</p> <ul style="list-style-type: none"> <li>■ 279 millimeters - 914 millimeters</li> <li>■ 11 inch - 36 inch</li> </ul> <p>Length</p> <ul style="list-style-type: none"> <li>■ 210 millimeters - 45 meters (might influence side margins when &gt; 5 meters)</li> <li>■ 8 inch - 147.6 ft (might influence side margins when &gt; 16.4 ft)</li> </ul>
Drawing margins	<ul style="list-style-type: none"> <li>■ Leading and trailing strip: 3 millimeters (0.12 inch)</li> <li>■ Left and right side: 3 millimeters (0.12 inch)</li> </ul>
Width detection	Automatic
Media types	<ul style="list-style-type: none"> <li>■ Uncoated papers</li> <li>■ Recycled papers</li> <li>■ Coated papers</li> <li>■ Transparent papers</li> <li>■ Photo papers</li> <li>■ Films</li> </ul> <p>See: <a href="http://www.mediaguide.oce.com">www.mediaguide.oce.com</a></p>
Media weight	<p>56 g/m<sup>2</sup> - 175 g/m<sup>2</sup> 20 lb - 24 lb</p>
Calibration	<ul style="list-style-type: none"> <li>■ Automatic print head alignment</li> <li>■ Failing nozzle compensation</li> <li>■ Unattended printing in the overnight mode.</li> </ul>
Dimensions	<ul style="list-style-type: none"> <li>■ 1461 mm x 790 mm x 2000 mm (H x D x W) 58 inch x 31 inch x 79 inch (H x D x W) Including receiving tray and excluding the 'Top Delivery Tray'</li> </ul>
Voltage	100 - 240 V
Frequency	50 / 60 Hz
Ampere	2 - 4 A
Power consumption	<ul style="list-style-type: none"> <li>■ Active mode (Printing) Engine (printer + scanner): 201 W, Controller: 39W</li> <li>■ Ready mode (Standby) Engine (printer + scanner): 146 W, Controller: 39W</li> <li>■ Sleep mode Engine (printer + scanner): 3 W EPA Energy Star<sup>®</sup></li> </ul>

## Specifications Océ ColorWave 300 printer

---

Weight print engine	180 kg 397 lbs
Weight top delivery tray (optional)	37 kg 81.6 lbs
Safety approvals	Energy Star <sup>®</sup> , TÜV, GS, CETECOM, CE, UL, (c)UL, CB, FCC, RoHS, FEMP

## Specifications Océ Scanner Express

Technology	<ul style="list-style-type: none"> <li>■ Contact Image Sensor (CIS) with Océ Colour Image Logic® technology</li> </ul>
Scan speed	<ul style="list-style-type: none"> <li>■ Monochrome: Up to 11.6 meters/minute (38 feet/minute)</li> <li>■ Color: 4 meters/minute (13 feet/minute)</li> </ul>
Scan-to-file scan speed	<p>Black&amp;white</p> <ul style="list-style-type: none"> <li>■ Standard: 2.9 meters/minute (9.5 feet/minute)</li> <li>■ Maximum: 11.7 meters/minute (38.4 feet/minute)</li> </ul> <p>Color</p> <ul style="list-style-type: none"> <li>■ 3.9 meters/minute (12.8 feet/minute)</li> </ul>
Scan resolution	600 dpi x 600 dpi optical
Camera	<p>5 x A4 CIS sensors  22000 Pixels  24 bits color  Illumination: LED (R/G/B)</p>
Original feed	Center aligned
Original width and length	<p>Width</p> <ul style="list-style-type: none"> <li>■ Minimum 208 millimeters (8.2 inch)</li> <li>■ Maximum 914 millimeters (36 inch)</li> </ul> <p>Length</p> <ul style="list-style-type: none"> <li>■ Minimum 208 mm (8.2 inch)</li> <li>■ Maximum 16 meters (52.5 feet)</li> </ul>
Original thickness	Up to 0.8 millimeter (0.03 inch) (non-rigid media)
Scaling	Scale to standard format and custom scale 10% - 1000% (0.1% fixed step interval)
Preset modes	<ul style="list-style-type: none"> <li>■ Grayscale:  Lines&amp;Text, Grays&amp;Lines, Dark Original, Blueprint, Photo, Transparent, 'Folded line/text'</li> <li>■ Color:  Photo, Lines/text, Map, Artwork, 'Folded line/text'.</li> </ul>
Number of copies	1 - 999 (scan once print many)
Color space	sRGB

Image editing	<ul style="list-style-type: none"><li>■ 'Remove strip' (Top/Bottom/Left/Right)</li><li>■ Mirroring horizontal</li><li>■ Delete area</li></ul>
Other functions	<ul style="list-style-type: none"><li>■ Pre-programming of next job</li><li>■ Programmable default settings</li><li>■ Synchro cut mode or standard size cut</li><li>■ Leading and trailing strip adjustment (0 mm - 400 mm) (0 inch - 15.8 inch)</li><li>■ Concurrent scanning and printing</li><li>■ Scan to file Black&amp;White / Grayscale / Color</li><li>■ Scan to 'TIFF', 'TIFF multipage', 'PDF/A', 'PDF multipage', 'JPEG', 'CALS'.</li></ul>
Weight scanner	<ul style="list-style-type: none"><li>■ 24.5 kg 53.9 lbs</li></ul>

## Specifications Océ PowerM controller

### Océ PowerM controller hardware

Platform	Embedded Océ PowerM controller with Windows® XP embedded
Memory	1 Gb
Hard disk capacity	160 Gb. One single high speed hard disk.
Graphical user interface	None
Standard interface	Ethernet 100 Mb/s, 1Gb/s
Optional interfaces	None
Network protocols	TCP/IP, IPv4, IPv6, IPsec, Windows® APIPA
Printing protocols	LPR, FTP
Scanning protocols	FTP, SMB
Applicable software	Océ PowerM controller software
Security	Electronic file shredding permanently removes all traces of deleted jobs on the controller. Complies with DoD 522-22M standard. IPsec secures Internet Protocol communications between the client and the printer
Client OS support	Océ Windows driver for Windows® Vista (32 & 64bits), XP, Server 2003, Server 2008 and Windows 7. Windows® Terminal Server, Citrix Metaframe and presentation server Océ Postscript3 driver for Windows XP® and Server 2003. MacOS v9, OSX. Océ Express WebTools for Windows® Internet Explorer and Mozilla®Firefox®

### Océ PowerM controller software

The Océ PowerM controller software consists of a basic module and a print module.

#### Basic module

Basic functions	File spooling on the controller. Concurrent receiving, processing, copying (or scanning) and printing of digital jobs.
-----------------	---

Basic applications	<ul style="list-style-type: none"> <li>■ Océ Express WebTools</li> <li>■ Océ Publisher Express</li> <li>■ Queue Management</li> <li>■ License Management</li> <li>■ Smart Inbox</li> <li>■ System Control Panel</li> <li>■ Settings Management</li> </ul>
Optional	<ul style="list-style-type: none"> <li>■ Océ Account Center.</li> </ul>

Print module

Scan and copy processing technology	Océ Image Logic
Number of prints	1 - 999 Set memory: send once, process once, print many
Roll selection and switching	Manual Automatic
Print manipulation	Rotation Auto-scaling Positioning Pen management Trailing strip adjustment; add up to 400 mm
Color modes scanner	<ul style="list-style-type: none"> <li>■ Grayscale</li> <li>■ Color</li> </ul>
Quality modes printer	<ul style="list-style-type: none"> <li>■ Standard</li> <li>■ Lines &amp; Text</li> <li>■ Poster</li> </ul>
Language sensing	Automatic Language Sensing (ALS)
Standard file formats	<ul style="list-style-type: none"> <li>■ Vector: HPGL, HPGL/2, Calcomp, DWF, DWF/X</li> <li>■ Raster: JPEG, HP-RTL, TIFF 6.o, NIFF, CALS-I, NIRS, C4, ASCII</li> </ul>
Cut length	<ul style="list-style-type: none"> <li>■ Standard cut</li> <li>■ Synchro cut</li> <li>■ Custom cut</li> </ul>
Optional	Adobe® PostScript 3™ PDF printing Adobe Asian Fonts for PS/PDF printing



## Specifications drivers and job submission software

### Océ Windows® Printer Driver

Software environment	Remarks
All Windows applications (for example, AutoCAD® 2000 family)	<p>This driver is a mixed raster-vector HP-GL/2 printer driver that allows you to print to your Océ printer from any application under one of the following supported Operating Systems.</p> <ul style="list-style-type: none"> <li>■ Windows® 7</li> <li>■ Windows 2000® Server</li> <li>■ Windows XP® (Sp2, Sp3) (32-bit and 64-bit)</li> <li>■ Windows Server® 2003 (Sp2) (32-bit and 64-bit)</li> <li>■ Windows Vista® (Sp1) (32-bit and 64-bit)</li> <li>■ Windows Server® 2008 (32-bit and 64-bit)</li> <li>■ Citrix Presentation Server 3.x</li> <li>■ Citrix Presentation Server 4.x</li> <li>■ Citrix Metaframe</li> </ul> <p>The driver is compatible with the Novell iPrint and NDPS environments (installation, propagation and printing).</p>



**Note:**

Visit Océ on the Internet at [www.oce.com](http://www.oce.com) for the latest information.

## Océ PostScript® 3™ Driver

Software environment	Remarks
Graphical application software	<p>This driver allows you to print to your Océ printer from any application under one of the following supported Operating Systems.</p> <ul style="list-style-type: none"> <li>■ Windows 2000®</li> <li>■ Windows 2000® Server</li> <li>■ Windows XP® (x86), without signature</li> <li>■ Windows Server® 2003 (x86)</li> <li>■ Windows Vista®, without signature</li> <li>■ Citrix Presentation Server 3.x</li> <li>■ Citrix Presentation Server 4.x</li> <li>■ Citrix Metaframe</li> <li>■ Macintosh Mac OS 9.x</li> <li>■ Macintosh Mac OS 10.x</li> </ul>



**Note:**

Visit Océ on the internet at [www.oce.com](http://www.oce.com) for the latest information.

## Optional application software

Function	Application software
Job submission	<ul style="list-style-type: none"> <li>■ Océ Repro Desk Studio</li> </ul>

## Preferred Océ media names

### Introduction

The following preferred media names are supported by the Océ ColorWave 300. Four categories of media names are defined:

- Paper
- Coated paper
- Photopaper
- Transparencies & Films

### Supplies

A media guide with the latest information is available on the website:

<http://www.mediaguide.oce.com/>

Here you can find the media that your product supports, for example. You can also find more information about supplies for your product, such as print heads. You can also order new supplies directly through the website.

### Media category: Paper

Paper

	'Media type' on the user interface	'Media label' on the media box	Compatible media
1	'Paper 70-80g'	IJM005: Océ Draft Paper 75 g/m <sup>2</sup>	IJM009: Océ Draft Paper PEFC 75 g/m <sup>2</sup>
		IJM012: Océ Draft Plus Paper 80 g/m <sup>2</sup>	
2	'Recycled paper 70-80g'	IJM042: Océ Recycled Paper 80 g/m <sup>2</sup>	
3	'Paper 90g'	IJM021: Océ Standard Paper 90 g/m <sup>2</sup>	
		IJM022: Océ Standard PLUS Paper FSC 90 g/m <sup>2</sup>	

	'Media type' on the user interface	'Media label' on the media box	Compatible media
4	'Paper Japan 64g'	IPS-B: Océ Plain Paper 64 g/m <sup>2</sup>	
5	'Paper 56g'	IJMoo1: Océ Standard Paper (FSC) 56 g/m <sup>2</sup>	
6	'Paper 20 lb'	Ink Jet Bond: 86500 Océ Check Plot Bond 20 lb	
7	'Recycled paper 20 lb'	Ink Jet Bond: 86500R Océ Recycled Bond 20 lb	
8	'Paper 24 lb'	Ink Jet Bond: 86800 Océ Deluxe Bond 24 lb	
9	'Custom paper'		

### Media category: Coated Paper

Coated Paper

	'Media type' on the user interface	'Media label' on the media box	Compatible media
10	'Coated paper 90-130g'	IJM113: Océ Premium Paper FSC 90 g/m <sup>2</sup>	
		IJM119: Océ Premium Paper FSC 100 g/m <sup>2</sup>	
		IJM123: Océ Premium Paper FSC 130 g/m <sup>2</sup>	
		IJM131: Océ Premium Plus Paper 90 g/m <sup>2</sup>	
		IJM132: Océ Premium Plus Paper 120 g/m <sup>2</sup>	

	'Media type' on the user interface	'Media label' on the media box	Compatible media
11 / B	'High qual. coated paper 120-170g'	IJM149: Océ Smart Matt Paper (FSC) 120 g/m <sup>2</sup>	
		IJM150: Océ Smart Matt Paper (FSC) 170 g/m <sup>2</sup>	
		IJM151: Océ Smart Matt Paper 150 g/m <sup>2</sup>	
12	'Coated paper 24 lb'	Ink Jet Bond: 862024 Océ Premium Color Bond 24 lb	
		Ink Jet Bond: 861024 Océ Inkjet Color Bond 24 lb	
13	'Coated paper Japan'	IPC-U: Océ Coated Paper 80 g/m <sup>2</sup>	
14	'High qual. coated paper Japan'	IPP-J: Océ Premium Coated Paper 81 g/m <sup>2</sup>	
15	'Custom coated paper'		

**Media category: Photopaper**

Photopaper

	'Media type' on the user interface	'Media label' on the media box	Compatible media
16	'Photo gloss'	IJM222: Océ Top Photo Plus Gloss 195 g/m <sup>2</sup>	
		GIPPLS7: Océ Glossy Photo paper 7.6 mil	
		IPG-ZA: Océ Top Photo Plus Gloss 195 g/m <sup>2</sup>	
17	'Photo gloss (instant dry)'	IJM251: Océ Photo Gloss Paper 170 g/m <sup>2</sup>	IJM258: Océ Photo Gloss FSC 170 g/m <sup>2</sup>
		IPG: Océ Photo Gloss Paper 170 g/m <sup>2</sup>	
18	'Photo matte'	IJM229: Océ Top Photo Plus Matt Paper 195 g/m <sup>2</sup>	
		PMPLUS7: Océ Matte Photo Paper 7.6 mil	
19	'Photo semi-matte (instant dry)'	IJM257: Océ Semi-Matt Photo Paper 170 g/m <sup>2</sup>	
20	'Photo satin'	IJM240: Océ Top Photo Plus Satin 195 g/m <sup>2</sup>	IJM259: Océ Top Photo Satin FSC 170 g/m <sup>2</sup>
		SIPPLS7: Océ Satin Photo Paper 7.6 mil	
21	'Custom photo paper'		

## Media category: Transparencies & Films

### Transparencies & Films

	'Media type' on the user interface	'Media label' on the media box	Compatible media
22	'Transparent paper 90-112g'	IJM138: Océ Transparent Paper 90 g/m <sup>2</sup>	
		IJM140: Océ Transparent Paper 90 g/m <sup>2</sup>	
		IJM141: Océ Transparent Paper 112 g/m <sup>2</sup>	
23	'Transparent paper 16-18 lb'	Ink Jet Bond: Océ 860018 Translucent Bond 18 lb	
		Ink Jet Bond: Océ 860016 Translucent Bond 16 lb	
24	'Transparent paper Japan'	IPT: Tracing Paper 75 g/m <sup>2</sup>	

	'Media type' on the user interface	'Media label' on the media box	Compatible media
25	'Matte film'	IJM311: Océ Double Matt Film 110 µm	
		IJM320: Océ Double Matt Film Erasable 120 µm	
		Ink Jet Film: 868342 Océ Double Matte Film 4 mil	
		Ink Jet Film: 868632 Océ Double Matte Film 3 mil	
		IPF-E: Océ Matt Film 78 µm	
		IPF-H: Océ Matt Film 95 µm	
		IPF-J: Océ Matt Film 105 µm	
26	'White film gloss'	IJM345: Océ White Film Gloss 100 µm	IJM339: Océ Smart Dry White Film Gloss 125 µm
		FGPLS4: Océ Glossy White Film 4 mil	
27	'Clear film (side stripe)'	IJM332: Océ Clear Film Extra 110 µm	
		Ink Jet Film: 868340 Océ Clear Film w/ Side Stripe 4 mil	
28		IJM545: Océ Polyprop Outdoor Banner 200 µm	



	'Media type' on the user interface	'Media label' on the media box	Compatible media
29	'Custom film'		

## Media sizes

	Maximum	Minimum
Media width	914 millimeters 36 inch	297 millimeters 11 inch
Roll diameter	130 millimeters 5.1 inch	This is the outer diameter of a media roll
Core	50 millimeters 2 inch	Not applicable

# Typical drying times

## Introduction

The printer automatically adapts the default drying time. The default drying time depends on the following.

- The media type
- The ambient humidity
- The print mode.

When you print grayscale in the 'Check' quality mode, the system decreases the drying time to 20% of the default value.

You can change the drying time for all the media types. You can select a percentage of 100% - 999% of the default drying time.

## Typical drying times per media type

The following table describes typical drying times for Océ media under standard conditions (22 °C, 50% relative humidity).

Media drying times per media: Paper

	'Media type' on the user interface	'Media label' on the media box	Drying time (minutes ' and seconds ") without 'Top Delivery Tray'	Drying time (minutes ' and seconds ") with 'Top Delivery Tray'
1	'Paper 70-80g'	IJM005: Océ Draft Paper 75 g/m <sup>2</sup>	0"	0"
		IJM012: Océ Draft Plus Paper 80 g/m <sup>2</sup>		
2	'Recycled paper 70-80g'	IJM042: Océ Recycled Paper 80 g/m <sup>2</sup>	0"	0"

	'Media type' on the user interface	'Media label' on the media box	Drying time (minutes ' and seconds ") without 'Top Delivery Tray'	Drying time (minutes ' and seconds ") with 'Top Delivery Tray'
3	'Paper 90g'	IJMo21: Océ Standard Paper 90 g/m2	0"	0"
		IJMo22: Océ Standard PLUS Paper FSC 90 g/m2		
4	'Paper Japan 64g'	IPS-B: Océ Plain Paper 64 g/m2	0"	0"
5	'Paper 56g'	IJMoo1: Océ Standard Paper 56 g/m2	0"	0"
6	'Paper 20 lb'	Ink Jet Bond: 86500 Océ Check Plot Bond 20 lb	0"	0"
7	'Recycled paper 20 lb'	Ink Jet Bond: 86500R Océ Recycled Bond 20 lb	0"	0"
8	'Paper 24 lb'	Ink Jet Bond: 86800 Océ Deluxe Bond 24 lb	0"	0"
9	'Custom paper'		0"	0"

## Typical drying times

Media drying times per media: Coated Paper

	'Media type' on the user interface	'Media label' on the media box	Drying time (minutes ' and seconds ") without 'Top Delivery Tray'	Drying time (minutes ' and seconds ") with 'Top Delivery Tray'
10	'Coated paper 90-130g'	IJM113: Océ Premium Paper FSC 90 g/m2	0"	0"
		IJM119: Océ Premium Paper FSC 100 g/m2		
		IJM123: Océ Premium Paper FSC 130 g/m2		
		IJM131: Océ Premium Plus Paper 90 g/m2		
		IJM132: Océ Premium Plus Paper 120 g/m2		
11 / B	'High qual. coated paper 120-170g'	IJM149: Océ Smart Matt Paper 120 g/m2	0' 50"	1' 30"
		IJM150: Océ Smart Matt Paper 170 g/m2		
		IJM151: Océ Smart Matt Paper 150 g/m2		
12	'Coated paper 24 lb'	Ink Jet Bond: 862024 Océ Premium Color Bond 24 lb	0"	0"
		Ink Jet Bond: 861024 Océ Inkjet Color Bond 24 lb		

	'Media type' on the user interface	'Media label' on the media box	Drying time (minutes ' and seconds ") without 'Top Delivery Tray'	Drying time (minutes ' and seconds ") with 'Top Delivery Tray'
13	'Coated paper Japan'	IPC-U: Océ Coated Paper 80 g/m2	0"	0"
14	'High qual. coated paper Japan'	IPP-J: Océ Premium Coated Paper 81 g/m2	0"	1' 40"
15	'Custom coated paper'		0"	0"

Media drying times per media: Photopaper

	'Media type' on the user interface	'Media label' on the media box	Drying time (minutes ' and seconds ") without 'Top Delivery Tray'	Drying time (minutes ' and seconds ") with 'Top Delivery Tray'
16	'Photo gloss'	IJM222: Océ Top Photo Plus Gloss 195 g/m2	4' 10"	10' 0"
		GIPPLS7: Océ Glossy Photo paper 7.6 mil		
		IPG-ZA: Océ Top Photo Plus Gloss 195 g/m2		
17	'Photo gloss (instant dry)'	IJM251: Océ Photo Gloss Paper 170 g/m2	0"	0"
		IPG: Océ Photo Gloss Paper 170 g/m2		

Typical drying times

	'Media type' on the user interface	'Media label' on the media box	Drying time (minutes ' and seconds ") without 'Top Delivery Tray'	Drying time (minutes ' and seconds ") with 'Top Delivery Tray'
18	'Photo matte'	IJM229: Océ Top Photo Plus Matt Paper 195 g/m2	4' 10"	10' 0"
		PMPLUS7: Océ Matte Photo Paper 7.6 mil		
19	'Photo semi-matte (instant dry)'	IJM257: Océ Semi-Matt Photo Paper 170 g/m2	0"	0"
20	'Photo satin'	IJM240: Océ Top Photo Plus Satin 195 g/m2	4' 10"	9' 40"
		SIPPLS7: Océ Satin Photo Paper 7.6 mil		
21	'Custom photo paper'		4' 10"	10' 0"

Media drying times per media: Transparencies & Films

	'Media type' on the user interface	'Media label' on the media box	Drying time (minutes ' and seconds ") without 'Top Delivery Tray'	Drying time (minutes ' and seconds ") with 'Top Delivery Tray'
22	'Transparent paper 90-112g'	IJM138: Océ Transparent Paper 90 g/m2	2' 35"	Not allowed
		IJM140: Océ Transparent Paper 90 g/m2		
		IJM141: Océ Transparent Paper 112 g/m2		
23	'Transparent paper 16-18 lb'	Ink Jet Bond: Océ 860018 Translucent Bond 18 lb	0' 28"	Not allowed
		Ink Jet Bond: Océ 860016 Translucent Bond 16 lb		
24	'Transparent paper Japan'	IPT: Tracing Paper 75 g/m2	0' 55"	Not allowed

Typical drying times

	'Media type' on the user interface	'Media label' on the media box	Drying time (minutes ' and seconds ") without 'Top Delivery Tray'	Drying time (minutes ' and seconds ") with 'Top Delivery Tray'
25	'Matte film'	IJM311: Océ Double Matt Film 110 um	1' 25"	Not allowed
		IJM320: Océ Double Matt Film Erasable 120 um		
		Ink Jet Film: 868342 Océ Double Matte Film 4 mil		
		Ink Jet Film: 868632 Océ Double Matte Film 3 mil		
		IPF-E: Océ Matt Film 78 um		
		IPF-H: Océ Matt Film 95 um		
		IPF-J: Océ Matt Film 105 um		
26	'White film gloss'	IJM345: Océ White Film Gloss 100 um	2' 35"	Not allowed
		FGPLS4: Océ Glossy White Film 4 mil		
27	'Clear film (side stripe)'	IJM332: Océ Clear Film Extra 110 um	3' 20"	Not allowed
		Ink Jet Film: 868340 Océ Clear Film w/ Side Stripe 4 mil		
28	'Custom film'		2' 35"	Not allowed



## Standard scale factor

### Introduction

The Océ ColorWave 300 can scale (reduce and enlarge) the image to a defined format. The overview below shows the scale factor if you need to copy on media of different sizes.



**Caution:**

If you select the wrong scale factor you can lose information.

### Supported DIN media series

The table shows the scale factor if you copy from one media size (original column) to another media size (first row)

DIN table

Originals	Standard scale fixed steps for the DIN media series [%]						
	A0	A1	A2	A3	36 Inch	B1	B2
A0	100	71	50	35	109	84	59
A1	141	100	71	50	153	119	84
A2	200	141	100	71	218	168	119
A3	283	200	141	100	308	238	168
36 Inch	107	65	46	32	100	77	55
B1	119	84	59	42	129	100	71
B2	168	119	84	59	183	141	100

### Generic ISO media series

The table shows the scale factor if you copy from one media size (original column) to another media size

ISO table

Originals	Standard scale fixed steps for the ISO media series [%]					
	A0	A1	A2	A3	A4	A5
A0	100	71	50	35	-	-
A1	141	100	71	50	35	-
A2	200	141	100	71	50	35

Originals	Standard scale fixed steps for the ISO media series [%]					
	A0	A1	A2	A3	A4	A5
A <sub>3</sub>	283	200	141	100	71	50
A <sub>4</sub>	400	283	200	141	100	77
A <sub>5</sub>	565	400	283	200	141	100

# **Appendix B**

## **Reader's comment sheet**

# Reader's comment sheet

## Questions

Have you found this manual to be accurate?

- Yes
- No

Were you able to operate the product, after reading this manual?

- Yes
- No

Does this manual provide sufficient background information?

- Yes
- No

Is the format of this manual convenient in size, readability and arrangement (page layout, chapter order, etc.)?

- Yes
- No

Could you find the information you were looking for?

- Always
- Most of the times
- Sometimes
- Not at all

What did you use to find the required information?

- Table of contents
- Index

Are you satisfied with this manual?

- Yes
- No

Thank you for evaluating this manual.

If you have other comments or concerns, please explain or suggest improvements overleaf or on a separate sheet.

**Comments:**

-----  
-----  
-----  
-----

-----  
-----  
**Date:**

This reader's comment sheet is completed by:  
(If you prefer to remain unknown, please do fill in your occupation)

**Name:**

**Occupation:**

**Company:**

**Phone:**

**Address:**

**City:**

**Country:**

Please return this sheet to:

Océ-Technologies B.V.  
For the attention of ITC User Documentation.  
P.O. Box 101,  
5900 MA Venlo  
The Netherlands

Send your comments by E-mail to: [itc-userdoc@oce.com](mailto:itc-userdoc@oce.com)

For the addresses of local Océ organisations see: <http://www.oce.com>

# Index

- 2D CAD monochrome**
    - 2D CAD monochrome .....230
  - 3D CAD**
    - Color .....232
  - 3D CAD drawings and rendering**
    - 3D CAD drawings and rendering .....231
- A**
- Active job**
    - delete .....154, 156
    - pause .....154
    - resume .....154
    - stop .....154
  - Add a strip**
    - bottom .....202
    - top .....202
  - Alignment**
    - description .....191
  - Authorizations**
    - Océ Express WebTools .....102
  - Auto-feed the original**
    - description .....162, 180
  - Available documentation**
    - Océ ColorWave 300 .....16
    - Océ Express WebTools .....16
    - Océ PostScript® 3 Driver .....17
    - Océ Windows® Printer Driver .....17
- B**
- Background compensation**
    - description .....137, 143
  - Basic**
    - copy job .....182
    - scan job .....164
  - Browser security settings**
    - Browser security settings .....81
  - Business color**
    - Color .....233
  - Business graphics**
    - Color .....232
- C**
- CAD drawings: Color**
    - CAD drawings: Color .....231
  - Calibrate the scanner**
    - description .....226, 302
  - Calibration**
    - sheet .....226, 302
    - wizard .....226, 302
  - Change**
    - a setting in the Océ Express WebTools .....92
    - passwords in the Océ Express WebTools .....105
    - the language of the Océ Express WebTools .....90
    - the regional settings .....112
  - Check**
    - the settings in the Océ Express WebTools .....95
    - your licenses .....326
  - Clean the scanner**
    - description .....299
  - Clear**
    - an original jam .....317
    - the system .....159
  - Color feel**
    - Color feel .....243
  - Color feel for DWF**
    - description .....131, 241
  - Color feel for HP-GL, HP-GL/2 and HP-RTL**
    - description .....128, 238
  - Color feel for PostScript and PDF**
    - description .....130, 240
  - Color feel for TIFF and JPEG**
    - description .....129, 239
  - Color Management**
    - Overview settings .....238
  - Color mode**
    - black and white .....175
    - color .....174
    - grayscale .....175
  - Color reference chart**
    - Color reference chart .....261
  - Colors**
    - Output quality problems .....266
  - Components**
    - Océ Scanner Express .....34
  - Components: system**
    - Components: system .....27
  - Concept**
    - copy functionality .....21
    - default settings .....123

- 
- green button principle .....21
  - Océ Express WebTools controller application .....22
  - print jobs .....22
  - printer configuration .....21
  - scan functionality .....21
  - Smart Inbox and Jobs Queue .....145
  - templates .....21
  - USB .....21
  - Configuration**
    - sleep mode .....113
  - Configuration tab**
    - Océ Express WebTools .....86
  - Configure**
    - local scan destinations .....117
    - network settings .....114
    - remote scan destinations .....118
    - the pen settings .....122
    - the regional settings .....112
  - Connect**
    - mains supply cable .....46
  - Consumables**
    - Consumables .....44
  - Consumer graphics**
    - Color .....235
  - Controller**
    - hardware specifications .....351
    - software specifications .....351
  - Copy example**
    - a specific area of an original .....206
    - add a strip .....202
    - erase a specific area of an original .....208
    - Fast CAD b/w copy .....69
    - Fast CAD color copy .....65
    - multiple sets .....197
    - Normal color copy .....67
    - remove a strip .....204
    - scale to another media size .....200
    - with a stamp .....199
  - Copy jobs**
    - basic .....182
    - clear an original jam .....317
    - default output quality .....136
    - defaults .....133
    - description .....178, 184
    - extended .....185
    - settings overview .....187
  - Copy quality**
    - problem .....226, 302
  - Copy templates**
    - description .....133
  - Create**
    - a network destination with SMB .....119
    - a web destination with FTP .....118
    - Smart Inbox .....150
  - Current date and time**
    - description .....112
  - Cut method**
    - description .....190
  - D**
  - Date format**
    - description .....112
  - Default output quality**
    - for copy jobs .....136
    - for print jobs .....128
    - for scan jobs .....142
  - Default passwords**
    - Océ Express WebTools .....105
  - Default settings**
    - copy jobs .....133
    - print jobs .....126
    - scan jobs .....139
    - system .....124
  - Default settings concept**
    - Default settings concept .....123
  - Define**
    - the copy job preferences and copy templates ..133
    - the default output quality for copy jobs .....136
    - the default output quality for print jobs .....128
    - the default output quality for scan jobs .....142
    - the print job defaults .....126
    - the scan job preferences and copy templates ..139
    - the system defaults .....124
  - Define the delete area dimensions**
    - length .....208
    - width .....208
    - x offset .....208
    - y offset .....208
  - Delete**
    - active job .....154, 156
    - Smart Inbox .....151
  - Delivery**
    - description .....190
  - Demo prints**
    - Demo prints .....256
  - Destination**
    - description .....168
  - DIN media series**
-

- 
- DIN media series .....369
  - Download**
    - media profile .....251
    - media profile from the Océ web site .....251
  - Drawing method**
    - description .....195
  - Driver**
    - Océ PostScript® 3™ Driver .....354
    - Océ Windows® Printer Driver .....353
  - Drying time: typical drying times per media type**
    - Drying time: typical drying times per media type .....362
  - E**
  - E-shredding**
    - algorithm .....110
    - Disable .....109
    - Enable .....109
    - Number of overwrite passes .....111
  - Edit a setting**
    - Océ Express WebTools .....92
  - Enhanced colors: Rendering intent**
    - Enhanced colors: Rendering intent .....246
  - Enhanced colors: RGB input data:**
    - Enhanced colors: RGB input data: .....244
  - Erase a specific area**
    - description .....208
  - Erase area**
    - description .....193
  - Erase margins**
    - bottom .....176, 204
    - description .....172, 192
    - left .....176, 204
    - right .....176, 204
    - top .....176, 204
  - Error codes**
    - Printhead .....308
  - Error messages**
    - Printer .....308
  - Errors: Carriage away from home position too long**
    - Errors: Carriage away from home position too long .....316
  - Errors: Cover or door opened**
    - Errors: Cover or door opened .....310
  - Errors: Temperature or humidity out of range**
    - Errors: Temperature or humidity out of range .....315
  - Errors: types**
    - Errors: types .....308
  - Extended**
    - copy job .....185
    - scan job .....166
  - F**
  - Factory defaults**
    - restore .....98
  - Feed the original**
    - description .....161, 179
  - File type**
    - description .....144, 168
    - scan to file .....174
  - Fill ink tube**
    - Fill ink tube .....293
  - Firefox 2 / 3**
    - minimum browser security settings .....82
  - Firefox 4**
    - minimum browser security settings .....82
  - First language**
    - description .....112
  - Footprint**
    - printing system .....28
  - FTP**
    - FTP .....218
  - G**
  - Graininess**
    - Output quality problems .....263
  - H**
  - Humidity**
    - Humidity .....268, 362
  - I**
  - Icons**
    - job states .....157
    - scanner states .....100
    - system states .....99
  - Ink tank: place**
    - Ink tank: place .....282
  - Ink tank: remove**
    - Ink tank: remove .....281
  - Ink tank: replace**
    - Ink tank: replace .....281
  - Ink tube: refill**
    - Ink tube: refill .....293
-



- 
- Input profile**
    - Input profile .....253–254
  - Install a new license**
    - Install a new license .....329
  - Internet Explorer 7 / 8 / 9**
    - minimum browser security settings .....81
  - IPSec**
    - Enable .....106
  - IPv6**
    - Enable .....107
  - ISO media series**
    - ISO media series .....369
- J**
- Jammed media: Remove**
    - Jammed media: Remove .....313
  - Job**
    - delete .....154, 156
    - pause .....154
    - resume .....154
    - stop .....154
  - Job states**
    - Queue .....157
    - Smart Inbox .....157
  - Job submission**
    - description .....210
    - FTP .....218
    - LPR .....219
    - Océ Windows ® Printer Driver .....61, 214
  - Jobs Queue**
    - concept .....145
  - Jobs tab**
    - Océ Express WebTools .....83
- K**
- Key operator**
    - description .....102
  - Knowledge base**
    - Knowledge base .....14
- L**
- License**
    - demo .....324
    - resale .....324
  - Licenses**
    - Licenses .....320
    - activation .....322
  - check .....326
  - install .....329
  - overview .....323
  - save .....328
  - upload .....329
  - Lighter/darker**
    - description .....138, 144, 173, 195
  - Load**
    - settings from a file .....97
  - Load media roll**
    - Load media roll .....50, 278
  - Local scan destination**
    - configure .....117
    - description .....115
  - Log in**
    - Océ Express WebTools .....103
  - Log out**
    - Log out .....104
  - Logo**
    - Color .....233
  - LPR**
    - LPR .....219
- M**
- Main components**
    - Océ ColorWave 300 .....26
  - Mains supply cable**
    - connect .....46
  - Maintenance cassette: Place**
    - Maintenance cassette: Place .....292
  - Maintenance cassette: Remove**
    - Maintenance cassette: Remove .....290
  - Make a copy**
    - and add a strip .....202
    - and delete a specific area of an original .....208
    - and erase margins .....204
    - of a specific area of an original .....206
  - Make a Scan**
    - and erase margins .....176
  - Make multiple sets of copies**
    - description .....197
  - Managing licenses**
    - Managing licenses .....320
  - Map**
    - Color .....233
  - Margins**
    - erase .....176, 204
  - Measurement unit**
    - description .....112
-

- 
- Media**
    - description .....189
  - Media profile**
    - Media profile .....248–249
    - download .....251
  - Media roll: load**
    - Media roll: load .....50, 278
  - Media roll: remove**
    - Media roll: remove .....48, 276
  - Media series**
    - description .....112
  - media types**
  - Minimum browser security settings for Océ Express WebTools**
    - for Firefox 2 / 3 .....82
    - for Firefox 4 .....82
    - for Internet Explorer 7 / 8 / 9 .....81
  - Mixed content**
    - Color .....237
- N**
- Network settings**
    - configure .....114
  - Network settings: Adapt**
    - Network settings: Adapt .....340
  - Network settings: Check**
    - Network settings: Check .....340
  - Number of overwrite passes**
    - Number of overwrite passes .....111
- O**
- Océ Account Center**
    - Overview .....337
  - Océ ColorWave 300**
    - footprint .....28
    - main components .....26
  - Océ Enhanced colors: CMYK input data**
    - Océ Enhanced colors: CMYK input data .....245
  - Océ Express WebTools**
    - change the language .....90
    - change the regional settings .....112
    - configure the network settings .....114
    - edit a setting .....92
    - load the settings from a file .....97
    - log in .....103
    - passwords .....105
    - save the settings in a file .....96
    - System requirements .....81
    - the configuration tab .....86
    - the jobs tab .....83
    - the preferences tab .....85
    - the support tab .....87
    - the system tab .....89
    - user roles and authorizations .....102
    - view and check the settings .....95
  - Océ License Logic**
    - access .....323
  - Océ Media Profile**
    - Océ Media Profile .....248
  - Océ PostScript® 3 Driver**
    - print .....63, 216
  - Océ PostScript® 3™ Driver**
    - specifications .....354
  - Océ PowerM controller**
    - hardware specifications .....351
  - Océ Publisher Express**
    - print .....57, 211
  - Océ Remote Patch**
    - Océ Remote Patch .....304
  - Océ Repro Desk Studio**
    - Overview .....336
  - Océ Scanner Express**
    - Specifications .....349
  - Océ Windows® Printer Driver**
    - Océ Windows® Printer Driver .....61, 214
  - Océ Windows® Printer Driver**
    - specifications .....353
  - OIP file**
    - OIP file .....253–254
  - OKB**
    - OKB .....14
  - OMP file**
    - OMP file .....248–249
  - Omp.file**
    - Omp.file .....251
  - Open**
    - the system monitor .....99
  - Optimize Output quality**
    - Optimize Output quality .....268
  - Optimize print quality**
    - Optimize print quality .....273
  - Optional application software**
    - specifications .....354
  - Original**
    - auto-feed .....162, 180
    - description .....170, 187
    - feed .....161, 179
  - Original jam**
-

description .....	317	configure .....	122
<b>Original type color copy</b>		<b>Photo</b>	
description .....	136	Color .....	236
<b>Original type grayscale copy</b>		<b>Photo realistic impression</b>	
description .....	136	Photo realistic impression .....	235
<b>Original type when scanning to color</b>		<b>Place: Maintenance cassette</b>	
description .....	142	Place: Maintenance cassette .....	292
<b>Original type when scanning to grayscale or black-and-white</b>		<b>Place: Print heads</b>	
description .....	142	Place: Print heads .....	287
<b>Output</b>		<b>Point of sales graphics</b>	
description .....	190	Color .....	234
<b>Output quality</b>		<b>Power user</b>	
Output quality .....	224, 229	description .....	102
for copy jobs .....	136	<b>Preferences</b>	
for print jobs .....	128	copy jobs .....	133
for scan jobs .....	142	default output quality for copy jobs .....	136
<b>Output quality problems</b>		default output quality for print jobs .....	128
Colors .....	266	default output quality for scan jobs .....	142
Graininess .....	263	print jobs .....	126
Overview .....	263	scan jobs .....	139
Stripes and Banding .....	264	system .....	124
Waves / Cockle .....	266	<b>Preferences tab</b>	
<b>Output quality problems: solutions</b>		Océ Express WebTools .....	85
Output quality problems: solutions .....	268	<b>Print</b>	
<b>Output quality: Optimize</b>		from a USB mass storage device .....	56, 221
Output quality: Optimize .....	268	from Océ Publisher Express .....	57, 211
<b>Output type</b>		from the Océ PostScript® 3 Driver .....	63, 216
Output type .....	229	from the Smart Inbox .....	60, 220
<b>Overview</b>		<b>Print heads: Place</b>	
available documentation .....	16	Print heads: Place .....	287
copy job settings .....	187	<b>Print heads: Remove</b>	
Océ Account Center .....	337	Print heads: Remove .....	285
Océ Repro Desk Studio .....	336	<b>Print job submission</b>	
Output quality problems .....	263	description .....	210
scan job settings .....	168	<b>Print jobs</b>	
scanner states .....	100	default output quality .....	128
system states .....	99	defaults .....	126
<b>Overview settings</b>		<b>Print mode</b>	
Color Management .....	238	description .....	187
<b>Overview: system</b>		<b>Print quality</b>	
Overview: system .....	27	description .....	128, 137
<b>P</b>		<b>Print quality: Optimize</b>	
<b>Passwords</b>		Print quality: Optimize .....	273
Océ Express WebTools .....	105	<b>Print speed</b>	
<b>Pause</b>		Print speed .....	229
active job .....	154	<b>Printer</b>	
<b>Pen settings</b>		Error messages printer .....	308
		System messages printer .....	308
		working area .....	28
		<b>Printhead</b>	

- 
- Error codes .....308
  - Printheads: Replace**
  - Printheads: Replace .....284
  - Printing of gray colors**
  - description .....132
  - Printing system**
  - footprint .....28
  - switch off .....77
  - switch on .....47
- Q**
- Quality**
  - copy jobs .....136
  - print jobs .....128
  - problem .....226, 302
  - scan jobs .....142
  - Quality check print**
  - Quality check print .....258
  - Quality modes: check**
  - Quality modes: check .....228
  - Quality modes: presentation**
  - Quality modes: presentation .....228
  - Quality modes: release**
  - Quality modes: release .....228
  - Queue**
  - job states .....157
- R**
- Refill: ink tube**
  - Refill: ink tube .....293
  - Regional settings**
  - change .....112
  - Relation between output quality parameters**
  - Relation between output quality parameters ..229
  - Remote scan destination**
  - configure .....118
  - description .....115
  - Remove**
  - all jobs from the system .....159
  - Remove media roll**
  - Remove media roll .....48, 276
  - Remove: Jammed media**
  - Remove: Jammed media .....313
  - Remove: Maintenance cassette**
  - Remove: Maintenance cassette .....290
  - Remove: Print heads**
  - Remove: Print heads .....285
  - Replace printheads**
  - Replace printheads .....284
  - Replace: ink tank**
  - Replace: ink tank .....281
  - Resolution**
  - description .....143, 170
  - Restart**
  - description .....101
  - Restore factory defaults**
  - Restore factory defaults .....98
  - Resume**
  - active job .....154
- S**
- Save**
  - settings in a file .....96
  - Save active licenses**
  - Save active licenses .....328
  - Scale**
  - description .....189
  - Scale formats**
  - Standard .....369
  - Scale to another media size**
  - description .....200
  - Scan destinations**
  - local .....115, 117
  - remote .....115
  - remote via FTP .....118
  - remote via SMB .....118
  - Scan example**
  - CAD drawing to b/w TIFF format .....73
  - color CAD drawing to PDF format .....71
  - remove a strip .....176
  - Scan to a USB mass storage device .....75
  - Scan jobs**
  - basic .....164
  - clear an original jam .....317
  - default output quality .....142
  - defaults .....139
  - description .....160, 165
  - extended .....166
  - settings overview .....168
  - Scan quality**
  - problem .....226, 302
  - Scan templates**
  - description .....139
  - Scan to file**
  - compression method .....174
  - file type .....174
  - organization .....174
-

- 
- Scan-to-file**
    - color mode: black and white .....175
    - color mode: color .....174
    - color mode: grayscale .....175
  - Scanner**
    - calibration .....226, 302
    - clean .....299
    - Specifications .....349
  - Scanner calibration sheet**
    - description .....226, 302
  - Scanner original jam**
    - description .....317
  - Scanner states**
    - overview .....100
  - Second language**
    - description .....112
  - Security settings: Adapt**
    - Security settings: Adapt .....342
  - Security settings: Check**
    - Security settings: Check .....342
  - Send print jobs**
    - description .....210
  - Sets**
    - copy .....197
  - Settings**
    - change .....92
    - restore defaults .....98
    - view and check .....95
  - Settings file**
    - load .....97
    - save .....96
  - Settings overview**
    - copy jobs .....187
    - scan jobs .....168
  - Sheet size**
    - description .....190
  - Shut down**
    - description .....101
  - Sleep mode**
    - configuration .....113
  - Smart Inbox**
    - concept .....54, 145
    - create .....150
    - delete .....151
    - job states .....157
    - multiple-user environment .....148
    - print .....60, 220
    - repro environment .....149
  - Software controller**
    - specifications .....351
  - Sort**
    - description .....196
  - Specific area**
    - description .....206
  - Specifications**
    - Controller software .....351
    - Océ PostScript® 3™ Driver .....354
    - Océ PowerM controller .....351
    - Océ Windows® Printer Driver .....353
    - optional application software .....354
    - scanner .....349
  - Specifications: Media sizes**
    - Specifications: Media sizes .....361
  - Specifications: Printer**
    - Specifications: Printer .....346
  - Stamp**
    - description .....194, 199
  - Standard scale formats**
    - Standard scale formats .....369
  - Stop**
    - active job .....154
  - Strip**
    - add a leading strip .....202
    - add a trailing strip .....202
    - remove a bottom strip .....176, 204
    - remove a left strip .....176, 204
    - remove a right strip .....176, 204
    - remove a top strip .....176, 204
  - Stripes and Banding**
    - Output quality problems .....264
  - Support**
    - Downloads: .....14
    - Knowledge base .....14
    - Manuals .....14
    - Media .....14, 355
    - OKB .....14
    - Print head .....14, 355
    - Printer drivers .....14
    - Supplies .....14, 355
  - Support tab**
    - Océ Express WebTools .....87
  - Switch off**
    - description .....77
  - Switch on**
    - description .....47
  - System**
    - defaults .....124
    - shut down or restart .....101
  - System administrator**
    - description .....102
-

- 
- System messages**
    - Printer .....308
  - System monitor**
    - description .....99
  - System requirements**
    - System requirements .....81
  - System software**
    - System software .....304
  - System states**
    - overview .....99
  - System tab**
    - Océ Express WebTools .....89
- T**
- Templates**
    - for copy jobs .....133
    - for scan jobs .....139
  - Time format**
    - description .....112
  - Tone scale area check**
    - Tone scale area check .....259
  - Top delivery tray**
    - description .....40
- U**
- Update**
    - Update .....304
  - Upload**
    - licenses .....329
  - USB mass storage device**
    - print .....56, 221
  - User interaction**
    - Océ Express WebTools .....23
    - Océ Publisher Express .....23
    - printer drivers .....23
    - user panel .....23
  - User panel**
    - keys .....37
  - User roles**
    - key operator .....102
    - Océ Express WebTools .....102
    - power user .....102
    - system administrator .....102
- V**
- View the settings**
    - Océ Express WebTools .....95
- W**
- Waves / Cockle**
    - Output quality problems .....266
  - Wizard: Change the media type**
    - Wizard: Change the media type .....48, 276
  - Wizard: Ink tube**
    - Wizard: Ink tube .....293
  - Wizard: Network settings**
    - Wizard: Network settings .....340
  - Wizard: Optimize print quality**
    - Wizard: Optimize print quality .....268, 273
  - Wizard: Replace cassette**
    - Wizard: Replace cassette .....290
  - Wizard: Replace ink tank**
    - Wizard: Replace ink tank .....281
  - Wizard: Replace print head**
    - Wizard: Replace print head .....285
  - Wizard: Security**
    - Wizard: Security .....342
  - Workflow**
    - Workflow .....338
  - Working area**
    - printing system .....28
-



# Beyond the Ordinary



## Printing for Professionals

### Creating global leadership in printing

Canon and Océ have joined forces to create the global leader in the printing industry. For our customers, this combines Canon and Océ technology with the support of the Océ direct sales and service organizations. Look to the new Canon-Océ combination for:

- Enterprise printing in the office and corporate printroom
- Large format printing of technical documentation, signage, and display graphics
- Production printing for marketing service bureaus and graphic arts
- Business Services for document process outsourcing

© 2011Océ. Illustrations and specifications do not necessarily apply to products and services offered in each local market. Technical specifications are subject to change without prior notice. Trademarks mentioned in this document are the property of their respective owners.

For more information visit us at:

[www.océ.com](http://www.océ.com)